HOBBS DIVISION

CLASS THREE PREVENTER

To Floor Manifold

2" Check Valve

EKL to Accumulator

ALL 2" MIN. ON KILL SIDE

2" STEEL VALVE

IF POSSIBLE, CASING SPOOL SHOULD
BE POSITIONED SO THAT THESE
VALVES ARE DIRECTLY UNDER THE
BARREL OF THE RAM PREVENTER

Fill Connection

Rotating BOP

FLOW LINE

ANNULAR PREVENTER

BLIND RAMS

PIPE RAMS

DRILLING SPOOL

B SEC.

CSG. HEAD

4" STEEL VALVES

4" LINE

CHOKE MANIFOLD

ADJUSTABLE CHOKE

FLANGED STEEL CROSS

2" STEEL VALVE

2" STEEL VALVE

4" STEEL VALVE

PRESSURE GAUGE CONNECTION

ADJUSTABLE CHOKE

Beyond Edge of Derrick Floor

2" BALL VALVES

TO STEEL PITS

TO BURN PIT