

HOBBS DIVISION CLASS III PREVENTER





FIGURE III-4
THREE PREVENTER HOOKUP
CLASS III



IF POSSIBLE, CASING SPOOL SHOULD BE POSITIONED SO THAT THESE VALVES ARE DIRECTLY UNDER THE BARREL OF THE RAM PREVENTER

GENERAL INSTRUCTIONS ON PAGE FOLLOWING FIGURE III-7