NO. OF COPIES RECEIVED	4
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	2

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

5a. Indicate Type of Lease

State ☐   Fee ☒

5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT —" (FORM C-101) FOR SUCH PROPOSALS.)

1.

OIL WELL ☐   GAS WELL ☐   OTHER- Convert to water-injection from SI

7. Unit Agreement Name

Hospah Sand Unit

2. Name of Operator

Tesoro Petroleum Corporation

8. Farm or Lease Name

3. Address of Operator

2000 First of Denver Plaza, 633 17th Street, Denver, CO 80202

9. Well No.

49

4. Location of Well

UNIT LETTER ___A___, ___330___ FEET FROM THE ___North___ LINE AND ___1380___ FEET FROM

THE ___East___ LINE, SECTION ___1___ TOWNSHIP ___17N___ RANGE ___9W___ NMPM.

10. Field and Pool, or Wildcat

Hospah Upper Sand

15. Elevation (Show whether DF, RT, GR, etc.)

6956' Ground Level

12. County

McKinley

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐   PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

PULL OR ALTER CASING ☐   CHANGE PLANS ☐

OTHER Deepen in same zone and convert to water injection well. ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐   ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐   PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER _____ ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to convert HSU-49 from SI producer to water injection well by:

1. Fish packer and tubing out of hole.
2. Clean out to 1585 ft. TD.
3. Deepen 10 ft. to 1595 ft. TD (Open hole from 1560 ft. to 1595 ft.) with oil for drilling fluid.
4. Set Guiberson Unipacker VI with Type-L ON-OFF tool at 1530 ft.± with 2 3/8" tubing.
5. With standing valve in ON-OFF tool, come off tool, circulate oil out, and spot inhibited, gelled, packer-fluid.
6. Sting back onto ON-OFF tool and pull standing valve.
7. Put on injection.

(NMOCC:R-2807 authorizes waterflood)

SEP 20 1971
OIL CON. COM.
DIST. 3

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _William J Hicks_   TITLE _Asst Prod Supt_   DATE _____

APPROVED BY _A R Kendrick_   TITLE _____   DATE _____

SUPERVISOR DIST. #3

CONDITIONS OF APPROVAL, IF ANY: