**Operator** Shackelford Oil Company
**Well** Arrington Federal #1
**Unit** C **Section** 14 **Twnship** 19 **Range** 31
**API #** 30-0 15 - 20756

**TOPS**

| | | |
|---|---|---|
| Rustler | @ | 650 |
| Salado | @ | 900 |
| B Salt | @ | 2200 |
| Yates | @ | 2400 |

← Plug 60' - 0' surface.

← Shoe Plug 900' - 600' Perf + Squeeze TAG

← 2524' TAG

- Contact OCD 24 hrs. prior to any work done.
- Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
- Install dry hole marker as per Rule 202.B.2
- Plugs are to be set from point indicated **up.**
- Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
- Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
- Surface plug will be from 0' - 60'
- Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists.**
- Plugs to be tagged will be indicated.