Operator Duane Parrish
Well Caroline #1
Unit C **Section** 28 **Twnship** 19 **Range** 28
API # 30-015-02305

TOPS

Salado	300
B Salt	472
Yates	~700
7 Rivers	1040

60' Surface Plug

300' - TAG

378' TOC @ 50%

700' - TAG

1050' - TAG

1076-1178' Perfs

4 1/2 1220'
200 sxs.
7" hole

* Contact OCD 24 hrs. prior to any work done.
* Salt gel mud consisting of 10# brine with 25# of gel per barrel must be placed between each plug.
* Install dry hole marker as per Rule 202.B.2
* Plugs are to be set from point indicated **up.**
* Plugs must not be less than 100' or 25 Sacks of cement, whichever is greater, unless specifically indicated.
* Shoe and stub plugs will be 50' above and below shoe or stub and tagged.
* Surface plug will be from 0' - 60'
* Where plugs are required, cement must be placed inside and outside of **all** casing string(s) in the correct footage or sacks required, **if no cement exists.**
* Plugs to be tagged will be indicated.