RECEIVED

MAY 1 1 2012

Form 3160-3 (March 2012)

NMOCD ARTESIA

FORM APPROVED
ONIB No 1004 0137
Expires October 31, 2014

UNITED STATES
DEPARTMENT OF THE INTERIOR

5 Lease Serial No

	BUREAU OF LAND MANAGEMENT				(SH) NMNM25533 (BH) LC061705B			
APPLICATION FOR PERMIT TO				6 If Indian, Allote	e or Tribe	Name	-	
ATTENDATION TOTAL PERSON. TO	DITTEL 0	THE COUNTRY		·		*	_	
ia. Type of work DRILL RELENTI	ER.			7 If Unit or CA Ag NMNM071016X	reement, N	ame and No.	_	
fb. Type of Well Oil Well Gas Well Other	 □ s	ingle Zone Multip	ole Zone	8 Lease Name and Well No. PLU BIG SINKS 19 24 31 USA 1 143916				
2 Name of Operator CHESAPEAKE AGENT FOR BOPCO				9 API Well No.	15-	4026		
3a. Address PO BOX 18496	3b Phone No	O. (include urea code)		10 Field and Pool. o				
OKLAHOMA CITY, OK 73154-0496	405-935-2	896		WILDCAT; BONE	SPRING	296	4037	
4. Location of Well (Report location clearly and in accordance with an	3' State requirer	nenis *)		11 Sec , T R M. or	Blk and Su	rvey or Area	•	
At surface 140' FNL & 1980' FWL NENW				19-24S-31E				
At proposed prod zone 100' FSL & 1980' FWL SESW								
14 Distance in inites and direction from nearest town or post office* 30 MILES SE OF LOVING, NM				12 County or Parish EDDY		13. State NM	-	
15 Distance from proposed* Incution to nearest property or lease line ft (Also to nearest drig unit line if any)	16 No. of a 2054.68	acres in Jease	17 Spacin 160 00	ng Unit dedicated to this well			-	
18 Distance from proposed location* to nearest well, drifting, completed partial for our thing least 6	19 Proposed Depth 20 BLM 14017 MD ESB00			/BIA Bond No on file			-	
applied for on this lease, ft, PATTON 18 FEDERAL 6	9403 TVD			100				
21, Llevations (Show whether Dr. KDB, RT, Gl. etc.)	The state of the s			23. Estimated durati	on		_	
3495 GL	05/10/2012			30 DAYS			-	
	24 Atta						_	
The following, completed in accordance with the requirements of Oushor	e Gil and Gas	Order No 1, must be at	tached to thi	s form			-	
Well plat certified by a registered surveyor. A Drilling Plan		4 Bond to cover the Item 20 above)	e operation	ns unless covered by a	n existing b	ond on file (see		
3. A Surface Use Plan (if the location is on National Lorest System SUPO must be filed with the appropriate Lorest Service Office).	Lands, the	5 Operator certifies 6 Such other site s BLM		rmation and or plans a	is may be re	equired by the		
25 Signature Con Cov		(Printed Typed) Carson			Date \(05/10/2	2012	:	
File Regulatory Corpolance Technician III	4		****		 		•	
Approved by (Signatule)	Name	(Printed Typed)			Date _5	110	l_{12}	
Title AFM	Office	BLM	1 Carlsbac	d Field Office	1		, ,	
Application approval does not warrant or certify that the applicant holds conduct operations thereon. Conditions of approval if any, are attached	legal or equi	table title to those rights	s in the subj	ect lease which would	entitle the a	pplicant to		
Fitte 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a cristales any false. Fictitious or fraudulent statements or representations as to	me for any pe any matter w	erson knowingly and within its jurisdiction.	illfully to m	ake to any department	or agency o	of the United		
(Continued on page 2)	UNAL	ble to DR	oduc	e We/*(Inst	tructions	on page 2)		
WATER BASIN	unti	ble to pro LNSL	pern	nit issu	xed"	105,	h -	
CARLSBAD CONTROLLED WATER BASIN		A DDI	20VAI	SUBJECT	TN	5/11/	12012	

SEE ATTACHED FOR CONDITIONS OF APPROVAL

APPROVAL SUBJECT TO
GENERAL REQUIREMENTS AND
SPECIAL STIPULATIONS
ATTACHED

CERTIFICATION

I hereby certify that I, or someone under my direct supervision, have inspected the drill site and access route proposed herein; that I am familiar with the conditions which currently exist; that I have full knowledge of state and Federal laws applicable to this operation; that the statements made in this APD package are, to the best of my knowledge, true and correct; and, that the work associated with the operations proposed will be performed in conformity with this APD package and the terms and conditions under which it is approved. I also certify that I, or the company I represent, am responsible for the operations conducted under this application. These statements are subject to the provisions of 18 U.S.C. 1001 for the filing of a false statement.

Executed this 13th day of IRWUARY., 2011

Name: 10-ly Reid Superintendent

Address: 1616 W Bender Blvd Hobbs, NM 88240

Telephone: 575-725-8497

E-mail: toby.reid@chk.com

DISTRICT I

1825 N French Dr., Hobbs, NM 88240
Phone (678) 593-6161 Fax: (576) 593-0720

DISTRICT II

1301 W Grand Avenue, Artesia, NM 88210
Phone (675) 748-1283 Fax: (575) 748-6720 DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410
Phone (503) 334-8170 Fax: (505) 334-8170

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-102 Revised August 1, 2011

Submit one copy to appropriate District Office

OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, New Mexico 87505

QA API	Number	2/1		Pool Code	AND ACREA	AGE DEDICATI	Pool Name		
50-0/5 Property 0	- 70	1261	<u> </u>	96403	Property Nat		CAT; BONE SPF	RING Well No	ımbeı
39169	l			PLU BIG		NKS 19 24 31 USA 2 H			
OGRID No					Operator Nac	· · · · · · · · · · · · · · · · · · ·			
147179				CHESA	PEAKE OPER		·	349	O
UL or lot No.	Section	Township	Range	Lot Idn	Surface Loc	North/South line	Feet from the	East/West line	County
C	19	24 S	31 E	Lot Idn	140	NORTH	1980	WEST	EDD,
		<u> </u>		Hole Lo	<u> </u>	erent From Sur		1 11201	
UL or let No.	Section	Township	Range	Lot Idn	Feet from the	North/South line	Feet from the	East/West line	County
l N	19	24 S	31 E		100	SOUTH	1980	WEST	EDD.
Dedicated Acres	Joint c	or Infill Co	onsolidation	Code Or	der No.				
NO ALLO	WABLE V					UNTIL ALL INTER APPROVED BY		EEN CONSOLID	ATED
ECTED FIRST PERFOF 330' FSL & 1980' FW	Project Area OITS	Producing Area	3496 6'	Long – W NMSPCE– (NA Lal – N Long – W NMSPCE–	32.20968230' N 440396.683 E 700325.021 D-83) 32.20955888' 103.81879653' N 440338.019 E 659140.515 D-27)		Email Addre	n Arrant bryan arrant@	Date Chk com FION Clon shown d notes of under my
				HOLE La1 - N Long - W NMSPCE- (NAI La1 - N	ED BOTTOM LOCATION 32.19581043* 103.81929030* N 435350.274 E 700346.057 D-B3) 32.19568686* 103.81880716* N 435291.591 E 659161.635	Paris and Paris and American American	Date Survey Signature & Professional	MSERATE 201 AND UNA 11 TO HOL UNA 11 TO GOTY L. Jone:	1

ONSHORE ORDER NO 1 Chesapeake Operating, Inc, Agent for BOPCO PLU Big Sinks 19-24-31 USA 1H CONFIDENTIAL -- TIGHT HOLE Lease No.

Eddy, NM

DRILLING PLAN PAGE. 1

OHSORE OIL & GAS ODER NO. 1 Approval of Operations on Onshore Federal and Indian Oil and Gas Leases

All lease and/or unit operations are to be conducted in such a manner that full compliance is made with the applicable laws, regulations (CFR 43, Part 3160) and the approved Application for Permit to Drill. The operator is considered fully responsible for the actions of his subcontractors. A copy of the approved APD must be on location during construction, drilling and completion operations.

Approval of this application does not warrant or certify that the applicant holds legal or equitable title to those rights in the subject lease, which would entitle the applicant to conduct operations thereon

1. FORMATION TOPS

The estimated tops of important geologic markers are as follows

FORMATION	SUB-SEA .	KBTVD	MD
Rustler	2976	544	
Top of Salt	2702	818	
Base of Salt	-477	3997	
Lamar	-700	4220	
Bell Canyon	- 720	` 42 4 0	
Cherry Canyon	-1636	5156	
Brushỳ Canyon	-2902	6422	
Bone Spring	-4580	8100	
Pilot Hole ·	-6180	9700	
Lateral TD	-5883	9403	14018

2. ESTIMATED DEPTH OF WATER, OIL, GAS & OTHER MINERAL BEARING FORMATIONS

The estimated depths at which the top and bottom of the anticipated water, oil, gas, or other mineral bearing formations are expected to be encountered are as follows.

Substance	Formation	Depth
Water	Rustler	544
Oil/Gas	Brushy Canyon	6422
Oil/Gas	Bone Spring	8100

All shows of fresh water and minerals will be reported and protected.

Chesapeake Minimum BOPE Requirements

Wellname: PLU Big Sinks 19-24-31 USA 1H

Operation: Intermediate and Production Hole Sections

BLOWOUT PREVENTOR SCHEMATIC

CHESAPEAKE OPERATING INC

Permian District-Minimum Requirements

FIELD


: Avalon

OPERATION: Intermediate and Production Hole Sections

SIZE PRESSURE DESCRIPTION **Rotating Head** 500 B 13 5/8 5,000 Annular C 13 5/8 5,000 Pipe Ram D 13 5/8 5,000 Blind Ram E 13 5/8" 5,000 **Mud Cross** F DSA As required for each hole size C-Sec B-Sec 13-5/8" 3K x 11" 5K A-Sec 13-3/8" SOW x 13-5/8" 3K

Test Notes

- Pressure test to rating of BOP or wellhead every 21 days. Function test on trips H2S service trim required



Kill Line

SIZ	E PRESSUR	E DESCRIPTION
2*	5,000	Chéck Valve
2*	5,000	Gate Valve
2*	5,000	Gate Valve
		,

Choke Line

SIZE	PRESSURE	DESCRIPTION
3"	5,000	Gate Valve
3*	5,000	HCR Valve
3"	5,000	Steel Line Only

EXHIBIT FI

Chesapeake Operating, Inc. Agent for BOPCO PLU Big Sinks 19-24-31 USA 1H

CONFIDENTIAL -- TIGHT HOLE Lease No.

DRILLING PLAN

Eddy, NM

PAGE

2

3. BOP EQUIPMENT

Will have a 5000 psi rig stack (see proposed schematic) for drill out below surface casing. Stack will be tested as specified below. Surface casing and Intermediate Casing shoes will be tested to 10.5 ppg equivalent after drilling out 10' of new formation.

Chesapeake Operating Inc.'s minimum specifications for pressure control equipment are as follows:

I. BOP, Annular, Choke Manifold Pressure Test - See Exhibit F-1 and F-2

A Equipment

- 1. The equipment to be tested includes all of the following that is installed on the well.
 - (a) Ram-type and annular preventers
 - (b) Choke manifolds and valves
 - (c) Kill lines and valves
 - (d) Upper and lower kelly cock valves, inside BOP's and safety valves

B Frequency

- 1. All tests shall be performed with clear water
 - (a) when installed
 - (b) before drilling out each casing string
 - (c) at any time that there is a repair requiring a pressure seal to be broken in the assembly
 - (d) at least once every 30 days while drilling

C. Frequency

- 1 In some drilling operations, the pressures to be used for low and high pressure testing of preventers and casing may be different from those given below due to governmental regulations or approved local practices
- 2 If an individual component does not test at the low pressure, do not test to the high pressure and then drop back down to the low pressure.
- 3 All valves located downstream of a valve being tested must be placed in the open position.
- 4. All equipment will be tested with an initial "low pressure" test at 250 psi.
- 5 The subsequent "high pressure" test will be conducted at the rated working pressure of the equipment for all equipment except the annular preventer.
- 6. The "high pressure" test for the annular preventer will be conducted at 70% of the rated working pressure.
- 7 A record of all pressures will be made on a pressure-recording chart.

II Accumulator Performance Test

A Scope

1. The purpose of this test is to check the capabilities of the Bop control systems and to detect deficiencies in the hydraulic oil volume and recharge time

B. Test Requency

1 The accumulator is to be tested each time the BO's are tested, or any time a major repair is performed.

ONSHORE ORDER NO. 1 Chesapeake Operating, Inc. Agent for BOPCO PLU Big Sinks 19-24-31 USA 1H CONFIDENTIAL -- TIGHT HOLE
Lease No.

DRILLING PLAN

PAGE

Eddy, NM

C. Minimum Requirements

- 1 The accumulator should be of sufficient volume to supply 1.5 times the volume to close and hold all BOP equipment in sequence, without recharging and the pump turned off, and have remaining pressures of 200 psi above the precharge pressure
- 2 Minimum precharge pressures for the various accumulator systems per manufacturers recommended specifications are as follows

System Operating Pressure	Precharge Pressure
1500 psi	750 psi
2000 psi	1000 psi
3000 psi	1000 psi

- 3. Closing times for the annular preventer should be less than 20 seconds and for the ram-type preventers less than 10 seconds
- 4 System recharge time should not exceed 10 minutes

D. Test Procedure

- 1. Shut accumulator pumps off and record accumulator pressure
- 2. In sequence, close the annular and one set of properly sized pipe rams, and open the HCR valve
- 3 Record time to close or open each element and the remaining accumulator pressure after each operation
- 4 Record the remaining accumulator pressure at the end of the test sequence Per the previous requirement, this pressure should not be less than the following pressures

System Operating Pressure	Remaining Pressure After Test
1500 psi	950 psi
2000 psi	1200 psi
3000 psi	1200 psi

- 5 Turn the accumulator pumps on and record the recharge time. This time should not exceed 10 minutes.
- 6. Open annular and ram-type preventers Close HCR valve
- 7 Place all 4-way control valves in full open or full closed position. Do not leave in neutral position

3 CASING PROGRAM

a. The proposed casing program will be as follows

Purpose	From	То	Hole Size	Csg Size	Weight	Grade	Thread	Condition
Surface	0'	650'	17-1/2"	13-3/8"	48#	H-40	STC	New
Shallow Intermediate	0'	4,100'	11"	8-5/8"	32 #	J-55	LTC	New
Production		14.018'	7-7/8"	5-1/2"	20.0#	1 00	LTC	Nou
Production	U	14,010	1-110	0-1/2	20.0#	L-80	LIC	New

b Casing design subject to revision based on geologic conditions encountered

DRILLING PLAN

Eddy, NM PAGE

c. Casing Safety Factors

Casing String	Min SF Burst	Min SF Collapse	Min SF Tension
Surface	1.41	2.62	2.53
Shallow Intermediate	1.41	1.43	1,97
Production	1 21	2.06	1 59

Min SF is the smallest of a group of safety factors that include the following considerations

	Surf	Int	Prod
Burst Design			
Pressure Test- Surface, Int, Prod Csg	Х	Х	Х
P external. Water			
P internal Test psi + next section heaviest mud in csg			
Displace to Gas- Surf Csg	Х		
P external [.] Water			
P internal Dry Gas from Next Csg Point			
Frac at Shoe, Gas to Surf- Int Csg		Х	
P external. Water			
P internal Dry Gas, 15 ppg Frac Gradient			
Stimulation (Frac) Pressures- Prod Csg			X
P external Water			
P internal: Max inj pressure w/ heaviest injected fluid			
Tubing leak- Prod Csg (packer at KOP)			X
P external Water			
P internal. Leak just below surf, 8.7 ppg packer fluid	1		,
Collapse Design			
Full Evacuation	Х	Х	X
P external Water gradient in cement, mud above TOC			
P internal none			
Cementing- Surf, Int, Prod Csg	Х	Х	X
P external Wet cement			ľ
P internal. water			
Tension Design			
100k lb overpull	×	Х	X

ONSHORE ORDER NO 1 Chesapeake Operating, Inc. Agent for BOPCO PLU Big Sinks 19-24-31 USA 1H CONFIDENTIAL -- TIGHT HOLE Lease No:

DRILLING PLAN

PAGE: 5

5. **CEMENTING PROGRAM**

Eddy, NM

Slurry	Туре	Тор	Btm	Wt	Yld	%Exc	Sx
Surface				(ppg)	(sx/cu ft)	Open Hole	
Single Slurry	C + 4% Gel	0,	650'	13 5	, 1.73	200	758
Shallow Int							
Lead	TXI + 5% Salt	0,	3,600'	12	1.99	200	1280
Tail	50C/50Poz +5% Salt	3,600'	4,100'	14 2	1.37	200	290
Production -	, , , , , , , , , , , , , , , , , , , ,					, ·	
1st Stage lead	35/65Poz H +8% Gel	5,050'	8,950'	12 4	2.11	75	560
1st Stage Tail	50/50Poz H +2% Gel	8,950'	14,018'	14 5	1 27	75	1218
	35/65Poz C +6% Gel						
2nd Stage Lead	+ 5% Salt	3,600'	4,800'	12.4	2 19	200	207
2nd Stage Tail	С	4,800'	5,050'	14 8	1 33	200	98

- 1. Final cement volumes will be determined by caliper.
- 2. Surface casing shall have at least one centralizer installed on each of the bottom three joints starting with the shoe joint.
- 3. The production casing will be cemented in two stages with the DV tool place at 5,050'
- 4. Production casing will have one centralizer on every other joint from TD to KOP (horizontal type) and from KOP to intermediate casing (bowspring type)

Pilot Hole Plugging Plan

Pilot hole will be plugged back from TD of 9,700' TVD to KOP of 8,948' TVD with a single balanced plug using tubing that will be cemented in place on the bottom of the Smith Trackmaster OH-Openhole whipstock cmenting system (previously approved by BLM) This will be accomplished using 360 sx (40% excess) of 17.0 ppg 0 99 cuft/sk yield Class H cement.

ONSHORE ORDER NO 1 Chesapeake Operating, Inc. Agent for BOPCO PLU Big Sinks 19-24-31 USA 1H CONFIDENTIAL -- TIGHT HOLE
Lease No.

DRILLING PLAN

PAGE

Eddy, NM

6 MUD PROGRAM

From	То	Туре	Weight	F. Vis	Filtrate
0'	650'	Spud Mud	8.4 - 8.7	32 - 34	NC - NC
650'	4,100'	Brine	9.5 - 10 1	28 - 29	NC - NC
4,100'	8,948'	Cut Brine	8.3 - 8 8	28 - 29	NC - NC
8,948'	9,700'	Cut Brine	83-88	28 - 29	NC - NC
8,948'	9,701'	Cut Brine	83-8.8	28 - 29	NC - NC
. 9.701'	14,018'	Cut Brine	83-8.8	28 - 29	NC - NC

A closed system will by utilized consisting of above ground steel tanks. All wastes accumulated during drilling operations will be contained in a portable trash cage and removed from location and deposited

All fluids and cuttings will be disposed of in accordance with New Mexico Oil Conservation Division rules and regulations

A mud test shall be performed every 24 hours after mudding up to determine, as applicable. density, viscosity, gel strength, filtration, and pH.

7. TESTING, LOGGING, AND CORING

The anticipated type and amount of testing, logging, and coring are as follows:

- a. Drill stem tests are not planned
- b The logging program will be as follows:

TYPE	Logs	Interval	Timing	Vendor
Mud Log	2 man Mudlog	Int Cas to TD	Int Csg Drill out	Suttles
ОН	Triple Combo	Curve to Int Csg	After Curve	TBD
ОН .	GR/Neutron	Int Cas to Surf	After Curve	TBD
LWD	MWD Gamma	Curve and Lateral	While Drilling	Ryan

- c. Core samples are not planned.
- d. A Directional Survey will be run.

8. ABNORMAL PRESSURES AND HYDROGEN SULFIDE

a. No abnormal pressures or temperatures are expected. Estimated BHP is: 4540 psi

b. Hydrogen sulfide gas is not anticipated.

PECOS DISTRICT CONDITIONS OF APPROVAL

OPERATOR'S NAME:	Chesapeake Operating Inc.			
	NMLC061705B			
WELL NAME & NO.:	PLU Big Sinks 19 24 31 USA 1Y			
SURFACE HOLE FOOTAGE:	140' FNL & 1980' FWL	,		•
BOTTOM HOLE FOOTAGE	100' FSL & 1980' FWL	,	•	
LOCATION:	Section 19, T. 24, S., R. 31, E., NMPM			
COUNTY:	Eddy County, New Mexico			

TABLE OF CONTENTS

Standard Conditions of Approval (COA) apply to this APD. If any deviations to these standards exist or special COAs are required, the section with the deviation or requirement will be checked below.

General Provisions
Permit Expiration
Archaeology, Paleontology, and Historical Sites
Noxious Weeds
Special Requirements
Lesser Prairie-Chicken Timing Stipulations
Ground-level Abandoned Well Marker
Commercial Well Determination
Construction
Notification
Topsoil
Closed Loop System
Federal Mineral Material Pits
Well Pads
Roads
Road Section Diagram
☑ Drilling
Logging requirements
Waste Material and Fluids
Production (Post Drilling)
Well Structures & Facilities
Pipelines
Electric Lines
☐ Interim Reclamation

Chesapeake Operating, Inc.'s Closed Loop System PLU BIG SINKS 19 24 31 USA 1H Unit C, Sec. 19, T-24-S R-31-E Eddy Co., NM API # 30-015-

Equipment & Design:

Chesapeake Operating, Inc. is to use a closed loop system with roll-off steel pits. Cactus Drilling Company (#120) has the following equipment for maintenance of their drilling mud:

Mud System:

- (2) Derrick FLC-503 Linear Motion Shale Shakers
- (1)NOV 16-cone/4" desilter
- (1) NOV 2 cone/ 10" desander

Fresh and brine water tanks with the capacity to efficiently drill well

Operations & Maintenance:

During each tour, the rig's drilling crew will inspect and monitor the drilling fluids contained within the steel pits and visually monitor any spill which may occur. Should a spill, release, or leak occur; the NMOCD District II office in Artesia (575-748-1283) will be notified. Please note that notifications may be made earlier to the district office should a greater release occur per NMOCD's rules.

Closure:

During and after drilling operations, drilling fluids and cuttings will be hauled to Controlled Recovery, Inc. Permit # NM-01-0006.

The alternative disposal facility will be Sundance Disposal. Permit # NM-01-000

Chesapeake Minimum BOPE Requirements


Wellname: PLU Big Sinks 19-24-31 USA 1H

Operation: Intermediate and Production Hole Sections

CHOKE MANIFOLD SCHEMATIC

CHESAPEAKE OPERATING INC

Permian District
Avalon Minimum Requirements



Permian District

Poker Lake PLU Big Sinks 19-24-31 USA 1H Well #1

Wellbore #1

Plan: Plat

Standard Planning Report

02 February, 2012

EXHIBIT 6

Planning Report

Drilling Database Database: Local Co-ordinate Reference: Well Well #1 Local Co-orginate Rejerence:

WELL @ 0 Ousft (Original Well Elev)

MD Reference:

WELL @ 0 Ousft (Original Well Elev)

WELL @ 0 Ousft (Original Well Elev)

Grid

Minimum Curvature Company: Permian District Project: Poker Lake PLU Big Sinks 19-24-31 USA 1H Site: 📑 Well: Well #1 Survey Calculation Method Wellbore #1 Wellbore: Design: Plat

Project Poker Lake, Eddy County, NM

Map System: US State Plane 1983 Geo Datum: North American Datum 1983 Map Zone: New Mexico Eastern Zone

IGRF200510

System Datum: Ground Level

المنطانين سيمولناه محمد بعناه ويراهون مراعه والمعارض والمعل والمعل المناهد المالية المالية والموادي والمدار الماليات Northing: 440,397 00 usft Latitude: Site Position:

1/13/2012

32.209682 From: Easting: 700,325 00 usft Longitude: -103 819281 0 0 usft Position Uncertainty: Slot Radius:

13.200 in Grid Convergence: 0.27°

大学,"我们是一个""我们的一个",这里是一个是是一个,我们也不是我们的,我们就是我们的的,我们就是一个的,他们就是一个时间,我们就是一个的人,这个人,这个人,

かかかっていたしゃしい しん しつかんいんしょうというかん こうしんかんきゅう しんれんしゅんしゅんしゅん Well Position 0 0 usft Northing: 440,397.00 usft Latitude:

+E/-W 0 0 usft Easting: 700,325 00 usft Longitude: -103 819281 **Position Uncertainty** 0 0 usft Wellhead Elevation: **Ground Level:**

Wellbore a construction for the property of a construction of the construction of the property of the construction Declination Dip Angle Rield Strength Magnetics (TT)

Design or the secretion of the control of the secretary and the secretary and the secretary **Audit Notes:** Version. **PROTOTYPE** Phase: 00 Tie On Depth. Vertical Section: Depth From (TVD) +N/-S. +E/-W ... Direction (usft) 🖰 (usft) 🕝 "(usft) 🎏

Plan Sections Dogleg Build Vertical Measured vertical Depth Turn Răte Depth Inclination Azimuth +N/-S 4E/-W Rate (usft) ر**(°)** ر (usft) (usft) %(°/100usft) (°/100usft) (°/100usft) √ (°) (usft) 00 0 00 0 00 0.0 0.0 0.0 0.00 0.00 0.00 0.008,948 1 0 00 0 00 8,948 1 00 00 0.00 0.00 0.00 0.00 9,7006 90 30 179.76 9,4256 **-4800** 20 12 00 12 00 0 00 179 76 14,0177 90 30 179 76 9,403 0 -4,797 0 200 0.00 0 00 0.00 0 00 BS 19-24-31 USA 1

Planning Report

Drilling Database Database:

Company. Permian District . Poker Lake Project:

PLU Big Sinks 19-24-31 USA 1H

Site: ∛Well #1 Well: Wellbore: Wellbore #1 Local Co-ordinate Reference: Well Well #1

TVD Reference: MD Reference:

MD Reference: North Reference: Survey Calculation Method:

WELL @ 0 Ousft (Original Well Elev)

WELL @ 0.0usft (Original Well Elev)

Grid...

Minimum Curvature

Wellbore: Design:	Wellbore #1		and the state of t		المنافقة المنافقة المنافقة		2		
Planned Survey		and a second of the second of	الورد و درود المارود ا	ار در	معددها در محددها در المحددهات مشتله المحدد المحددهات	and the second	the state of the s	THE MENT THEY	المناسبة معامله المناسبة عن المناسبة ا
Measured Depth (usft)	Inclination (°)	Azimuth	Vertical Depth (usft)	+N/-S (usft)	+E/-W- (usft)	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Rate (°/100usft)	ETurn Rate (°/100usft)
00	0 00	0 00	0.0	0.0	0.0	0.0	0.00	0 00	0.00
100 0 200.0	0 00 0 00	0.00 0 00	100 0 200 0	0 0 0 0	00	0.0	0.00 0 0 0	0 00 0.00	0 00
300.0	0 00	0 00	300 0	00	0.0 0.0	0 0 0 0	0 00	0.00	0 00 0.00
400 0	0 00	0 00	400 0	00	00	0.0	0 00	0.00	0.00
500 0	0 00	0 00	500 0	0 0	0 0	0 0	0 00	0 00	0 00
600 0	0 00	0 00	600.0	0 0	0.0	0.0	0.00	0.00	0 00
700.0	0 00	0 00	700 0	0 0	00	0 0	0 00	0 00	0 00
800.0	0 00	0 00	800 0	0.0	0.0	0 0	0 00	0 00	0 00
900 0	0 00	0.00	900 0	0.0	0 0	0 0	0 00	0 00	0 00
1,000 0	0 00	0 00	1,000 0	0 0	00	0.0	0 00	0 00	0 00
1,100 0 1,200 0	0 00 0 00	0 00 0.00	1,100 0 1,200 0	0 0 0 0	0 0 0 0	0 0 0 0	0 00 0 00	0 00 0 00	0 00 0 00
1,300 0	0 00	0.00	1,300 0	0.0	00	00	0 00	0.00	0 00
1,400 0	0 00	0 00	1,400 0	0.0	00	00	0 00	0.00	0 00
1,500 0	0 00	0 00	1,500 0	0.0	0 0	0.0	0 00	0 00	0 00
1,600.0	0 00	0.00	1,600 0	00	0.0	00	0.00	0 00	0 00
1,700 0	0.00	0.00	1,700 0	0 0	0 0	0 0	0 00	0.00	0 00
1,800.0	0 00	0.00	1,800 0	0.0	00	0.0	0 00	0 00	0 00
1,900.0	0 00	0.00	1,900 0	00	0 0	0 0	0 00	0 00	0 00
2,000 0	0 00	0 00	2,000.0	00	0.0	0.0	0 00	0 00	0 00
2,100.0 2,200 0	0 00 0 00	0 00 0.00	2,100.0 2,200 0	0 0 0 0	0.0	0.0	0 00	0 00	0 00
2,300 0	0 00	0.00	2,200 0	0.0	0 0 0.0	0 0 0 0	0 00 0 00	0 00 0 00	0.00 0 00
2,400 0	0 00	0.00	2,400 0	0.0	0.0	0.0	0.00	0 00	0 00
2,500 0	0 00	0 00	2,500 0	0 0	0.0	0.0	0 00	0 00	0 00
2,600 0	0 00	0 00	2,600 0	00	0 0	00	0 00	0 00	0 00
2,700 0	0 00	0 00	2,700 0	0.0	0.0	00	0 00	0 00	0 00
2,800 0 2,900 0	0 00 0.00	0 00 0 00	2,800 0 2,900.0	0.0 0.0	0 0 0 0	0 0 0 0	0 00 0 .00	0 00 0 00	0.00 0 00
3,000 0 3,100 0	0.00 0 00	0 00 0 00	3,000 0 3,100 0	0 0 0 0	0 0 0 0	0 0 0 0	0 00 0 00	0 00 0.00	0 00 0 00
3,200 0	0 00	0 00	3,200 0	00	00	00	0 00	0.00	0.00
3,300 0	0 00	0 00	3,300 0	0.0	0.0	00	0 00	0 00	0 00
3,400 0	0.00	0 00	3,400 0	0 0	0.0	0 0	0.00	0 00	0 00
3,500 0	0 00	0 00	3,500 0	0.0	0 0	0 0	0.00	0.00	0 00
3,600 0	0 00	0 00	3,600 0	0 0	0 0	00	0.00	0.00	0.00
3,700 0 3,800.0	0 00 0 00	0 00 0 00	3,700 0 3,800 0	0.0	0.0	0.0	0 00	0 00	0.00
3,900.0	0 00	0.00	3,900 0	0.0 0 0	00	0 0 0 0	0 00 0 00	0 00 0 00	0 00 0 00
4,000 0	0 00	0.00	4,000 0	00	00	00	0 00		
4,100.0	0 00	0.00	4,100 0	00	00	00	0 00	0.00 0 00	0.00 0.00
4,200.0	0 00	0 00	4,200 0	0.0	0.0	0.0	0 00	0 00	0 00
4,300.0	0 00	0 00	4,300 0	0 0	0 0	0.0	0.00	0 00	0 00
4,400.0	0 00	0.00	4,400.0	0 0	0.0	0 0	0 00	0 00	0 00
4,500.0	0 00	0 00	4,500 0	0.0	0 0	0 0	0 00	0 00	0.00
4,600.0	0.00	0 00	4,600 0	0 0	0 0	0.0	0 00	0 00	0 00
4,700 0 4,800 0	0 00 0 00	0 00 0.00	4,700 0 4,800.0	0.0	0.0	0.0	0 00	0 00	0 00
4,900 0	0 00	0.00	4,800.0	0 0 0 0	0 0 0 0	0 0 0 0	0 00 0 00	0 00 0 00	0 00 0 00
5,000 0 5,100 0	0.00 0.00	0.00 0 00	5,000 0 5,100 0	0.0 0 0	0.0 0.0	0 0 0 0	0 00 0 00	0 00 0 00	0.00 0.00
5,200.0	0.00	0 00	5,200.0	00	0.0	00	0 00	0 00	0 00
5,300 0	0.00	0 00	5.300.0	0.0	0.0	0.0	0.00	0.00	0.00

5,300 0

00

00

00

0 00

0 00

5,300 0

0.00

0.00

0 00

Planning Report

Drilling Database Database: Company:

Permian District Poker Lake

Well Well #1 WELL @ 0 0usft (Original Well Elev)

Project: PLU Big Sinks 19-24-31 USA 1H Site:

TVD Reference:
MD Reference:
North Reference:
Survey Calculation Method:

Local Co-ordinate Réference de

WELL @ 0 Ousft (Original Well Elev)

Well: Well #1 Wellbore: Wellbore #1 blat with the way of the way and the same of the same Design:

Ğrıd Minimum Curvature

Planned Survey

Veli: Velibore:	Well #1 Wellbore #1			Survey	Calculation	Method:	Minimum C	urvature	, , , , , , , , , , , , , , , , , , ,
Design:	Plat		Marie Carlotte State Comercial	mention and region of				seria desservada se procesa.	A THE PERSON OF
Planned Survey	is while there	به پښته په د شويد	and the second	د پېښې په د د درسه نوسري د پېښې په د د د درسه نوسري		ش سد سرته	The state of the s	en april man district	أدسيه والمراجع المراجع المجاد المام المجاد الم
Measured Depth (usft)	inclination (°)	Azimuth	Vertical Depth (usft)	+N/-S (usft)	+E/-W	Vertical Section (usft)	Dogleg Rate (°/100usft)	Build Råte (°/100usft)	Turn Rate (°/100úsft)
5,400 0	0 00	0 00	5,400.0	0.0	00	00	0 00	0 00	0 00
5,500 0 5,600 0 5,700 0 5,800 0 5,900.0	0 00 0 00 0 00 0.00 0 00	0 00 0 00 0 00 0 00 0 00	5,500 0 5,600 0 5,700 0 5,800.0 5,900 0	0 0 0 0 0 0 0.0 0 0	0 0 0 0 0 0 0 0	0 0 0 0 0.0 0 0 0.0	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0.00	0 00 0.00 0 00 0 00 0 00
6,000 0 6,100.0 6,200 0 6,300.0 6,400.0	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0 00	6,000 0 6,100 0 6,200 0 6,300 0 6,400 0	0 0 0.0 0 0 0.0 0 0	0 0 0 0 0.0 0 0 0.0	0 0 0 0 0 0 0.0 0.0	0 00 0 00 0.00 0 00 0 00	0 00 0 00 0 00 0.00 0 00	0 00 0 00 0 00 0 00 0 00
6,500 0 6,600.0 6,700 0 6,800 0 6,900.0	0 00 0 00 0 00 0.00 0.00	0 00 0.00 0 00 0 00 0.00	6,500 0 6,600 0 6,700 0 6,800 0 6,900 0	0 0 0.0 0 0 0.0 0.0	0 0 0 0 0 0 0 0 0.0	0 0 0 0 0 0 0 0 0 0	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0 00
7,000.0 7,100 0 7,200.0 7,300 0 7,400 0	0.00 0 00 0.00 0 00 0 00	0 00 0.00 0 00 0 00 0 00	7,000 0 7,100 0 7,200 0 7,300 0 7,400 0	0 0 0 0 0 0 0.0 0.0	0 0 0 0 0 0 0 0 0.0	0 0 0 0 0 0 0 0	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0.00 0 00	0 00 0 00 0 00 0 00 0 00
7,500 0 7,600 0 7,700 0 7,800.0 7,900.0	0.00 0 00 0.00 0.00 0 00	0 00 0.00 0 00 0.00 0 00	7,500.0 7,600.0 7,700.0 7,800.0 7,900 0	0.0 0.0 0 0 0 0	0 0 0 0 0.0 0 0 0 0	0 0 0.0 0 0 0 0 0.0	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0.00 0.00	0 00 0 00 0.00 0 00 0 00
8,000.0 8,100.0 8,200 0 8,300.0 8,400 0	0.00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0 00	8,000 0 8,100.0 8,200 0 8,300.0 8,400 0	0.0 0.0 0 0 0.0 0.0	0 0 0 0 0 0 0 0 0 0	00 00 00 00	0 00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0 00 0.00	0 00 0 00 0 00 0 00 0 00
8,500 0 8,600.0 8,700.0 8,800.0 8,900 0	0.00 0 00 0 00 0 00 0 00	0 00 0 00 0 00 0.00 0.00	8,500.0 8,600 0 8,700.0 8,800.0 8,900 0	0 0 0.0 0 0 0 0 0 0	0 0 0.0 0 0 0 0 0 0	0 0 0 0 0 0 0.0 0.0	0 00 0 00 0.00 0.00 0 00	0 00 0 00 0 00 0 00 0 00	0.00 0.00 0 00 0 00 0 00
8,948 1 .9,000.0 9,100.0 9,200.0 9,300 0	0.00 6.23 18 23 30 23 42 23	0 00 179 76 179.76 179 76 179.76	8,948 1 8,999.9 9,097.5 9,188 5 9,269.0	0 0 -2 8 -24 0 -64 9 -123 9	0 0 0 0 0 1 0.3 0 5	0 0 2 8 24 0 64 9 123 9	0 00 12 00 12 00 12.00 12.00	0 00 12 00 12 00 12 00 12 00	0 00 0.00 0 00 0 00 0 00
9,400 0 9,500.0 9,600 0 9,700 0 9,700 6	54 23 66 23 78.23 90 23 90 30	179.76 179.76 179.76 179.76 179.76	9,335 5 9,385 1 9,415.5 9,425 6 9,425 6	-198 4 -285 0 -380 1 -479 4 -480 0	08 12 16 20 20	198 4 285 0 380 1 479 4 480 0	12 00 12 00 12 00 12 00 12 00	12 00 12 00 12 00 12 00 12 00	0 00 0 00 0 00 0 00 0 00
9,800 0 9,900.0 10,000.0 10,100.0 10,200 0	90 30 90 30 90 30 90 30 90.30	179 76 179.76 179 76 179 76 179 76	9,425.0 9,424 5 9,424 0 9,423.5 9,422 9	-579 4 -679.4 -779.4 -879 4 -979 4	2 4 2 8 3 3 3 7 4 1	579 4 679 4 779 4 879 4 979 4	0 00 0 00 0.00 0.00 0 00	0 00 0 00 0 00 0 00 0 00	0.00 0.00 0.00 0.00 0.00
10,300 0 10,400 0 10,500.0	90.30 90.30 <u>90.30</u>	179 76 179 76 179.76	9,422.4 9,421.9 9,421.4	-1,079 4 -1,179 4 -1,279 3	4 5 4 9 5,3	1,079 4 1,179.4 1,279 4	0.00 0 00 <u>0</u> 00	0 00 0 00 0 00	0.00 0 00 0 00

Planning Report

3 Drilling Database Database:

Company: Permian District Poker Lake Project:

Site: PLU Big Sinks 19-24-31 USA 1H Well: Well #1

Wellbore: Wellbore #1 Design: Plat

Local Co-ordinate Reference: Well Well #1.

TVD Reference: WELL @ 0 Ousft (Original Well Elev) MD Reference: WELL @ 0 Ousft (Original Well Elev)

North Reference: Grid

Survey Calculation Method Minimum Curvature

P	1	ann	ıed	S	ìui	rvėy.
٠,		2.	•	t.		. 54

Monayer		The state of the s	Vortical			Votical	Dogles Will	Dilla F	Turn
Measured . Depth	Inclination	Azimuth	Vertical Depth	+N/-S	+Ē/-W 👵	Vertical Section	Dogleg ** Rate	Build Rate	Rate
(usft)	(*)	To a series of the second	پ (usft): .	(usft)	(úsft)	(usft)	(°/100usft)	/100usft)	(°/100úsft)
10,600.0	90 30	179 76	9,420 8	-1,379 3	5.8	1,379 4	0 00	0 00	0 00
10,700.0	90 30	179.76	9,420 3	-1,479 3	6 2	1,479 4	0.00	0 00	0 00
10,800 0	90 30	179 76	9,419.8	-1,579 3	6.6	1,579 4	0 00	0 00	0 00
10,900 0	90 30	179 76	9,419 3	-1,679 3	7.0	1,679 4	0 00 0 00	0 00 0 00	0 00 0 00
11,000 0 11,100 0	90 30 90 30	179 76 179.76	9,418 7 9,418 2	-1,779 3 -1,879 3	74 79	1,779 4 1,879 4	0 00	0 00	0 00
11,200.0	90.30	179.76	9,417.7	-1,979 3	83	1,979 4	0 00	0 00	0 00
·			·	-2.079 3	87		0 00	0 00	0.00
11,300 0 11,400 0	90 30 90 30	179 76 179 76	9,417 2 9,416 7	-2,079 3 -2,179 3	91	2,079 3 2,179 3	0 00	0.00	0.00
11,500 0	90 30	179.76	9,416 1	-2,1793	95	2,1793	0.00	0.00	0 00
11,600 0	90 30	179.76	9,415 6	-2.379.3	99	2,379 3	0.00	0 00	0 00
11,700 0	90 30	179.76	9,415 1	-2,479 3	10 4	2,479.3	0 00	0 00	0 00
11,800.0	90.30	179 76	9,414.6	-2,579 3	10 8	2,579 3	0 00	0 00	0 00
11,900.0	90 30	179 76	9,414.0	-2,679.3	11 2	2,679,3	0 00	0 00	0 00
12,000 0	90 30	179 76	9,413 5	-2,779 3	11 6	2,779.3	0.00	0 00	0 00
12,100 0	90 30	179 76	9,413 0	-2,879 3	12.0	2,879.3	0 00	0.00	0 00
12,200 0	90.30	179 76	9,412 5	-2,979 3	12 4	2,979 3	0 00	0 00	0 00
12,300 0	90 30	179 76	9,411 9	-3,079 3	12 9	3,079.3	0.00	0.00	0 00
12,400 0	90 30	179.76	9,411 4	-3,179 3	13,3	3,179 3	0 00	0 00	0 00
12,500 0	90 30	179 76	9,410 9	-3,279 3	13 7	3,279 3	0 00	0 00	0 00
12,600 0	90 30	179 76	9,410 4	-3,379 3	14.1	3,379 3	0 00	0 00	0 00
12,700 0	90 30	179 76	9,409 8	-3,479 3	14.5	3,479 3	0.00	0 00	0 00
12,800 0	90 30	179 76	9,409 3	-3,579 3	150	3,579 3	0 00	0 00	0 00
12,900.0	90 30	179 76	9,408.8	-3,679 3	15 4	3,679 3	0 00	0 00	0.00
13,000 0 13,100 0	90 30	179 76	9,408.3	-3,779 3	15 8	3,779 3	0 00	0 00	0 00
13,100 0	90.30 90.30	179 76 179 76	9,407 8 9,407 2	-3,879 3 -3,979 <i>.</i> 3	16.2 16 6	3,879 3 3,979 3	0 00 0 00	0 00 0.00	0.00 0.00
			•	•					
13,300.0	90 30	179 76	9,406 7	-4,079.3	17.0	4.079 3	0 00	0.00	0.00
13,400.0	90.30	179.76	9,406 2	-4,179 3	17.5	4,179 3	0 00	0 00	0 00
13,500 0 13,600 0	90 30 90 30	179 76 179 76	9,405.7 9.405.1	-4,279.3 -4.379 3	17.9 18 3	4,279.3 4,379.3	0 00 0 00	0 00 0 00	0 00 0.00
13,700 0	90 30	179.76	9,405.1	-4,3793 -4,4793	18 7	4,379 3	0 00	0 00	0.00
13,800 0	90 30	179 76	9,404.1	-4,579 3	19 1	4.579 3	0 00	0 00	0.00
13,900.0	90.30	179 76	9,403.6	-4,679 3	19 5	4,679 3	0 00	0 00	0.00
14,000 0	90 30	179 76	9,403.0	-4,779.3	20 0	4,779 3	0 00	0 00	0.00
14,017 7	90 30	179 76	9,403 0		20.0			0.00	
									i t

Design	Tare	jetš

Target Name							1.15
- hit/miss target	Dip Angle Dip Dir				Easting	and the state of the	
- Shape	(°)	(usft) (usft)	(usft)	(usft) 🐇 🚎	(usft)	Latitude	Longitude

200

435,600 00

700,345 00

BS 19-24-31 USA 1H-- plan hits target center - Point 0.00

0 00 9,403 0

-4,797 0

32 196497

-103 819290

Project: Poker Lake

Site: PLU Big Sinks 19-24-31 USA 1H

Well: Well #1

Wellbore: Wellbore #1

Design: Plat


PROJECT DETAILS: POKER Lake

Geodetic System: US State Plane 1983

Datum: North American Datum 1983

Ellipsoid: GRS 1980

Zone: New Mexico Eastern Zone





Drilling Engineer: Chns Gray

Superintendent

Daniel Gipson

Geologist^e

Chris Persellin

Well Name: PLU Big Sinks 19-24-31 USA 1H

First Bone Spring Shale Target.

Eddy, NM County, State

Surface Location 140' FNL 1980' FWL, Section 19, Township 24S, Range 31

E 350' FSL 1980' FWL, Section 19, Township 24S, Range 31 **BH Location**

SHL Latitude: SHL Longitude. BHL Latitude: BHL Longitude.

32 209682 -103 819282 32 19649743 -103 8192913

SHL North 440397 SHL East. 700325 BHL North 435600 BHL East. 700345 Coordinates NMSPCE Drilling Rig: Directional-Surface

Ryan Directional-Curve. Ryan Directional-Lateral Ryan **Drilling Mud:** Nova

Patterson 62

Cement Schlumberger

Wellhead: Sunbelt

Property Number 643075

AFE Number 161571

			,,,g,,,aac,	
		Coord	nates:	NAD 83
	KB	Elevation:	3,520'	KB: 25'
i	Ground	Elevation.	3,495	
	AT .			
Conductor	60'			
OD, 20	Hole Size 17 1/2"			
Wt	1 B			
	¥ 88		544'	Rustler
Surface Casing	650'			
WBS- 13 3/8"	Hole Size. 11"	11		-
Wt. 48.#	<u> </u>		818'	Top of Salt
Grd; H-40	•	1.7		
Con STC				i i
		.,I I		,
		<u> </u>		
		<u> </u>		
			3,997'	Base of Salt
				, L
Shallow Int Casing	4,100		i	
OD 8 5/8"	Hole Size: 7 7/8"	- T	i	1,
Wt, 32.#		1 "1	4,220'	'. Lamar
Grd; J-55		▼ 1	4,240	Bell Canyon
Con LTC				4,
		1	1	<u>L</u> .
Ĭ		4		
				188

DV tool Depth

5,050 5,156

6,422'

8,100

Cherry Canyon

Brushy Canyon

- Bone Spring

¥	Wellhead Eq	uipment		
A Section	13-3/8" x 13-5/8"	5K SOW (Mu	Itibowl)	
B Section	N/A (Multibowl)			
C Section	11" 5K X 7-1/16"	10K w/10k ga	te valve	
D Section	N/A			
Required BOP Stack	13-5/8" 5K- Doul	ole, Annular, R	ot Head w/	orbit valve
	Mud			
Depth	Туро	Weight	F Vis	FL
0' - 650'	Spud Mud	84-87	32 - 34	NC - NC
650/ 4/400	Name of the last	05 404	20 20	NO NO

	Dept	h	Туро	Weight	F Vis	FL
0,	-	650'	Spud Mud	84-87	32 - 34	NC - NC
650′	_	4;100'	Brine	95-101	28 - 29	NC - NC
4,100'	Ξ	8,948'	Cut Brine	83-88	28 - 29	NC - NC
8,948'	Ξ	9,700'	Cut Brine	83-88	28 - 29	NC - NC
8,948'	-	9,701'	Cut Brine	83-88	28 - 29	NC - NC
9,701	•	14,018'	Cut Brine	83-88	28 - 29	NC - NC
				<u> </u>	L	
			Cemer	nt		

		Cemen	t				
Slurry	Тор	Btm	Wt	Yld	%Exc	Bbl	Sx
Surface							
Single Slurry	0,	650'	13 5	173	200	234	758
Shallow Int							
Lead	0'	3,600'	120	1 99	200	454	1280
Tail	3,600'	4,100'	14 2	1 37	200	71	290
Production							
1st Lead	5,050'	8,950	124	211	75	211	560
1st Tail	8,950'	14,018'	14'5	1 27	75	275	1218
2nd Lead	3,600'	4,800'	124	2 19	200	81	207
2nd Tail	4,800'	5,050'	148	1 33	200	23	98

Hole Size 7 7/8" 7 7/8 Hole Size

Hole Size 7 7/8"

14,018 Production Casing

OD; 5 1/2" Wt 20.# Grd: L-80 Con: LTC

1. 1	Type	Logs	interval	Vendor
L	Mud Log	2 man Mudlog	Int Cas to TD	Suttles
0	ОН	Triple Combo	Curve to Int Csq	TBD
G	ОН	GR/Neutron	Int Cas to Surf	`TBD
S	LWD	MWD Gamma	Curve and Lateral	9
	LAVID	IMAND Gamma	Curve and Lateral	Ryan

Pilot TD: 9,700

		Direc	tional Plan	1				
Target Line:		9243' @ 0' VS w/89 5 deg inclination						
Target Window:		20' above, 20' below, 50' left, 50' right						
	MD	INC	AZM	TVD	VS	DLS		
KOP	8,94	8' 0 00	0 00	8,948'	0'	0 00		
EOB	9,70	1' 90 30	179 76	9,426	480'	12 00		
TD	14,01	8' 90 30	179 76	9,403'	4,797	0 00		
Hardlines:	Lateral- 330' from parallel lease lines Vertical- Actual Lease Lines							
Notes: Please note SHL and BHL distance from lease lines								

Chesapeake Operating, Inc.


Legals: PLU Big Sinks 19 24 31 USA 1H

Jal, NM

UL C Section 19 Township 24 South

Lat: N 32.20965491 Long: W 103.81928184 Lat: N 32.19649743 Long: W 103.81929126

H₂S "Contingency Plan"





Safety Solutions, LLC 7907 Industrial

(432) 563-0400 Midland, TX 79706

Emergency Assistance Telephone List

Emergency Assistance relephone	LIST	
PUBLIC SAFETY:		911
Lea County Sheriff's Department		(575) 396-3611
Jal City Police Dept		(575)395-2121
Fire Department:		
Jal		(575) 395-2221
Eunice		(575) 394-2111
Ambulance: Jal		(575) 657-4355
Hobbs		
Hospitals:		
Lea Regional Medical Center (Hobbs)		(575) 492-5000
Permian Regional Medical Center (Andrews, TX)		(432) 523-2200
Dept. of Public Safety/Roswell		(575) 622-7200
Texas Dept. of Transportation		(432) 694-7951
U.S. Dept. of Labor		(505) 841-8405
AirMed/ Care Star		(877) 730-0009
Chesapeake Operating, Inc.	0.00	(422) 607 2002
Chesapeake / Midland	Om	ice (432) 687-2992
Company Drilling Consultants:	C - II	(405) 640 0767
Nathan Berg	Cell	(405) 618-0767
Marcus Garcia		(000) 200 (700
Trailer		(832) 380-6700
Drilling Engineer		
Chris Gary	Cell	(405) 935-4346
Drilling Superintendent	······	
Tim Hartsfield	Ce	·II (432) 940-9978
Latshaw	_	/040\ 255 4220
Office	c "	(918) 355-4380
Safety- Cody Ashley	Cell	(940) 867-4102
<u>Latshaw</u>	C "	(832) 380-6700
Ray Ash Superintendent	Cell	(432) 638-2008
Trailer Table 1 Problem		(832) 213-5247
Tool Pusher:		(422) 755 4442
Lupe Rodrigues	Cell	(432) 755-4418
Jason	Cell	(432) 556-0675
Safety Consultants		
Safety Solutions, LLC		(432) 563-0400
Cliff Strasner	Cell	(432) 894-9789
Craig Strasner	Cell	(432) 894-0341

Table of Contents

I. H₂S Contingency Plan

- a. Scope
- b. Objective
- c. Discussion of Plan

II. Emergency Procedures

- a. Emergency Procedures
- b. Emergency Reaction Steps
- c. Simulated Blowout Control Drills

III. Ignition Procedures

- a. Responsibility
- b. Instructions

IV. Training Requirements

V. Emergency Equipment

VI. Check Lists

- a. Status Check List
- b Procedural Check List

VII. Briefing Procedures

VIII. Evacuation Plan

- a. General Plan
- b. Emergency Phone Lists

IX. Maps and Plats

- a. Location Plat
- b. Map to Location
- c. Radius of Exposure

X. General Information

- a. Drilling/Re-entry Permits
- b. H-9 Permit
- c. H₂S Permissible Limits
- d. Toxicity Table
- e. Physical Properties
- f. Respirator Use
- g. Emergency Rescue

H₂S CONTINGENCY PLAN SECTION

Scope:

This contingency plan provides an organized plan of action for alerting and protecting the public within an area of exposure prior to an intentional release, or following the accidental release of a potentially hazardous volume of hydrogen sulfide. The plan establishes guidelines for all personnel whose work activity may involve exposure to Hydrogen Sulfide Gas (H₂S).

Objective:

Prevent any and all accidents, and prevent the uncontrolled release of H₂S into the atmosphere.

Provide proper evacuation procedures to cope with emergencies.

Provide immediate and adequate medical attention should an injury occur.

Discussion of Plan:

Suspected Problem Zones:

Implementation: This plan, with all details, is to be fully implemented 1000' before drilling into the first sour zone.

Emergency Response Procedure: This section outlines the conditions and denotes steps to be taken in the event of an emergency.

Emergency Equipment and Procedure: This section outlines the safety and emergency equipment that will be required for the drilling of this well.

Training Provisions: This section outlines the training provisions that must be adhered to 1000' before drilling into the first sour zone.

Emergency call list: Included are the telephone numbers of all persons that would need to be contacted, should an H₂S emergency occur.

Briefing: This section deals with the briefing of all persons involved with the drilling of this well.

Public Safety: Public Safety Personnel will be made aware of the drilling of this well.

Check Lists: Status check lists and procedural check lists have been included to ensure adherence to the plan.

General Information: A general information section has been included to supply support information.

EMERGENCY PROCEDURES SECTION

- I. In the event of any evidence of H₂S level above 10ppm, take the following steps immediately:
 - a. Secure breathing apparatus.
 - b. Order non-essential personnel out of the danger zone.
 - c Take steps to determine if the H₂S level can be corrected or suppressed, and if so, proceed with normal operations.
- II. If uncontrollable conditions occur, proceed with the following:
 - a. Take steps to protect and/or remove any public downwind of the rig, including partial evacuation or isolation. Notify necessary public safety personnel and the New Mexico Oil Conservation Division of the situation.
 - b. Remove all personnel to the Safe Briefing Area.
 - Notify public safety personnel for help with maintaining roadblocks and implementing evacuation.
 - d. Determine and proceed with the best possible plan to regain control of the well. Maintain tight security and safety measures.

III. Responsibility:

- a. The Company Approved Supervisor shall be responsible for the total implementation of the plan.
- b. The Company Approved Supervisor shall be in complete command during any emergency.
- c. The Company Approved Supervisor shall designate a back up Supervisor in the event that he/she is not available

EMERGENCY PROCEDURE IMPLEMENTATION

I. Drilling or Tripping

a. All Personnel

- i. When alarm sounds, don escape unit and report to upwind Safe Briefing Area.
- ii. Check status of other personnel (buddy system).
- iii. Secure breathing apparatus.
- iv. Wait for orders from supervisor.

b. Drilling Foreman

- i. Report to the upwind Safe Briefing Area.
- ii. Don Breathing Apparatus and return to the point of release with the Tool Pusher or Driller (buddy system).
- iii. Determine the concentration of H₂S.
- iv. Assess the situation and take appropriate control measures.

c. Tool Pusher

- i. Report to the upwind Safe Briefing Area.
- ii. Don Breathing Apparatus and return to the point of release with the Drilling Foreman or the Driller (buddy system).
- iii. Determine the concentration of H₂S.
- iv. Assess the situation and take appropriate control measures.

d. Driller

- i. Check the status of other personnel (in a rescue attempt, always use the buddy system).
- **ii.** Assign the least essential person to notify the Drilling Foreman and Tool Pusher, in the event of their absence.
- iii. Assume the responsibility of the Drilling Foreman and the Tool Pusher until they arrive, in the event of their absence.

e. Derrick Man and Floor Hands

i. Remain in the upwind Safe Briefing Area until otherwise instructed by a supervisor.

f. Mud Engineer

- i. Report to the upwind Safe Briefing Area.
- ii. When instructed, begin check of mud for pH level and H₂S level.

g. Safety Personnel

- i. Don Breathing Apparatus
- ii. Check status of personnel.
- iii. Wait for instructions from Drilling Foreman or Tool Pusher.

II. Taking a Kick

- a. All Personnel report to the upwind Safe Briefing Area.
- b. Follow standard BOP procedures.

III. Open Hole Logging

- a. All unnecessary personnel should leave the rig floor.
- **b.** Drilling Foreman and Safety Personnel should monitor the conditions and make necessary safety equipment recommendations.

IV. Running Casing or Plugging

- a. Follow "Drilling or Tripping" procedures.
- **b.** Assure that all personnel have access to protective equipment.

SIMULATED BLOWOUT CONTROL DRILLS

All drills will be initiated by activating alarm devices (air horn) One long blast, on the air horn, for ACTUAL and SIMULATED Blowout Control Drills This operation will be performed by the Drilling Foreman or Tool Pusher at least one time per week for each of the following conditions, with each crew:

Drill #1 Bottom Drilling

Drill #2 Tripping Drill Pipe

In each of these drills, the initial reaction time to shutting in the well shall be timed as well as the total time for the crew to complete its entire pit drill assignment. The times must be recorded on the IADC Driller's Log as "Blowout Control Drill".

Drill No .:

Reaction Time to Shut-In: minutes, seconds.

Total Time to Complete Assignment: minutes, seconds.

I. Drill Overviews

- a. Drill No. 1 Bottom Drilling
 - i Sound the alarm immediately.
 - ii. Stop the rotary and hoist Kelly joint above the rotary table.
 - iii. Stop the circulatory pump.
 - iv. Close the drill pipe rams.
 - v. Record casing and drill pipe shut-in pressures and pit volume increases.
- b. Drill No. 2 Tripping Drill Pipe
 - i. Sound the alarm immediately.
 - ii Position the upper tool joint just above the rotary table and set the slips
 - iii. Install a full opening valve or inside blowout preventer tool in order to close the drill pipe.
 - iv. Close the drill pipe rams.
 - v. Record the shut-in annular pressure.

vi.

II. Crew Assignments

a. <u>Drill No. 1 – Bottom Drilling</u>

i. Driller

- 1. Stop the rotary and hoist Kelly joint above the rotary table.
- 2. Stop the circulatory pump.
- 3. Check Flow.
- 4. If flowing, sound the alarm immediately
- 5. Record the shit-in drill pipe pressure
- 6. Determine the mud weight increase needed or other courses of action.

ii. Derrickman

- 1. Open choke line valve at BOP.
- 2. Signal Floor Man #1 at accumulator that choke line is open.
- 3. Close choke and upstream valve after pipe tam have been closed.
- 4. Read the shut-in annular pressure and report readings to Driller.

iii. Floor Man #1

- 1. Close the pipe rams after receiving the signal from the Derrickman.
- 2. Report to Driller for further instructions.

iv. Floor Man #2

- 1. Notify the Tool Pusher and Operator representative of the H₂S alarms.
- 2. Check for open fires and, if safe to do so, extinguish them.
- 3. Stop all welding operations.
- 4. Turn-off all non-explosions proof lights and instruments.
- 5. Report to Driller for further instructions.

v. Tool Pusher

1. Report to the rig floor.

- 2. Have a meeting with all crews.
- 3. Compile and summarize all information.
- 4. Calculate the proper kill weight.
- 5. Ensure that proper well procedures are put into action.

vi. Operator Representative

- 1. Notify the Drilling Superintendent.
- 2. Determine if an emergency exists and if so, activate the contingency plan.

b. Drill No. 2 - Tripping Pipe

i. Driller

- 1. Sound the alarm immediately when mud volume increase has been detected.
- 2. Position the upper tool joint just above the rotary table and set slips.
- 3. Install a full opening valve or inside blowout preventer tool to close the drill pipe.
- 4. Check flow.
- 5. Record all data reported by the crew.
- 6. Determine the course of action.

ii. Derrickman

- 1. Come down out of derrick.
- 2. Notify Tool Pusher and Operator Representative.
- 3. Check for open fires and, if safe to do so, extinguish them.
- 4. Stop all welding operations.
- 5. Report to Driller for further instructions.

iii. Floor Man #1

- 1. Pick up full opening valve or inside blowout preventer tool and stab into tool joint above rotary table (with Floor Man #2).
- 2. Tighten valve with back-up tongs.
- 3. Close pipe rams after signal from Floor Man #2.
- 4. Read accumulator pressure and check for possible high pressure fluid leaks in valves or piping.
- 5. Report to Driller for further instructions.

iv. Floor Man #2

- 1. Pick-up full opening valve or inside blowout preventer tool and stab into tool joint above rotary table (with Floor Man #1).
- 2. Position back-up tongs on drill pipe.
- 3. Open choke line valve at BOP.
- 4. Signal Floor Man #1 at accumulator that choke line is open.
- 5. Close choke and upstream valve after pipe rams have been closed.
- 6. Check for leaks on BOP stack and choke manifold.
- 7. Read annular pressure.
- 8. Report readings to the Driller.

v. Tool Pusher

- 1. Report to the rig floor.
- 2. Have a meeting with all of the crews
- 3. Compile and summarize all information.
- 4. See that proper well kill procedures are put into action.

vi. Operator Representative

- 1. Notify Drilling Superintendent
- 2. Determine if an emergency exists, and if so, activate the contingency plan.

TRAINING PROGRAM

When working in an area where Hydrogen Sulfide (H_2S) might be encountered, definite training requirements must be carried out. The Company Supervisor will ensure that all personnel, at the well site, have had adequate training in the following:

- 1. Hazards and characteristics of Hydrogen Sulfide.
- 2. Physicals effects of Hydrogen Sulfide on the human body.
- 3. Toxicity of Hydrogen Sulfide and Sulfur Dioxide.
- 4. H₂S detection, Emergency alarm and sensor location.
- 5. Emergency rescue.
- 6. Resuscitators.
- 7. First aid and artificial resuscitation.
- 8. The effects of Hydrogen Sulfide on metals
- 9. Location safety.

Service company personnel and visiting personnel must be notified if the zone contains H_2S , and each service company must provide adequate training and equipment for their employees before they arrive at the well site.

EMERGENCY EQUIPMENT REQUIREMENTS

Lease Entrance Sign:

Should be located at the lease entrance with the following information:

CAUTION – POTENTIAL POISON GAS HYDROGEN SULFIDE NO ADMITTANCE WITHOUT AUTHORIZATION

Respiratory Equipment:

- Fresh air breathing equipment should be placed at the safe briefing areas and should include the following:
- Two SCBA's at each briefing area.
- Enough air line units to operate safely, anytime the H₂S concentration reaches the IDLH level (100 ppm).
- Cascade system with enough breathing air hose and manifolds to reach the rig floor, the derrickman and the other operation areas.

Windsocks or Wind Streamers:

- A minimum of two 10" windsocks located at strategic locations so that they may be seen from any point on location.
- Wind streamers (if preferred) should be placed at various locations on the well site to ensure wind consciousness at all times. (Corners of location).

Hydrogen Sulfide Detector and Alarms:

- 1 Four channel H₂S monitor with alarms.
- Four (4) sensors located as follows: #1 Rig Floor, #2 Bell Nipple, #3 Shale Shaker, #4 Mud Pits.
- Gastec or Draeger pump with tubes.
- Sensor test gas.

Well Condition Sign and Flags:

The Well Condition Sign w/flags should be placed a minimum of 150' before you enter the location. It should have three (3) color coded flags (green, yellow and red) that will be used to denote the following location conditions:

GREEN – Normal Operating Conditions YELLOW – Potential Danger RED – Danger, H₂S Gas Present

Auxiliary Rescue Equipment:

- Stretcher
- 2 100' Rescue lines.
- First Aid Kit properly stocked.

Mud Inspection Equipment:

Garret Gas Train or Hach Tester for inspection of Hydrogen Sulfide in the drilling mud system.

Fire Extinguishers:

Adequate fire extinguishers shall be located at strategic locations.

Blowout Preventer:

- The well shall have hydraulic BOP equipment for the anticipated BHP.
- The BOP should be tested upon installation.
- BOP, Choke Line and Kill Line will be tested as specified by Operator.

Confined Space Monitor:

There should be a portable multi-gas monitor with at least 3 sensors (O₂, LEL H₂S). This instrument should be used to test the atmosphere of any confined space before entering. It should also be used for atmospheric testing for LEL gas before beginning any type of Hot Work. Proper calibration documentation will need to be provided.

Communication Equipment:

- Proper communication equipment such as cell phones or 2-way radios should be available at the rig.
- Radio communication shall be available for communication between the company man's trailer,
 rig floor and the tool pusher's trailer.

Communication equipment shall be available on the vehicles.

Special Control Equipment:

- Hydraulic BOP equipment with remote control on the ground.
- · Rotating head at the surface casing point.

Evacuation Plan:

- Evacuation routes should be established prior to spudding the well.
- Should be discussed with all rig personnel.

Designated Areas:

Parking and Visitor area:

- All vehicles are to be parked at a pre-determined safe distance from the wellhead.
- Designated smoking area.

Safe Briefing Areas:

- Two Safe Briefing Areas shall be designated on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds or they are at a 180 degree angle if wind directions tend to shift in the area.
- Personal protective equipment should be stored at both briefing areas or if a moveable cascade trailer is used, it should be kept upwind of existing winds. When wind is from the prevailing direction, both briefing areas should be accessible.

Note:

- Additional equipment will be available at the Safety Solutions, LLC office.
- Additional personal H₂S monitors are available for all employees on location.
- Automatic Flare Igniters are recommended for installation on the rig

Procedural Check List

Perform the following on each tour:

- 1. Check fire extinguishers to see that they have the proper charge.
- 2. Check breathing equipment to insure that they have not been tampered with.
- 3. Check pressure on the supply air bottles to make sure they are capable of recharging.
- 4. Make sure all of the Hydrogen Sulfide detection systems are operative.

Perform the following each week:

- 1. Check each piece of breathing equipment to make sure that they are fully charged and operational. This requires that the air cylinder be opened and the mask assembly be put on and tested to make sure that the regulators and masks are properly working. Negative and Positive pressure should be conducted on all masks.
- 2. BOP skills.
- 3. Check supply pressure on BOP accumulator stand-by source.
- 4. Check all breathing air mask assemblies to see that straps are loosened and turned back, ready for use.
- 5. Check pressure on cascade air cylinders to make sure they are fully charged and ready to use for refill purposes if necessary.
- 6. Check all cascade system regulators to make sure they work properly.
- 7. Perform breathing drills with on-site personnel.
- 8. Check the following supplies for availability:
 - Stretcher
 - Safety Belts and Ropes
 - Spare air Bottles
 - Spare Oxygen Bottles (if resuscitator required)
 - Gas Detector Pump and Tubes
 - Emergency telephone lists
- 9. Test the Confined Space Monitor to verify the batteries are good

BRIEFING PROCEDURES

The following scheduled briefings will be held to ensure the effective drilling and operation of this project:

Pre-Spud Meeting

Date: Prior to spudding the well.

Attendance: Drilling Supervisor

Drilling Engineer Drilling Foreman Rig Tool Pushers Rig Drillers Mud Engineer All Safety Personnel

Key Service Company Personnel

Purpose: Review and discuss the well program, step-by-step, to insure complete understanding of

assignments and responsibilities.

EVACUATION PLAN

General Plan

The direct lines of action prepared by SAFETY SOLUTIONS, LLC to protect the public from hazardous gas situations are as follows.

- 1. When the company approved supervisor (Drilling Foreman, Tool Pusher or Driller) determine that Hydrogen Sulfide gas cannot be limited to the well location, and the public will be involved, he will activate the evacuation plan. Escape routes are noted on the area map.
- 2. Company safety personnel or designee will notify the appropriate local government agency that a hazardous condition exists and evacuation needs to be implemented.
- 3. Company approved safety personnel that have been trained in the use of the proper emergency equipment will be utilized.
- 4. Law enforcement personnel (State Police, Local Police Department, Fire Department, and the Sheriff's Department) will be called to aid in setting up and maintaining road blocks. Also, they will aid in evacuation of the public if necessary.
- NOTE: Law enforcement personnel will not be asked to come into a contaminated area. Their assistance will be limited to uncontaminated areas. Constant radio contact will be maintained with them.
 - 5. After the discharge of gas has been controlled, "Company" safety personnel will determine when the area is safe for re-entry.

See Emergency Action Plan

MAPS AND PLATS (Maps & Plats Attached)

Affected Notification List

The geologic zones that will be encountered during drilling are known to contain hazardous quantities of H₂S. The accompanying map illustrates the affected areas of the community. The residents within this radius will be notified via a hand delivered written notice describing the activities, potential hazards, conditions of evacuation, evacuation drill siren alarms and other precautionary measures.

Evacuee Description:

Residents: THERE ARE NO RESIDENTS WITHIN 3000' ROE.

Notification Process:

A continuous siren audible to all residence will be activated, signaling evacuation of previously notified and informed residents.

Evacuation Plan:

All evacuees will migrate lateral to the wind direction.

The Oil Company will identify all home bound or highly susceptible individuals and make special evacuation preparations, interfacing with the local and emergency medical service as necessary.

***Given no offset well info about H2S Production, Chesapeake is assuming a ROE of 3000' for 100 ppm, as per Onshore Order 6. 'A search of the area-surrounding the drilling location found no public buildings, roadways, or residences within 1 mile

GENERAL INFORMATION

Toxic Effects of H₂S Poisoning

Hydrogen Sulfide is extremely toxic. The acceptable ceiling concentration for eight-hour exposure is 10 PPM, which is .001% by volume. Hydrogen Sulfide is heavier than air (specific gravity - 1.192) and is colorless and transparent. Hydrogen Sulfide is almost as toxic as Hydrogen Cyanide and is 5-6 times more toxic than Carbon Monoxide. Occupational exposure limits for Hydrogen Sulfide and other gases are compared below in Table 1. Toxicity table for H_2S and physical effects are shown in Table 2.

Table 1
Permissible Exposure Limits of Various Gases

Common Name	Symbol	Sp. Gravity	TLV	STEL	IDLH
Hydrogen Cyanide	HCN	.94	4.7 ppm	С	
Hydrogen Sulfide	H ₂ S	1.192	10 ppm	15 ppm	100 ppm
Sulfide Dioxide	SO ₂	2.21	2 ppm	5 ppm	
Chlorine	CL	2.45	.5 ppm	1 ppm	
Carbon Monoxide	СО	.97	25 ppm	200 ppm	
Carbon Dioxide	CO ₂	1.52	5000 ppm	30,000 ppm	
Methane	CH ₄	.55	4.7% LEL	14% UEL	

Definitions

- A. TLV Threshold Limit Value is the concentration employees may be exposed based on a TWA (time weighted average) for eight (8) hours in one day for 40 hours in one (1) week. This is set by ACGIH (American Conference of Governmental Hygienists) and regulated by OSHA.
- B. STEL Short Term Exposure Limit is the 15 minute average concentration an employee may be exposed to providing that the highest exposure never exceeds the OEL (Occupational Exposure Limit). The OEL for H₂S is 19 PPM.
- C. IDLH Immediately Dangerous to Life and Health is the concentration that has been determined by the ACGIH to cause serious health problems or death if exposed to this level. The IDLH for H₂S is 100 PPM.
- D. TWA Time Weighted Average is the average concentration of any chemical or gas for an eight (8) hour period. This is the concentration that any employee may be exposed based on an TWA.

TABLE 2

		Toxicity Table of H₂S
Percent %	PPM	Physical Effects
.0001	1	Can smell less than 1 ppm.
001	10	TIVE COLOURS OF THE STATE OF TH
.001	10	TLV for 8 hours of exposure.
.0015	15	STEL for 15 minutes of exposure.
	100	
01	100	Immediately Dangerous to Life & Health.
		Kills sense of smell in 3 to 5 minutes.
00	200	
.02	200	Kills sense of smell quickly, may burn eyes and throat.
.05	500	Disginass sociation of breathing begins in a few minutes
.03	500	Dizziness, cessation of breathing begins in a few minutes.
.07	700	Unconscious quickly, death will result if not rescued promptly.
.07	700	onconscious quickly, death will result it not rescued promptry.
.10	1000	Death will result unless rescued promptly. Artificial resuscitation
.25		may be necessary.

PHYSICAL PROPERTIES OF H2S

The properties of all gases are usually described in the context of seven major categories:

COLOR

VAPOR DENSITY

EXPLOSIVE LIMITS

FLAMMABILITY

SOLUBILITY (IN WATER)

BOILING POINT

Hydrogen Sulfide is no exception. Information from these categories should be considered in order to provide a fairly complete picture of the properties of the gas.

COLOR - TRANSPARENT

Hydrogen Sulfide is colorless so it is invisible. This fact simply means that you can't rely on your eyes to detect its presence. In fact that makes this gas extremely dangerous to be around.

ODOR - ROTTEN EGGS

Hydrogen Sulfide has a distinctive offensive smell, similar to "rotten eggs". For this reason it earned its common name "sour gas". However, H₂S, even in low concentrations, is so toxic that it attacks and quickly impairs a victim's sense of smell, so it could be fatal to rely on your nose as a detection device.

VAPOR DENSITY - SPECIFIC GRAVITY OF 1.192

Hydrogen Sulfide is heavier than air so it tends to settle in low-lying areas like pits, cellars or tanks. If you find yourself in a location where H_2S is known to exist, protect yourself. Whenever possible, work in an area upwind and keep to higher ground.

EXPLOSIVE LIMITS - 4.3% TO 46%

Mixed with the right proportion of air or oxygen, H₂S will ignite and burn or explode, producing another alarming element of danger besides poisoning.

FLAMMABILITY

Hydrogen Sulfide will burn readily with a distinctive clear blue flame, producing Sulfur Dioxide (SO₂), another hazardous gas that irritates the eyes and lungs.

SOLUBILITY - 4 TO 1 RATIO WITH WATER

Hydrogen Sulfide can be dissolved in liquids, which means that it can be present in any container or vessel used to carry or hold well fluids including oil, water, emulsion and sludge. The solubility of H_2S is dependent on temperature and pressure, but if conditions are right, simply agitating a fluid containing H_2S may release the gas into the air.

BOILING POINT – (-76 degrees Fahrenheit)

Liquefied Hydrogen Sulfide boils at a very low temperature, so it is usually found as a gas.

RESPIRATOR USE

The Occupational Safety and Health Administration (OSHA) regulate the use of respiratory protection to protect the health of employees. OSHA's requirements are written in the Code of Federal Regulations, Title 29, Part 1910, Section 134, Respiratory Protection. This regulation requires that all employees who might be required to wear respirators, shall complete a OSHA mandated medical evaluation questionnaire. The employee then should be fit tested prior to wearing any respirator while being exposed to hazardous gases.

Written procedures shall be prepared covering safe use of respirators in dangerous atmospheric situations, which might be encountered in normal operations or in emergencies Personnel shall be familiar with these procedures and the available respirators.

Respirators shall be inspected prior to and after each use to make sure that the respirator has been properly cleaned, disinfected and that the respirator works properly. The unit should be fully charged prior to being used.

Anyone who may use respirators shall be properly trained in how to properly seal the face piece. They shall wear respirators in normal air and then in a test atmosphere. (Note: Such items as facial hair (beard or sideburns) and eyeglass temple pieces will not allow a proper seal.) Anyone that may be expected to wear respirators should have these items removed before entering a toxic atmosphere. A special mask must be obtained for anyone who must wear eyeglasses. Contact lenses should not be allowed.

Respirators shall be worn during the following conditions:


- A. Any employee who works near the top or on the top of any tank unless tests reveal less than 20 ppm of H_2S .
- B. When breaking out any line where H₂S can reasonably be expected.
- C. When sampling air in areas where H₂S may be present.
- D. When working in areas where the concentration of H₂S exceeds the Threshold Limit Value for H₂S (10 ppm).
- E. At any time where there is a doubt as to the H₂S level in the area to be entered.

EMERGENCY RESCUE PROCEDURES

DO NOT PANIC!!!

Remain Calm - Think

- 1. Before attempting any rescue you must first get out of the hazardous area yourself. Go to a safe briefing area.
- 2. Sound alarm and activate the 911 system.
- 3. Put on breathing apparatus. At least two persons should do this, when available use the buddy system.
- 4. Rescue the victim and return them to a safe briefing area.
- 5. Perform an initial assessment and begin proper First Aid/CPR procedures.
- 6. Keep victim lying down with a blanket or coat, etc.., under the shoulders to keep airway open. Conserve body heat and do not leave unattended.
- 7. If the eyes are affected by H₂S, wash them thoroughly with potable water. For slight irritation, cold compresses are helpful.
- 8. In case a person has only minor exposure and does not lose consciousness totally, it's best if he doesn't return to work until the following day.
- 9. Any personnel overcome by H₂S should always be examined by medical personnel. They should always be transported to a hospital or doctor.



I. GENERAL PROVISIONS

The approval of the Application For Permit To Drill (APD) is in compliance with all applicable laws and regulations: 43 Code of Federal Regulations 3160, the lease terms, Onshore Oil and Gas Orders, Notices To Lessees, New Mexico Oil Conservation Division (NMOCD) Rules, National Historical Preservation Act As Amended, and instructions and orders of the Authorized Officer. Any request for a variance shall be submitted to the Authorized Officer on Form 3160-5, Sundry Notices and Report on Wells.

II. PERMIT EXPIRATION

If the permit terminates prior to drilling and drilling cannot be commenced within 60 days after expiration, an operator is required to submit Form 3160-5, Sundry Notices and Reports on Wells, requesting surface reclamation requirements for any surface disturbance. However, if the operator will be able to initiate drilling within 60 days after the expiration of the permit, the operator must have set the conductor pipe in order to allow for an extension of 60 days beyond the expiration date of the APD. (Filing of a Sundry Notice is required for this 60 day extension.)

III. ARCHAEOLOGICAL, PALEONTOLOGY & HISTORICAL SITES

Any cultural and/or paleontological resource discovered by the operator or by any person working on the operator's behalf shall immediately report such findings to the Authorized Officer. The operator is fully accountable for the actions of their contractors and subcontractors. The operator shall suspend all operations in the immediate area of such discovery until written authorization to proceed is issued by the Authorized Officer. An evaluation of the discovery shall be made by the Authorized Officer to determine the appropriate actions that shall be required to prevent the loss of significant cultural or scientific values of the discovery. The operator shall be held responsible for the cost of the proper mitigation measures that the Authorized Officer assesses after consultation with the operator on the evaluation and decisions of the discovery. Any unauthorized collection or disturbance of cultural or paleontological resources may result in a shutdown order by the Authorized Officer.

IV. NOXIOUS WEEDS

The operator shall be held responsible if noxious weeds become established within the areas of operations. Weed control shall be required on the disturbed land where noxious weeds exist, which includes the roads, pads, associated pipeline corridor, and adjacent land affected by the establishment of weeds due to this action. The operator shall consult with the Authorized Officer for acceptable weed control methods, which include following EPA and BLM requirements and policies.

V. SPECIAL REQUIREMENT(S)

Timing Limitation Stipulation / Condition of Approval for lesser prairie-chicken: Oil and gas activities including 3-D geophysical exploration, and drilling will not be allowed in lesser prairie-chicken habitat during the period from March 1st through June 15th annually. During that period, other activities that produce noise or involve human activity, such as the maintenance of oil and gas facilities, pipeline, road, and well pad construction, will be allowed except between 3:00 am and 9:00 am. The 3:00 am to 9:00 am restriction will not apply to normal, around-the-clock operations, such as venting, flaring, or pumping, which do not require a human presence during this period. Additionally, no new drilling will be allowed within up to 200 meters of leks known at the time of permitting. Normal vehicle use on existing roads will not be restricted. Exhaust noise from pump jack engines must be muffled or otherwise controlled so as not to exceed 75 db measured at 30 feet from the source of the noise.

Ground-level Abandoned Well Marker to avoid raptor perching: Upon the plugging and subsequent abandonment of the well, the well marker will be installed at ground level on a plate containing the pertinent information for the plugged well. For more installation details, contact the Carlsbad Field Office at 575-234-5972.

VI. CONSTRUCTION

A. NOTIFICATION

The BLM shall administer compliance and monitor construction of the access road and well pad. Notify the Carlsbad Field Office at (575) 234-5972 at least 3 working days prior to commencing construction of the access road and/or well pad.

When construction operations are being conducted on this well, the operator shall have the approved APD and Conditions of Approval (COA) on the well site and they shall be made available upon request by the Authorized Officer.

B. TOPSOIL

The operator shall stockpile the topsoil in a low profile manner in order to prevent wind/water erosion of the topsoil. The topsoil to be stripped is approximately 4 inches in depth. The topsoil will be used for interim and final reclamation.

C. CLOSED LOOP SYSTEM

Tanks are required for drilling operations: No Pits.

The operator shall properly dispose of drilling contents at an authorized disposal site.

D. FEDERAL MINERAL MATERIALS PIT

Payment shall be made to the BLM prior to removal of any federal mineral materials. Call the Carlsbad Field Office at (575) 234-5972.

E. WELL PAD SURFACING

Surfacing of the well pad is not required.

If the operator elects to surface the well pad, the surfacing material may be required to be removed at the time of reclamation.

The well pad shall be constructed in a manner which creates the smallest possible surface disturbance, consistent with safety and operational needs.

F. ON LEASE ACCESS ROADS

Road Width

The access road shall have a driving surface that creates the smallest possible surface disturbance and does not exceed fourteen (14) feet in width. The maximum width of surface disturbance, when constructing the access road, shall not exceed twenty (20) feet.

Surfacing

Surfacing material is not required on the new access road driving surface. If the operator elects to surface the new access road or pad, the surfacing material may be required to be removed at the time of reclamation.

Where possible, no improvements should be made on the unsurfaced access road other than to remove vegetation as necessary, road irregularities, safety issues, or to fill low areas that may sustain standing water.

The Authorized Officer reserves the right to require surfacing of any portion of the access road at any time deemed necessary. Surfacing may be required in the event the road deteriorates, erodes, road traffic increases, or it is determined to be beneficial for future field development. The surfacing depth and type of material will be determined at the time of notification.

Crowning

Crowning shall be done on the access road driving surface. The road crown shall have a grade of approximately 2% (i.e., a 1" crown on a 14' wide road). The road shall conform to Figure 1; cross section and plans for typical road construction.

Turnouts

Vehicle turnouts shall be constructed on the road. Turnouts shall be intervisible with interval spacing distance less than 1000 feet. Turnouts shall be constructed on all blind curves. Turnouts shall conform to the following diagram:




Drainage

Drainage control systems shall be constructed on the entire length of road (e.g. ditches, sidehill outsloping and insloping, lead-off ditches, culvert installation, and low water crossings).

A typical lead-off ditch has a minimum depth of 1 foot below and a berm of 6 inches above natural ground level. The berm shall be on the down-slope side of the lead-off ditch.

Cross Section of a Typical Lead-off Ditch



All lead-off ditches shall be graded to drain water with a 1 percent minimum to 3 percent maximum ditch slope. The spacing interval are variable for lead-off ditches and shall be determined according to the formula for spacing intervals of lead-off ditches, but may be amended depending upon existing soil types and centerline road slope (in %);

Formula for Spacing Interval of Lead-off Ditches

Example - On a 4% road slope that is 400 feet long, the water flow shall drain water into a lead-off ditch. Spacing interval shall be determined by the following formula:

400 foot road with 4% road slope:
$$\frac{400'}{4\%}$$
 + 100' = 200' lead-off ditch interval

Culvert Installations

Appropriately sized culvert(s) shall be installed at the deep waterway channel flow crossing.

Cattleguards

An appropriately sized cattleguard(s) sufficient to carry out the project shall be installed and maintained at fence crossing(s).

Any existing cattleguard(s) on the access road shall be repaired or replaced if they are damaged or have deteriorated beyond practical use. The operator shall be responsible for the condition of the existing cattleguard(s) that are in place and are utilized during lease operations.

A gate shall be constructed and fastened securely to H-braces.

Fence Requirement

Where entry is required across a fence line, the fence shall be braced and tied off on both sides of the passageway prior to cutting.

The operator shall notify the private surface landowner or the grazing allotment holder prior to crossing any fence(s).

Public Access

Public access on this road shall not be restricted by the operator without specific written approval granted by the Authorized Officer.

intervisible turnouts shall be constructed all single lane roads on all blind car, additional tunouts as needed to keep below 1000 feet. Typical Turnout Plan height of fill at shoulder **Embankment Section** 03 - .05 h/h 02 - .04 h/h .02 - .03 h/h **Side Hill Section** Typical Inslope Section Typical Outsloped Section

Figure 1 - Cross Sections and Plans For Typical Road Sections

VII. DRILLING

A. DRILLING OPERATIONS REQUIREMENTS

The BLM is to be notified a minimum of 4 hours in advance for a representative to witness:

- a. Spudding well
- b. Setting and/or Cementing of all casing strings
- c. BOPE tests

Eddy County.

Call the Carlsbad Field Office, 620 East Greene St., Carlsbad, NM 88220, (575) 361-2822

- 1. Although Hydrogen Sulfide has not been reported in the area, it is always a potential hazard. If Hydrogen Sulfide is encountered, please report measured amounts and formations to the BLM.
- 2. Unless the production casing has been run and cemented or the well has been properly plugged, the drilling rig shall not be removed from over the hole without prior approval. If the drilling rig is removed without approval an Incident of Non-Compliance will be written and will be a "Major" violation.
- 3. Floor controls are required for 3M or Greater systems. These controls will be on the rig floor, unobstructed, readily accessible to the driller and will be operational at all times during drilling and/or completion activities. Rig floor is defined as the area immediately around the rotary table; the area immediately above the substructure on which the draw works are located, this does not include the dog house or stairway area.
- 4. The record of the drilling rate along with the GR/N well log run from TD to surface (horizontal well vertical portion of hole) shall be submitted to the BLM office as well as all other logs run on the borehole 30 days from completion. If available, a digital copy of the logs is to be submitted in addition to the paper copies. The Rustler top and top and bottom of Salt are to be recorded on the Completion Report.

B. CASING

Changes to the approved APD casing program need prior approval if the items substituted are of lesser grade or different casing size. The Operator can exchange the components of the proposal with that of superior strength (i.e. changing from J-55 to N-80, or from 36# to 40#).

Changes to the approved cement program need prior approval if the altered cement plan has less volume or strength or if the changes are substantial (i.e. Multistage tool, ECP, etc.).

Centralizers required on surface casing per Onshore Order 2.III.B.1.f.

Wait on cement (WOC) time prior to drilling out for a primary cement job will be a minimum 18 hours for a water basin, 24 hours in the potash area, or 500 pounds compressive strength, whichever is greater for all casing strings. DURING THIS WOC TIME, NO DRILL PIPE, ETC. SHALL BE RUN IN THE HOLE. Provide compressive strengths including hours to reach required 500 pounds compressive strength prior to cementing each casing string. See individual casing strings for details regarding lead cement slurry requirements.

No pea gravel permitted for remedial or fall back remedial without prior authorization from the BLM engineer.

Possible water flows in the Castile, Salado, Delaware and Bone Springs Groups Possible lost circulation in the Delaware and Bone Spring formations

- 1. The 13-3/8 inch surface casing shall be set at approximately 650 feet (below the Magenta Dolomite member of the Rustler Anhydrite and above the salt) and cemented to the surface.
 - a. If cement does not circulate to the surface, the appropriate BLM office shall be notified and a temperature survey utilizing an electronic type temperature survey with surface log readout will be used or a cement bond log shall be run to verify the top of the cement. Temperature survey will be run a minimum of six hours after pumping cement and ideally between 8-10 hours after completing the cement job.
 - b. Wait on cement (WOC) time for a primary cement job is to include the lead cement slurry.
 - c. Wait on cement (WOC) time for a remedial job will be a minimum of 4 hours after bringing cement to surface or 500 pounds compressive strength, whichever is greater.
 - d. If cement falls back, remedial cementing will be done prior to drilling out that string.
- 2. The minimum required fill of cement behind the 8-5/8 inch intermediate casing is: (Ensure casing is set in the base of the Castile or the Lamar at approximately 4200')
 - ☐ Cement to surface. If cement does not circulate see B.1.a, c-d above.

Centralizers required on horizontal leg, must be type for horizontal service and a minimum of one every other joint.

The pilot hole plugging is approved as written.

- 3. The minimum required fill of cement behind the 5-1/2 inch production casing is:
 - a. First stage to DV tool, cement shall:
 - Cement to circulate. If cement does not circulate, contact the appropriate BLM office before proceeding with second stage cement job. Operator should have plans as to how they will achieve circulation on the next stage.
 - b. Second stage above DV tool, cement shall:
 - Cement should tie-back at least **500** feet into previous casing string. Operator shall provide method of verification.
- 4. If hardband drill pipe is rotated inside casing, returns will be monitored for metal. If metal is found in samples, drill pipe will be pulled and rubber protectors which have a larger diameter than the tool joints of the drill pipe will be installed prior to continuing drilling operations.

C. PRESSURE CONTROL

- 1. All blowout preventer (BOP) and related equipment (BOPE) shall comply with well control requirements as described in Onshore Oil and Gas Order No. 2 and API RP 53 Sec. 17.
- 2. Minimum working pressure of the blowout preventer (BOP) and related equipment (BOPE) required for drilling below the surface casing shoe shall be 3000 (3M) psi. Operator installing a 5M and testing as a 3M.
 - a. For surface casing only: If the BOP/BOPE is to be tested against casing, the wait on cement (WOC) time for that casing is to be met (see WOC statement at start of casing section). Independent service company required.
- 3. The appropriate BLM office shall be notified a minimum of 4 hours in advance for a representative to witness the tests.

- a. In a water basin, for all casing strings utilizing slips, these are to be set as soon as the crew and rig are ready and any fallback cement remediation has been done. The casing cut-off and BOP installation can be initiated four hours after installing the slips, which will be approximately six hours after bumping the plug. For those casing strings not using slips, the minimum wait time before cut-off is eight hours after bumping the plug. BOP/BOPE testing can begin after cut-off or once cement reaches 500 psi compressive strength (including lead when specified), whichever is greater. However, if the float does not hold, cut-off cannot be initiated until cement reaches 500 psi compressive strength (including lead when specified).
- b. The tests shall be done by an independent service company utilizing a test plug **not** a **cup** or **J-packer**. The operator also has the option of utilizing an independent tester to test without a plug (i.e. against the casing) pursuant to Onshore Order 2 with the pressure not to exceed 70% of the burst rating for the casing. Any test against the casing must meet the WOC time for water basin (18 hours) or potash (24 hours) or 500 pounds compressive strength, whichever is greater, prior to initiating the test (see casing segment as lead cement may be critical item).
- c. The results of the test shall be reported to the appropriate BLM office.
- d. All tests are required to be recorded on a calibrated test chart. A copy of the BOP/BOPE test chart and a copy of independent service company test will be submitted to the appropriate BLM office.
- e. The BOP/BOPE test shall include a low pressure test from 250 to 300 psi. The test will be held for a minimum of 10 minutes if test is done with a test plug and 30 minutes without a test plug.

D. DRILL STEM TEST

If drill stem tests are performed, Onshore Order 2.III.D shall be followed.

E. WASTE MATERIAL AND FLUIDS

All waste (i.e. drilling fluids, trash, salts, chemicals, sewage, gray water, etc.) created as a result of drilling operations and completion operations shall be safely contained and disposed of properly at a waste disposal facility. No waste material or fluid shall be disposed of on the well location or surrounding area.

Porto-johns and trash containers will be on-location during fracturing operations or any other crew-intensive operations.

CRW 040412

VIII. PRODUCTION (POST DRILLING)

A. WELL STRUCTURES & FACILITIES

Placement of Production Facilities

Production facilities should be placed on the well pad to allow for maximum interim recontouring and revegetation of the well location.

Containment Structures

The containment structure shall be constructed to hold the capacity of the entire contents of the largest tank, plus 24 hour production, unless more stringent protective requirements are deemed necessary by the Authorized Officer.

Painting Requirement

All above-ground structures including meter housing that are not subject to safety requirements shall be painted a flat non-reflective paint color Shale Green, Munsell Soil Color Chart # 5Y 4/2

B. PIPELINES

Temporary Freshwater Pipelines (Fracturing Operations) CONDITIONS OF APPROVAL

Maintain a copy of your temporary permit and your approved route diagram on location. BLM personnel may request to see a copy of your permit during construction to ensure compliance with all conditions of approval.

Holder agrees to comply with the following conditions of approval to the satisfaction of the Authorized Officer:

1. The Holder shall indemnify the United States against any liability for damage to life or property arising from the occupancy or use of public lands under this permit.

2. Standard Conditions of Approval:

- Temporary pipelines must be removed within 30-45 days from this route unless granted in writing by the authorized officer.
- Temporary pipelines flowing from the frac pond to the target well(s) will be laid along existing roadways unless an exception has been granted by the authorized officer.
- Pipe will be hand-carried and hand-laid along any cross country portion of the approved route.
- Areas impacted (disturbed greater than vegetation compaction) by your project may require full reclamation.

- Pipelines will be empty before disassembly. Flow water back to the pond whenever possible.
- Do not restrict traffic on existing roads. Place ramps where needed.
- Pipe will be placed not more than 2 feet off the edge of existing lease roads, 2-track roads, or buried pipeline corridors.
- All pumps will be placed on existing disturbance (pads, roads, etc.).
- 3. Any cultural and/or paleontological resources (historic or prehistoric site or object) discovered by the holder, or any person working on his behalf shall be immediately reported to the Authorized Officer. Holder shall suspend all operations in the immediate area of such discovery until written authorization to proceed is issued by the Authorized Officer.

C. ELECTRIC LINES (not applied for in APD)

IX. INTERIM RECLAMATION

During the life of the development, all disturbed areas not needed for active support of production operations should undergo interim reclamation in order to minimize the environmental impacts of development on other resources and uses.

Within six (6) months of well completion, operators should work with BLM surface management specialists (Jim Amos: 575-234-5909) to devise the best strategies to reduce the size of the location. Interim reclamation should allow for remedial well operations, as well as safe and efficient removal of oil and gas.

During reclamation, the removal of caliche is important to increasing the success of revegetating the site. Removed caliche that is free of contaminants may be used for road repairs, fire walls or for building other roads and locations. In order to operate the well or complete workover operations, it may be necessary to drive, park and operate on restored interim vegetation within the previously disturbed area. Disturbing revegetated areas for production or workover operations will be allowed. If there is significant disturbance and loss of vegetation, the area will need to be revegetated. Communicate with the appropriate BLM office for any exceptions/exemptions if needed.

All disturbed areas after they have been satisfactorily prepared need to be reseeded with the seed mixture provided below.

Upon completion of interim reclamation, the operator shall submit a Sundry Notices and Reports on Wells, Subsequent Report of Reclamation (Form 3160-5).

X. FINAL ABANDONMENT & RECLAMATION

At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land are restored.

Earthwork for final reclamation must be completed within six (6) months of well plugging. All pads, pits, facility locations and roads must be reclaimed to a satisfactory revegetated, safe, and stable condition, unless an agreement is made with the landowner or BLM to keep the road and/or pad intact.

After all disturbed areas have been satisfactorily prepared, these areas need to be revegetated with the seed mixture provided below. Seeding should be accomplished by drilling on the contour whenever practical or by other approved methods. Seeding may need to be repeated until revegetation is successful, as determined by the BLM.

Operators shall contact a BLM surface protection specialist prior to surface abandonment operations for site specific objectives (Jim Amos: 575-234-5909).

Ground-level Abandoned Well Marker to avoid raptor perching: Upon the plugging and subsequent abandonment of the well, the well marker will be installed at ground level on a plate containing the pertinent information for the plugged well.

Seed Mixture for LPC Sand/Shinnery Sites

The holder shall seed all disturbed areas with the seed mixture listed below. The seed mixture shall be planted in the amounts specified in pounds of pure live seed (PLS)* per acre. There shall be <u>no</u> primary or secondary noxious weeds in the seed mixture. Seed will be tested and the viability testing of seed will be done in accordance with State law(s) and within nine (9) months prior to purchase. Commercial seed will be either certified or registered seed. The seed container will be tagged in accordance with State law(s) and available for inspection by the authorized officer.

Seed will be planted using a drill equipped with a depth regulator to ensure proper depth of planting where drilling is possible. The seed mixture will be evenly and uniformly planted over the disturbed area (smaller/heavier seeds have a tendency to drop the bottom of the drill and are planted first). The holder shall take appropriate measures to ensure this does not occur. Where drilling is not possible, seed will be broadcast and the area shall be raked or chained to cover the seed. When broadcasting the seed, the pounds per acre are to be doubled. The seeding will be repeated until a satisfactory stand is established as determined by the authorized officer. Evaluation of growth will not be made before completion of at least one full growing season after seeding.

Species to be planted in pounds of pure live seed* per acre:

Species	lb/acre	
Plains Bristlegrass	5lbs/A	
Sand Bluestem	5lbs/A	
Little Bluestem	3lbs/A	
Big Bluestem	6lbs/A	
Plains Coreopsis	2lbs/A	
Sand Dropseed	1lbs/A	

^{*}Pounds of pure live seed:

Pounds of seed x percent purity x percent germination = pounds pure live seed