

CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.B.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No.	
Federal LC-049998 (a)	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - " (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER: <u>WIW</u>		RECEIVED	
2. Name of Operator		7. Unit Agreement Name	
<u>Sun Oil Company /</u>			
3. Address of Operator		8. Farm or Lease Name	
<u>P.O. Box 1861, Midland, Texas 79702</u>		<u>V.L. Foster</u>	
4. Location of Well		9. Well No.	
<u>UNIT LETTER G</u> , <u>2310</u> FEET FROM THE <u>North</u> LINE <u>ARTESIA, OFFICE</u> <u>1650</u> FEET FROM		<u>6</u>	
THE <u>East</u> LINE, SECTION <u>17</u> TOWNSHIP <u>17-S</u> RANGE <u>31-E</u> N.M.P.M.		10. Field and Pool, or Wildcat	
		<u>Grayburg-Jackson</u>	
11. Elevation (Show whether DF, RT, GR, etc.)		12. County	
<u>NA</u>		<u>Eddy</u>	

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPER. ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER ☐	CASING TEST AND CEMENT JOB ☐	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU csg. PU. Install BOP. POH W/ old 2-3/8 Tbg.
 RIH w/2-3/8" tbg. to 3465. Load Hole w/9.5#mud laden fluid. POH.
 RIH w/CIBP on WL. Set CIBP @ 2840, dump 2 sx cmt on top CIBP
 Stretch csg & locate free point. Cut csg. above free point & POH w/4-1/2"csg.
 RIH w/CIBP ON SL. Set CIBP @ 1960', dump 2 sx cmt on top CIBP.
 Stretch csg & locate free point. Cut csg above free point & POH w/7"csg.
 RIH w/2-3/8" tbg. Spot 20 sx cmt from 1410 to 1310', 30 sx cmt @561'.
 Spot 10 sx cmt @ Surface.
 Cut csg off 3' below surface, weld on steel plate. Weld on dry hole marker,
 clean up location.

12-3-81
 on 11/18/81
 12-3-81

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Maria L. Perez TITLE Sr. Acctng. Asst. DATE 12-1-81

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: