

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN 1 INDICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

1C 029420 (b)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. UNIT AGREEMENT NAME Shelly Unit
2. NAME OF OPERATOR SHELLY OIL COMPANY	8. FARM OR LEASE NAME Shelly Unit
3. ADDRESS OF OPERATOR P. O. Box 730 - Hobbs, New Mexico 88240	9. WELL NO. 65
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2080' FHL & 1980' FHL Sec. 21-178-31E	10. FIELD AND POOL, OR WILDCAT Grayburg-Jackson
14. PERMIT NO. -----	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 21-178-31E
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3812' DF	12. COUNTY OR PARISH Edley
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Well is presently producing from perfs. 3267-3320' of the Grayburg and perfs. 3642-3651' of the San Andres Formations.

We propose to perforate additional holes in the Grayburg and San Andres Formations and treat as follows:

1. Move in and rig up Workover Rig.
2. Pull rods and tubing.
3. Selectively perforate 5-1/2" OD casing in the Grayburg and San Andres Formations from 3006-3456' with a total of 20 shots.
4. Isolate and treat through 5-1/2" OD casing perfs. 3353-3456' with 1300 gals. acid.
5. Isolate and treat through 5-1/2" OD casing perfs. 3006-3240' with 1000 gals. acid and ball sealers.
6. Isolate and treat through 5-1/2" OD casing perfs. 3006-3240' with 15,000 gals. water and 15,000# 20/40 sand.
7. Pull retrievable bridge plug.
8. Run tubing and rods.
9. Test and return well to a producing status.

18. I hereby certify that the foregoing is true and correct

SIGNED Stanley J. E. StohrerTITLE District Superintendent DATE November 22, 1967

(This space for Federal or State office use)

APPROVED BY [Signature]
CONDITIONS OF APPROVAL, IF ANY:

TITLE _____ DATE _____

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.