

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	☒
FILE	☒
U.S.O.S.	☒
LAND OFFICE	☒
OPERATOR	☒

RECEIVED
OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501
OCT 26 '88

Form C-103
Revised 12-1-78

O. C. D.
ARTESIA, OFFICE

3a. Indicate Type of Lease State ☒ Fee ☐
3. State Oil & Gas Lease No. E-4201

SUNDRY NOTICES AND REPORTS ON WELLS DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE APPLICATION FOR PERMIT (FORM C-101) FOR SUCH PROPOSALS.	
OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name Empire South Deep Unit
Name of Operator Harvey E. Yates Company	8. Term of Lease Name
Address of Operator P.O. Box 1933 Roswell, NM. 88202	9. Well No. # 18
Location of Well UNIT LETTER <u>F</u> <u>1980'</u> FEET FROM THE <u>North</u> LINE AND <u>1980'</u> FEET FROM <u>West</u> LINE, SECTION <u>30</u> TOWNSHIP <u>17-s</u> RANGE <u>29-e</u> NMPM.	10. Field and Pool, or Wildcat E. Empire Wolfcamp
11. Elevation (Show whether DF, RT, GR, etc.) 3643' <u>+</u>	12. County Eddy

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REPAIR REMEDIAL WORK ☐	PLUG AND ABANDON ☒	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPERATIONS ☐	PLUG AND ABANDONMENT ☐
WELL OR ALTER CASING ☐		CASING TEST AND CEMENT JOBS ☐	
OTHER ☐	Re-activate prior approved P&A. Approved (7/23/87) ☒ by Mike Williams (OCD II)	OTHER ☐	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TOC @ 4010' by Temp Survey / PBTD @ 7940'; perfs: 7859-70'.

1. Set CIBP @ 7800+ or - w/ 35' amt on top; load hole w/ mud.
2. Pump 100' plug from 7300- 7200' (top of Wolfcamp)
3. Pump 100' plug from 6000-5900' (top if ABO)
4. Free point 5 1/2" 17# N-80 & J-55 csg. Cut & pull approx. 3500' + or - csg.
5. Pump 100' plug (50' in & out of 5 1/2" cut off) & tag.
6. Pump 100' plug from 2950 - 2850' (Across 8 5/8" shoe.) + Tag
7. Pump 100' plug from 450-350' (across 12 3/4" shoe interval)
8. Pump 50' surface plug.
9. Install dry hole marker.

Call OCD DISTRICT II prior to plugging @ 1-748-1283

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

Ray Nokes TITLE Prod. Mgr./ Eng. DATE 10-25-88

Original Signed By
Mike Williams

DATE OCT 27 1988

NOTATIONS OF APPROVAL, IF ANY: