

RECEIVED BY

NOV 15 1985
SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. O. C. D.
OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Anadarko Petroleum Corporation ✓

3. ADDRESS OF OPERATOR

P. O. Drawer 130, Artesia, New Mexico 88210

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)

At surface

2135' FSL & 1650' FEL

14. PERMIT NO. 22623

30-015-22581

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3590.4' GL

5. LEASE DESIGNATION AND SERIAL NO.

LC - 030570 B

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Power Federal Com.

9. WELL NO.

1-Y

10. FIELD AND POOL, OR WILDCAT

Cedar Lake Morrow

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

26 - 17S - 30E

12. COUNTY OR PARISH

Eddy

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐
☐

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other) Plug & Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rig up pulling unit; trip out of hole with packer.
2. Set CIBP @ 5156' (Glorietta top).
3. Shoot 4½" casing off @ 3580' (20' above cement top); pull 4½" casing out of hole.
4. Go in hole with tubing open-ended. Spot 25 sx cement on CIBP @ 5156' up to 4816' (this plug covers Glorietta top).
5. Spot 45 sx cement from 3700' up to 3480' (this plug covers 4½" and 9-5/8" casing stubs). Pull up hole; wait 3 hours; tag top of plug.
6. Spot 40 sx cement from 3420' up to 3305' (this plug covers San Andres formation top). Pull up hole; wait 3 hours; tag top of plug.
7. Spot 40 sx cement from 2910' up to 2795' (this plug covers Grayburg formation top). Pull up hole; wait 3 hours; tag top of plug.
8. Spot 40 sx cement from 1270' up to 1155' (this plug covers base of Salt). Pull up hole; wait 3 hours; tag top of plug.
9. Perforate 4 squeeze holes at 450' (50' above Salt).
10. Go in hole with packer and cement squeeze with 75 sx cement out squeeze holes, leaving 100' cement inside 9-5/8" casing and 100' cement outside 9-5/8" casing (this plug will cover top of Salt and 13-3/8" casing shoe). Pull up; wait 3 hours; tag top of plug.
11. Spot a 50' plug at surface.
12. Cut off all casing and anchors below surface; set P & A marker; clean & level location.

Note: Will leave 10# brine and Salt gel mud between all plugs.

18. I hereby certify that the foregoing is true and correct

SIGNED Mike Brumwell

TITLE Field Foreman

DATE October 3, 1985

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE 11-14-85

*See Instructions on Reverse Side

Anadarko

Powers Feed Corn 1-Y

10-3-85

