

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

M-031914

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Burrell #1 Federal

9. WELL NO.

10. FIELD AND POOL OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 14-19S-31E

12. COUNTY OR PARISH

Eddy

13. STATE

N.M.

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Gulf Oil Corporation

3. ADDRESS OF OPERATOR

P. O. Box 670, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980° FNNL Section 14-19S-31E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3539° GL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

11,410° TD. 5353° PB. It is proposed to plug and abandon as follows:

Kill well with water.

Pull tubing and packer. Run wire line bridge plug and set at approximately 5300°. Cap with 1-1/2 sacks cement. Run tubing to PB and circulate. Cut 5-1/2" casing at approximately 4500° and recover. Run tubing and spot cement plugs: #1, 430-450° with 20 sacks cement, across 5-1/2" casing stub; #2, 3900-4000° with 30 sacks, across 8-5/8" casing seat. Pull out of hole and cut 8-5/8" casing above top of cement at 2215° and recover if possible. Run tubing and spot cement plugs: #3, 50° inside 8-5/8" to 50° above stub with 55 sacks; #4, 650-750°, 75 sacks (across 13-3/8" casing seat); #5, 0-50°, 35 sacks. Install dry hole marker and clean location.

*In the event that free-point indicates insufficient recoverable 8-5/8" casing in lieu of Plugs Nos. 3 and 4, the hole will be filled with mud, then Plug No. 5 set.

RECEIVED

APR 22 1970

O. C. C.
ARTESIAL OFFICE

RECEIVED

APR 21 1970

GEOLOGICAL SURVEY

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Area Production Manager

(This space for Federal or State office use)

DATE 4-17-70

APPROVED BY
CONVENTION OF APPROVAL, IF ANY:

TITLE

DATE

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations of Federal or Indian lands should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents, not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mid or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1964 O-685229