

NO. OF COPIES RECEIVED	3
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

<b>SUNDRY NOTICES AND REPORTS ON WELLS</b> <small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small>		5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
1. OIL WELL <input checked="" type="checkbox"/> Dry GAS WELL <input type="checkbox"/> OTHER-		5. State Oil & Gas Lease No.
2. Name of Operator <b>Tesoro Petroleum Corporation</b>		7. Unit Agreement Name
3. Address of Operator <b>8520 Crownhill Boulevard, San Antonio, Texas 78209</b>		8. Farm or Lease Name <b>Santa Fe <del>R.R.</del></b>
4. Location of Well UNIT LETTER <b>J</b> <b>2330</b> FEET FROM THE <b>East</b> LINE AND <b>1620</b> FEET FROM THE <b>South</b> LINE, SECTION <b>1</b> TOWNSHIP <b>17N</b> RANGE <b>9W</b> NMPM.		9. Well No. <b>57</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>6952' GR 6960 RKB</b>		10. Field and Pool, or Wildcat <b>Undesignated</b>
12. County <b>McKinley</b>		

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/> CHANGE PLANS <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon above well which produced 100% water by setting 15-sack cement plug from P.B.T.D. 1652' to 1521' or 104' above top perforations in 5½" 15.5# casing. Load hole with drilling mud and shoot off casing at approximately 800' to 1000' from surface. Pull casing and set 25-sack cement plug 60' in top of 5½" casing and 62' above top of casing. Set 30-sack cement plug or 103' in 7-7/8" hole through Crevasse Canyon section if above plug does not fall in this section. Set 10-sack plug at surface with marker as per regulations.



18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Walter E. Dunn</u>	TITLE <u>Drig &amp; Prod Superintendent</u>	DATE <u>January 15, 1970</u>
APPROVED BY <u>Barney Chavez</u>	TITLE <u>Sup Dist III</u>	DATE <u>1-19-70</u>
CONDITIONS OF APPROVAL, IF ANY:		