

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1. NAME OF OPERATOR Hanson Oil Corporation	2. NAME OF OPERATOR ☒ OIL ☐ GAS ☐ WELL ☐ OTHER Dry Hole
3. ADDRESS OF OPERATOR P. O. Box 1515, Roswell, New Mexico 88201	4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) 2310' FEL & 330' FNL
5. ELEVATIONS (Show whether in ft., m., etc.) 6362' GL	6. COUNTY OR PARISH, STATE Sec. 25, T. 17N, R. 3W NM
7. UNIT AGREEMENT NAME CANDY BUTTE	8. FIELD AND ROOM, OR WILDCAT Wildcat
9. WELL NO. #5	10. SURVEY OR AREA Sandoval

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

TEST WATER SHUT-OFF	WELL OR ALTER CASING	MULTIPLE COMPLETE	ABANDON*	CHANGE PLANS	(Other)
☐	☐	☐	☒	☐	☐

17. (To be filled in for PROPOSED OR COMPLETED OPERATIONS. (If early state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

(Note: Report results of multiple completion on well completion or abandonment Report and Log form.)

REPAIRING WELL	ALTERING CASING	ABANDONING WELL	SHOOTING OR ACIDIZING	PRODUCTION OR ACIDIZING	WATER SHUT-OFF
☐	☐	☐	☐	☐	☐

Pursuant to telephone conversation with Mr. Richard Bell June 29, 1981, we plan to plug and abandon this well as follows:

- 1: One 100' plug VIA dump bailer from 3488' TD, top Entrada formation to 3388'.
- 2: Run freepoint to locate free pipe; dump 50' cement plug VIA dump bailer inside 5 1/2" stubb before shooting. Pump 50' cement plug VIA 5 1/2" casing, displacing with mud.
- 3: Spot 100' cement plugs VIA 5 1/2" casing as follows:

2400' - 2500' across top of Morrison formation
2210' - 2310' across top of Dakota formation
1260' - 1360' across top of Tooto formation
270' - 370' in and out base of 8 5/8" casing at 320'
50' plug with marker at surface

- 4: Should the free point be above any of the above listed formations, a cement plug VIA dump bailer will be spotted inside the 5 1/2" casing.

18. I hereby certify that the foregoing is true and correct

SIGNED: *[Signature]*

TITLE: Production Analyst

DATE: 7/2/81

(This space for Federal or State office use)

APPROVED BY: _____
CONDITIONS OF APPROVAL, IF ANY:

TITLE:

APPROVED

JUL 08 1981

Instructions on Reverse Side

INMOC

[Signature]

