## (ely 9-331) OIL WEL MAM

## UNITED STATES BUBMIT IN TRIPLICATES (Other instructions on re-

BUREAU OF LAND MANAGEMENT

Expires August 31, 1985 S. LEASE DESIGNATION AND SERIAL NO. SF079162

6. IF INDIAN, ALLOTTER OR TRIBE NAME

SUNDRY NOTICES	AND	REPORTS	ON	WELLS

	SUNDRY NOTICES AND REPORTS OF WELLS  (Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  Use "APPLICATION FOR PERMIT—" for such proposals.)	7. UNIT AGRREMENT NAME		
ī.	OIL GAS THESE	·		
		S. FARM OR LEASE NAME		
1.	NAME OF OPERATOR	MKL		
	DEPCO, Inc.	9. WBLL NO.		
3.	ADDRESS OF OPERATOR			
	1000 Petroloum Ridg 110 16th Street, Denver, CO 80202	10. FIELS AND POOL, OR WILDCAT		
4.	LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*  RECEIVED	So. Blanco P.C.		
	At surface TILOLIVE	11. SEC., T., B., M., OR BLK. AND		

NW-SW

1592' FSL, 847' FWL

JUN 17 1987

SURVEY OR AREA

Sec. 5, T26N-R7W

14. PERMIT NO. NA

16.

6033' GR

15. SLEVATIONS (Show whether DF, BT, GR, etc.)
BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA

Rio Arriba

12. COUNTY OR PARISH 18. STATE MM

## Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data SUBSEQUENT REPORT OF:

NAMED OF INT	ENTION TO:	Bubbadon:		
NOTICE OF INT	PULL OR ALTER CASING MULTIPLE COMPLETE ABANDON* CHANGE PLANS	WATER SHUT-OFF  FRACTURE TREATMENT  SHOOTING OR ACIDIZING  (Other)  (Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)		
(Other)		at a date including estimated date of start	an:	

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.).

PROCEDURE FOR REPAIRING CASING

10 3/4" CSG at 154' W/100 SX

TD at 2206'

7" csg at 2136 w/100 sx

Open Hole 2136-2206

- 2 3/8" TBG & Packer, Packer set at 2027
- MI & RU, POOH WITH PRODUCTION EQUIPMENT.
- SET RBP ABOVE OPEN HOLE, DUMP SAND ON TOP OF RBP 2.
- LOCATE CASING LEAK AND STAGE SQUEEZE WITH 50 TO 100 SACKS OF CEMENT.
- DRILL AND CLEAN OUT CEMENT. TEST CASING LEAK AND RESQUEEZE IF NECESSARY.
- TOOH WITH RBP, TIH WITH PRODUCTION EQUIPMENT AND PUT WELL ON PRODUCTION. 5.

,		si verti i
<u>-</u>		mengalan akan basa termini separah dari
		Car a second
18. I hereby cepair that the foregoing is true and correct		Burney Comment
SIGNED JAN SKYLL	TITLE Dist. Prod. Supt.	DATE June 12, 1987
(This space for Federal (of State office use)		JUN-1, 8, 1967
APPROVED BY	TITLE	John Killing
60.02270313	NMOCC	CAPEA MASONUM FARMINISTON RESOLUTE LATE
•s	ee Instructions on Reverse Side	PARMING CON PLOUS OF THE