

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on reverse side)

Form approved.
Budget Bureau No. 42-R7424.

5. LEASE DESIGNATION AND SERIAL NO.

FED. NOO-C14-20-2727

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Navajo Tribe

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Navajo Tribe "BP"

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Tocito Dome Field

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

K-26-T26N-R18W

12. COUNTY OR PARISH 13. STATE

San Juan N. Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

TEXACO, Inc.

3. ADDRESS OF OPERATOR

P.O. Box EE, Cortez, Colo. 81321

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

1980' from South line and 1980' from West line.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5592' DF

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to abandon well because of marginal productivity and uneconomical to repair collapsed casing.

Procedure:

1. Spot 50 sacks cement across perforations 6335' - 6365'.
2. Find free point of tubing string, cut it, and pull it.
3. Cut off casing above collapse point and salvage it.
4. Place 50 sacks cement in and around casing stub.
5. Fill hole with mud to 10' below surface pipe, or about 1635'.
6. Place 50 sacks cement at base of surface pipe 1625'.
7. Fill hole with mud.
8. Place 10 sacks cement surface plug, set proper marker, salvage all remaining wellhead equipment, and clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED *Alvin B. Marx*

TITLE Field Foreman

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

SEP 7

SEP 3 1976

*See Instructions on Reverse Side

NMOCC(3) USGS(2) GLE-ARM-JHP

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; and or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking for approval of the abandonment.

U.S. GOVERNMENT PRINTING OFFICE: 1963 - O-685229

847-485