

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-B1424.

5. LEASE DESIGNATION AND SERIAL NO.

14-20-603-5033

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

Navajo Tribe

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Navajo Tribal "P"

9. WELL NO.

5

10. FIELD AND POOL, OR WILDCAT

Tozito Dome Penn. "D"

11. SEC., T., R., M., OR BLK. AN
SURVEY OR AREANE/4 NE/4 Section 7,
T-26-N, R-18-W

12. COUNTY OR PARISH

San Juan

13. STATE

New Mexico

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL ☒ GAS ☐ OTHER ☐
WELL WELL

2. NAME OF OPERATOR

AMOCO PRODUCTION COMPANY

FEB 1 1975

3. ADDRESS OF OPERATOR

501 Airport Drive, Farmington, New Mexico 87401

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FNL & 660' FNL, Section 7, T-26-N, R-18-W

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5814' CL

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:


WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any
proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones perti-
nent to this work.)*Due to the above well being unable to produce commercial quantities of hydrocarbons, we
plan to plug and abandon the well as follows:

1. Squeeze perfs 6436-52' with 50 sacks cement.
2. Cut off 7" casing at 5800' and pull. Spot 50 sacks Cement plug 50' below casing
stub and displace out of stub.
3. Spot 50 sacks cement plug at 4770'.
4. Spot 100 sacks cement plug at 4100' to 4300'.
5. Spot 50 sacks cement plug at 3820'.
6. Spot 50 sacks cement plug at 2700'.
7. Spot 50 sacks cement plug at 2100'.
8. Spot 50 sacks cement plug below intermediate casing (1510') and displace 50' into
intermediate casing.
9. Spot 25 sack surface plug and erect P&A marker.

Procedure approved by H. L. Seelinger, U.S.G.S., 1-24-75.

18. I hereby certify that the foregoing is true and correct

SIGNED



TITLE

Area Adm. Supvr.

DATE

2-3-75

(This space for Federal or State office use)

APPROVED BY



TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.