

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT - " for such proposals

5. Lease Designation and Serial No.

SF-077085

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

OMLER 4

9. API Well No.

300450150

10. Field and Pool, or Exploratory Area

KUTZ PICTURED CLIFFS

11. County or Parish, State

SAN JUAN NEW MEXICO

1. Type of Well
☐ Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

AMOCO PRODUCTION COMPANY

Attention:

LOIS RAE BURN

3. Address and Telephone No.

P.O. Box 80C, Denver, Colorado 80201

(303) 830-5294

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

1650FSL 990FWL Sec. 26 T 28N R 10w

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

AMOCO PRODUCTION COMPANY REQUEST PERMISSION TO PLUG AND ABANDON THE ABOVE MENTIONED WELL.

Phone approval from Wayne Townsend by Carolanne Wyett.

SEE ATTACHED PROCEDURES

IF YOU HAVE ANY QUESTIONS PLEASE CONTACT CAROLANNE WYETT @ (303) 830-5578

RECEIVED
DEC - 8 1994

OIL CON. DIV.
DIST. 3

14. I hereby certify that the foregoing is true and correct

Signed

Lois Raeburn

Title

Business Assistant

Date

11-28-1994

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

APPROVED

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious, or fraudulent statements or representations as to any matter within its jurisdiction.

* See Instructions on Reverse Side

DEC 11 1994
DISTRICT MANAGER

PXA Procedures
Omler #4

1. Check location for anchors. Install if necessary. Test anchors.
2. MIRUSU. Blow down well. Kill if necessary with fresh water.
3. POOH with 1 1/4" tbg and lay down. NDWH. NUBOP. RIH with 2 3/8" workstring and cement retainer, set retainer at 1810'. Run short string CBL to determine TOC. (should be around 900') Squeeze perms at 1868' to 1929' with 39.752 cuft cement.
4. By CBL if TOC is below Ojo Alamo at 854', spot cement plug to 900'. POOH and run in hole with perf gun and shoot squeeze holes at 900' and circulate to surface with 499.52 cuft cement. Fill hole with 46.389 cuft of cement inside casing.
5. By CBL if TOC is above Ojo Alamo at 854', pull out of retainer and spot cement plug to surface. (90.824 cuft cement). Pump 42.067 cuft cement down bradenhead to insure cement across surface casing shoe.
6. NDBOP. Cut off casing and wellhead. Install PXA marker according to BLM or state requirements.
7. Turn over to John Schwartz for reclamation.
8. Rehabilitate location according to BLM or State requirements.