

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPPLICATE\*  
(Other instructions on reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

**SF 078106**

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

**Gallegos Canyon Unit GPA "1"**

8. FARM OR LEASE NAME

9. TIER NO.

**260**

10. FIELD AND POOL, OR WILDCAT

**Pinon Gallup**

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

**NE/4 SE/4 Section 15,  
T-28-N, R-12-W**

12. COUNTY OR PARISH

**San Juan**

13. STATE  
**New Mexico**

1. ☐ OIL ☐ WELL ☐ OTHER **Water Injection**

2. NAME OF OPERATOR  
**AMOCO PRODUCTION COMPANY**

3. ADDRESS OF OPERATOR  
**501 Airport Drive, Farmington, New Mexico 87401**

4. LOCATION OF WELL (Report location clearly and in accordance with all stat. requirements.  
See also space 17 below)  
At surface

**1910' FSL & 745' FEL**

14. PERMIT NO.

15. ELEVATIONS (Show absolute, etc., etc.)

**5668' RDE**

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

(Other) ☐

DRILL OR ALTER CASING ☐

MULTIPLE COMPLETION ☐

ABANDON\* ☒

CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐

FRACTURE TREATMENT ☐

SHOOTING OR ACIDIZING ☐

(Other) ☐

REPAIRING WELL ☐

ALTERING CASING ☐

ABANDONMENT\* ☐

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly show location in details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface positions and measured and true vertical depths for all markers and zones pertinent to this work.) \*

The subject well is part of a water injection system that has been abandoned due to its uneconomical state. No casing is to be removed from the hole. It is desired to permanently plug and abandon this well in the following manner:

1. Spot 50 sacks cement over perforations at 5572-5560' and squeeze 20 sacks into formation.
2. Spot 15 sacks from 4340-4142' over bottom of Mesaverde.
3. Spot 15 sacks from 3168-2970' over top of Mesaverde.
4. Spot 10 sacks from 2532-2400' over Chacra.
5. Spot 20 sacks from 1714-1450' over Pictured Cliffs.
6. Spot 20 sacks from 264'-surface.
7. Cut off wellhead, erect PXA marker, and clean up location.

(Cement was circulated to surface when surface casing was run.)

18. I hereby certify that the foregoing is true and correct

Certified by:

SIGNED

Area Engineer

**RECEIVED**  
**FEB 13 1973**  
**OIL CON. COM.**  
**DIST. 3**

DATE **February 8, 1973**

(This space for Federal or State office use)

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY

DATE

## Instructions

**General:** This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

**Item 4:** If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

**Item 17:** Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.