

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

Form Approved.  
Budget Bureau No. 42-R1424

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐  
2. NAME OF OPERATOR  
Tenneco Oil Company  
3. ADDRESS OF OPERATOR  
720 S. Colorado Blvd., Denver, Co. 80222  
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 935' FSL & 1755' FWL, Unit N  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:  
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT-OFF <input type="checkbox"/>	<input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	<input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	<input type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	<input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	<input type="checkbox"/>
MULTIPLE COMPLETE <input type="checkbox"/>	<input type="checkbox"/>
CHANGE ZONES <input type="checkbox"/>	<input type="checkbox"/>
ABANDON* <input checked="" type="checkbox"/>	<input type="checkbox"/>
(other) <input type="checkbox"/>	<input type="checkbox"/>

5. LEASE  
SF 078201  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Florance  
9. WELL NO.  
60  
10. FIELD OR WILDCAT NAME  
Blanco Pictured Cliffs  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 1, T-29-N, R-9-W  
12. COUNTY OR PARISH  
San Juan  
13. STATE  
New Mexico  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
6360' GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

The casing for this well is collapsed.

We propose to plug & abandon via the following procedure:

- 1) MIRUPU
- 2) RI H w/1 1/4" I J tbq to 2700'
- 3) Mix & pump 23 bbls 50/50 poz mix slurry w/6% Bentonite Gel dn tbq. Displace w/2.25 bbls water, cement to surface
- 4) POOH w/tbg-laying down
- 5) Fill hole w/50-50 poz mix slurry 6% Bentonite Gel. Close BOP, & pump cement dn tbq to 500 psi squeeze pressure (total of 145 Sx dry cement required - assuming 50 Sx needed for squeeze)
- 6) Cut off wellhead 1' below grade & install P&A marker. Clean & restore location in accordance with USGS requirements

Subsurface Safety Valve: Manu. and Type \_\_\_\_\_ Set @ \_\_\_\_\_ Ft.


18. I hereby certify that the foregoing is true and correct

SIGNED Carley M. Hatten TITLE Admin. Supervisor DATE 4/12/79

(This space for Federal or State office use)

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_  
CONDITIONS OF APPROVAL, IF ANY:

\*See Instructions on Reverse Side



*Tymoc*