

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Form approved.
Budget Bureau No. 42 R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER	7. UNIT AGREEMENT NAME San Juan 30-5 Unit
2. NAME OF OPERATOR El Paso Natural Gas Company	8. FARM OR LEASE NAME San Juan 30-5 Unit
3. ADDRESS OF OPERATOR PO Box 990, Farmington, NM 87401	9. WELL NO. 5
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 990'N, 900'E	10. FIELD AND POOL, OR WHICAT Blanco Mesa Verde
14. PERMIT NO.	11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 30, T-30-N, R-5-W NMPM
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6229'GL	12. COUNTY OR PARISH Rio Arriba
	13. STATE New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐
FRACTURE TREAT ☐
SHOOT OR ACIDIZE ☐
REPAIR WELL ☐
(Other) ☐

PULL OR ALTER CASING ☐
MULTIPLE COMPLETE ☐
ABANDON* ☒
CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐
FRACTURE TREATMENT ☐
SHOOTING OR ACIDIZING ☐
(Other) ☐

REPAIRING WELL ☐
ALTERING CASING ☐
ABANDONMENT* ☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Due to non-commercial production it is planned to plug and abandon this well as follows:

Spot a 50 sks. cement plug across the perforated interval (5102-5614').

Shoot off 5" casing at free point and spot a 50 sks. cement plug on the casing stub, pull casing.

Shoot off 7" casing at free point and spot a 50 sks. cement plug on the casing stub, pull casing.

Spot a 25 sks. cement plug at the base of the surface casing.

Place a 15 sks. cement plug at the surface with a Plug and Abandonment marker. Clean location.

18. I hereby certify that the foregoing is true and correct

SIGNED Original Signed 1/20/72

TITLE Petroleum Engineer

DATE January 20, 1972

(This space for Federal or State office use)

APPROVED BY
CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE