

NO. OF COPIES RECEIVED	2
DISTRIBUTION	
SANTA FE	1
FILE	1
U.S.G.S.	
LAND OFFICE	
OPERATOR	1

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator <b>El Paso Natural Gas Company</b>	8. Farm or Lease Name <b>Martin</b>
3. Address of Operator <b>Box 990, Farmington, New Mexico - 87401</b>	9. Well No. <b>3</b>
4. Location of Well UNIT LETTER <b>G</b> <b>1650</b> FEET FROM THE <b>North</b> LINE AND <b>1650</b> FEET FROM THE <b>East</b> LINE, SECTION <b>3</b> TOWNSHIP <b>29N</b> RANGE <b>11W</b> NMPM.	10. Field and Pool, or Wildcat <b>Aztec Pictured Cliffs</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>5717' GL</b>	12. County <b>San Juan</b>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Due to non-production it is planned to plug and abandon this well in the following manner:

Spot a 30 sack cement plug on bottom to fill approximately 53' of open hole and 150' inside the 5 1/2" casing.

Determine free point of 5 1/2" casing and shoot off at free point. Spot a 30 sack cement plug on casing stub and pull casing.

Spot a 30 sack cement plug across the surface casing shoe.

Place a 10 sack cement plug at surface, erect P & A marker.

Note: If 5 1/2" casing is not shot off near the base of the Ojo Alamo or below, perforate 4 holes at 820' and spot a 30 sack cement plug at that depth.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY

SIGNED **LARRY A. AIMES** TITLE **Petroleum Engineer**



APPROVED BY *[Signature]*  
CONDITIONS OF APPROVAL, IF ANY:

PETROLEUM ENGINEER DIST. NO. 9 DATE **JUN 20 1969**