

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

SF-080912

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Wood Oil Cam

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Cha Cha Gallup11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA**SE/4 SE/4 Section 17,
T-29-N, R-14-W**

12. COUNTY OR PARISH 13. STATE

San Juan**New Mexico**

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

PAN AMERICAN PETROLEUM CORPORATION

3. ADDRESS OF OPERATOR

P. O. Box 480, Farmington, New Mexico

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface**990' PBL & 660' PBL**U. S. GEOLOGICAL SURVEY
FARMINGTON, N. M.

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

5174' (RDB)

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

As a result of the Wood Oil Cam No. 1 ceasing to produce, we plan to plug and abandon the well as follows:

1. Spot 40 sacks cement containing 6% Gel and 2% calcium chloride from PBD 4733' TO about 4500' (perf 4639-4646' and 4692') and squeeze.
2. Load hole with fluid and spot 70 sacks cement containing 6% Gel and 2% calcium chloride from 3400' to 2100'.
3. Load hole with fluid and spot 10 sacks cement from 1200' to 1100'.
4. Load hole with fluid and spot 5 sacks cement (6% Gel and 2% calcium chloride) from surface to 50'.
5. Pump 50 sacks cement (6% Gel and 2% calcium chloride) into 8-5/8" - 4-1/2" casing annulus.
6. Cut off wellhead, erect PEA marker, and clean up location.

18. I hereby certify that the foregoing is true and correct

ORIGINAL SIGNATURE

SIGNED

G. W. Eaton, Jr.

TITLE

Area Engineer

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

RECEIVED

AUG 1 1966

OIL CON. COM.

DATE 3 July 28, 1966

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.