Form	9-331
(May	1963)

## UNITED STATES SUBMIT IN TRIPLICATE\* DEPARTMENT OF THE INTERIOR (Other Instructions on reverse side)

Form approved.

Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

miles miles	
*1 60 (60 nin)	
14206/132300	
<b>14-20-</b> 603 <b>-21</b> 99	
`	

EOLOGICAL SUMYET	2. 20 003-213
TEC AND DESCRIPTION WELLS	6. IF INDIAN, ALLOTTEE OR TRIBE NAM

	OFOROGLOS AND				
SUNDRY NOTICES AND REPORTS ON WELLS  (Do not use this form for proposals to drill or to respect to back to a different reservoir.  Use "APPLICATION FOR PERMIT— for the proposals.)			6. IF INDIAN, ALLOTTEE OF TRIBE NAME Navajo		
1.			7. UNIT AGREEMENT	NAME	
OIL GAS OTHER	Water Injection Well		Northwest	Northwest Cha Cha	
2. NAME OF OPERATOR			8. FARM OR LEASE	NAME	
Humble Oil & Refining Company 3. ADDRESS OF OPERATOR		Northwest 9. WELL NO.	Northwest Cha Cha Unit 9. WELL NO.		
P. O. Box 120, De	enver, Colorado 80201		23-21		
4. LOCATION OF WELL (Report location See also space 17 below.)	clearly and in accordance with any h	itate requirements.	10. FIELD AND POOL	OR WILDCAT	
NESW(1980' FSL & 1780' FWL) of Section 21		Cha Cha Gallup  11. SEC., T., R., M., OR BLE. AND SURVEY OR AREA			
			Sec 21-29N-14W NMPM		
14. PERMIT NO.   15. ELEVATIONS (Show mischer DF, RT, CR, etc.)		12. COUNTY OR PARISH 13. STATE			
	5601° KB		San Juan	New Mexico	
16. Charle A		(NLC D		11.01. 1101.20	
	ppropriate Box To Indicate No				
NOTICE OF INTE	NTION TO:	SUBSEC	QUENT REPORT OF:		
TEST WATER SHUT-OFF	PULL OR ALTER CASING	WATER SHUT-OFF	REPAIRIN	G WELL	
FRACTURE TREAT	MULTIPLE COMPLETE	FRACTURE TREATMENT	ALTERING		
SHOOT OF ACIDIZE	ABANDON*	SHOOTING OR ACIDIZING	ABANDON	MENT*	
REPAIR WELL	CHANGE PLANS	(Other)(Note: Report result	s of multiple completion	on on Well	
(Other)  17. DESCRIBE PROPOSED OR COMPLETED OF proposed work. If well is directinent to this work.)*	PERATIONS (Clearly state all pertinent ionally drilled, give supervisor breath		pletion Report and Log s, including estimated cal depths for all mark		
Ineffective injector, r in 11" hole at 217' w/1 hole at 5270' w/200 sxs We propose to plug and cement 4050-3950', Run 40 sxs cement (a 100' p @ 2590', 40 sxs cement 267-167' across bottom to be filled with mixed and clean location for	110 sxs cement circulars cement, TOC @ 3950'.  abandon as follows: free point, cut and puplug) between base of 1025-925' across top of surface casing, 12d mud. Place regulati	Perforated 5116-5 Spot 15 sxs cement .  pull as much 5½" of Pictured Cliffs @ 1 of Pictured Cliffs ( sxs cement 30-0".	14# csg set : 126' w/6 shots 5116-5016', 15 csg as possib; 130 and top of 3 975', 40 sxs Intervals bes	in 7-7/8" s/ft. 5 sxs le, spot 6 Mesaverde 6 cement tween plugs	
cc: 2 - NM O&G Commissi 1 - Minerals Superv 1 - Midland	ion visor - Navajo Tribe	OCT 1	8 1971 ( 0	CT 1 9 1971 CON. COM. DIST. 3	