

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

Form Approved.  
Budget Bureau No. 42-R1424

**SUNDRY NOTICES AND REPORTS ON WELLS**

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ gas ☒ other ☐  
well well

2. NAME OF OPERATOR  
Tenneco Oil Company

3. ADDRESS OF OPERATOR  
720 S. Colorado Blvd., Denver, CO 80222

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)  
AT SURFACE: 1190'FSL & 1190'FEL, Unit P  
AT TOP PROD. INTERVAL:  
AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

TEST WATER SHUT-OFF ☐  
FRACTURE TREAT ☐  
SHOOT OR ACIDIZE ☐  
REPAIR WELL ☐  
PULL OR ALTER CASING ☐  
MULTIPLE COMPLETE ☐  
CHANGE ZONES ☐  
ABANDON\* ☒  
(other) ☐

SUBSEQUENT REPORT OF:

☐  
☐  
☐  
☐  
☐  
☐  
☐  
☐  
☐  
☐

5. LEASE  
NM 09717  
6. IF INDIAN, ALLOTTEE OR TRIBE NAME  
7. UNIT AGREEMENT NAME  
8. FARM OR LEASE NAME  
Florance  
9. WELL NO.  
103  
10. FIELD OR WILDCAT NAME  
Blanco Pictured Cliffs  
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA  
Sec. 6, T30N, R8W  
12. COUNTY OR PARISH  
San Juan  
13. STATE  
New Mexico  
14. API NO.  
15. ELEVATIONS (SHOW DF, KDB, AND WD)  
5942'GR

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

We propose to plug and abandon via the following procedure:

- 1) MIRIPU
- 2) RIH w/1 1/4" I J tbg to 2650'
- 3) Mix and pump 17 bbls 50/50 poz mix slurry w/6% Bentonite gel down tbg
- 4) Close BOP & pump cement dn tbg to 500 psi squeeze pressure (approx 13.5 bbl/50 Sx squeeze)
- 5) Release pressure & pump 5.0 bbls water dn tbg for displacement
- 6) POOH w/tbg-laying down
- 7) Cut off wellhead 1' below grade & install P&A marker. Clean & restore location in accordance with USGS requirements.

Subsurface Safety Valve (Model and type)

18. I hereby certify that the foregoing is true and correct

SIGNED

*Carly Wether*

TITLE Admin. Supervisor

DATE

11/19/79

APPROVED BY  
CONDITIONS OF APPROVAL, IF ANY:

NMOCC

\*See Instructions on Reverse Side

APPROVED

NOV 30 1979

JAMES F. SIMS

DISTRICT OIL & GAS SUPERVISOR

