

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

Use not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331 for such proposals.

1. oil well ☐ gas well ☒ other ☐
2. NAME OF OPERATOR
El Paso Natural Gas Company
3. ADDRESS OF OPERATOR
P. O. Box 990, Farmington, N. M. 87401
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)
AT SURFACE: 990' INL, T13' VEL, Sec. 31, T32N
AT TOP PROD. INTERVAL: P5W Same
AT TOTAL DEPTH: Same
15. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:	SUBSEQUENT REPORT OF:
TEST WATER SHUT OFF	☐
FRACURE TRIAL	☐
SHOOT OR ACIDIZE	☐
REPAIR WELL	☐
PULL OR ALTER CASING	☐
MULTIPLE COMPLETE	☐
CHANGE ZONE	☐
ABANDON	☒
(other)	☐

5. LEASE
ST 080657
6. BUREAU, AGENCY, OR FIELD NAME
7. WELL ACRONYM NAME
San Juan 32-5 Unit
8. FARM OR PLAT NAME
San Juan 32-5 Unit
9. WELL NO.
0 (1D)
10. FIELD OR WILDCAT NAME
Blanco Mesa Verde & Basin Dakota
11. SEC. T. R. M. OR BLM ALLOTMENT OR AREA
Sec. 31, T32N, R5W, N.M.P.M.
12. COUNTY OF PARISH 13. STATE
Rio Arriba New Mexico
14. APN
15. ELEVATIONS (SHOW DEPTH AND VERT. DISTANCE)
6656' GL, 6666' D.F.
T.D. 8309', PRD 8334'

(NOTE: Report results of multiple completion tests on Form 9-331)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give estimated date of starting any proposed work. If well is directionally drilled, give full details location and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Circulate Mesa Verde side of well and run 1 1/4" tubing.
2. Pull 2 1/16" tbg. and seal assembly from pkr. and sting back in. Pressure displace cement plug down 2 1/16" tbg. into the Dakota formation.
3. Pull 2 1/16" tbg. to base of Mesa Verde-spot cement plug across perfs, and pressure displace part of cement through perfs.
4. Perforate squeeze holes at bases of Pictured Cliffs and Ojo Alamo formations and spot cement plugs and pressure displace part of cement through perfs.
5. If possible, shoot off 5 1/2" prod. csg. 2800' and pull csg. Spot 200' cement plug at csg. stub.
6. Place cement plug at surface. Install dry hole marker & clean location.

Subsurface Safety Valve: Manu. and Type

Set 60

18. I hereby certify that the foregoing is true and correct

SIGNED: *[Signature]* TITLE: Production Eng. DATE: 11-08-77

(This space for Federal or State office use)

APPROVED BY:
CONDITIONS OF APPROVAL, IF ANY.

TITLE

DATE

*See Instructions on Reverse Side

RECEIVED

NOV 9 1977

U. S. GEOLOGICAL SURVEY
DURANGO, COLO.