

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT--" for such proposals.

SUBMIT IN TRIPLICATE

5. Lease Designation and Serial No.

SF - 078096

6. If Indian, Allottee or Tribe Name

7. Unit or CA, Agreement Designation

8. Well Name and No.

Mudge LS 28

9. API Well No.

30-045-11575

10. Field and Pool, or Exploratory Area

Aztec Pictured Cliffs

11. County or Parish, State

San Juan New Mexico

1. Type of Well

☐ OIL
WELL

☒ GAS
WELL

☐ OTHER

2. Name of Operator

Amoco Production Company Attn: Melissa Velasco-Price

3. Address and Telephone No.

P.O. Box 3092 Houston, TX 77253

(281) 366-2548

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

890' FSL & 1650' FEL Sec 20 T31N R11W Unit O

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

TYPE OF ACTION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or
Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Amoco Production Company request permission to plug and abandon the subject wellbore as follows:

Current wellbore info: 8 5/8" 20# from surface to 348',

Current 2 7/8" from Surface to TD 2742' Cemented with 200Cubic Ft. Est top 1800'

Current 1 1/4" Coil from surface to 2610'

1. Please contact the BLM Office 48 hrs prior to starting (Steve Mason 599-6364)

2. MIRU pump truck

3. Kill well with 9# mud

4. Rig up coil unit and pull 1 1/4" Coil tubing 2606' (Keeping hole filled)

5. RU Wireline and set CIBP @ 2586' Dump bail 50' of cement to 1100'

6. Pressure test 2 7/8" casing to 500# (Very carefully)

7. Perforate 4 holes 90 degree phasing 1073'

8. Break circulation and cement to surface.

9. Cut off and install dry hole marker

10. Get with Buddy Shaw on reclamation

14. I hereby certify that the foregoing is true and correct

Signed

Melissa Velasco-Price

Title **Permitting Assistant**

Date

04/05/00

(This space for Federal or State office use)

Approved by

/s/ Charlie Beecham

Title

Team Lead, Petroleum Management

Date

APR 11 2000

Conditions of approval, if any: