

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation	8. Farm or Lease Name Maud Saunders
3. Address of Operator Box 670, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER N , 660 FEET FROM THE South LINE AND 1980 FEET FROM THE West LINE, SECTION 34 TOWNSHIP 14-S RANGE 33-E NMPM.	10. Field and Pool, or Wildcat Saunders Permian Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4207' GL	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/> Plug & Abandon

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

13,232' TD, 10,709' PB.

Set CI BP at approximately 9700'. Load hole with heavy mud. Run free point and out and recover 7" casing. Spot 100', 30 sack, cement plug No. 1 in and out of 7" casing stub. Spot 100', 40 sack, cement plug No. 2 across 9-5/8" shoe at 4197'. Cut and recover 9-5/8" casing at approximately 1500'. (If unable to recover at least 750' will not pull any 9-5/8" casing). Spot 200', 55 sack cement plug No. 3 in and out of 9-5/8" stub. Spot 100', 75 sack cement plug No. 4 across 13-3/8" shoe at 327'. Spot 40 sack cement plug No. 5 from 50' to surface. Install dry hole marker and clean location.

25 x 25 @ 1/2" x 1/2"

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

ORIGINAL SIGNED BY
C. D. BORLAND

SIGNED _____

TITLE **Area Production Manager**

DATE **January 19, 1971**

APPROVED BY _____

TITLE _____

DATE **JAN 21 1971**

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

JAN 2 1971

OIL CONSERVATION COMM.
JAN 2 1971