

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
NM-899	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT - L" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator ARCO Oil and Gas Company Division of Atlantic Richfield Company		8. Farm or Lease Name State AZ
3. Address of Operator P. O. Box 1710, Hobbs, New Mexico 88240		9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>860</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>East</u> LINE, SECTION <u>6</u> TOWNSHIP <u>19S</u> RANGE <u>35E</u> NMPM.		10. Field and Pool, or Wildcat Scharb Bone Springs
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input checked="" type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Rig up, POH w/rods & pump. Install BOP & POH w/compl assy. Drill out cmt @ 10,035' & cmt retr @ 10,050'. CO hole to CIBP @ 10,163'. Spot acid across perms @ 10,106-150'. Set trtg pkr & pump acid into perms 10,106-150'. If acid treatment unsuccessful, reperforate 10,106-150', acid treat & frac if needed. Swab test. If non-productive, cmt squeeze perms 10,106-150'. Acidize perms 9438-63', reperf if necessary, test and run compl assy. Return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Eugene L. Bush TITLE Drlg. Engr. DATE 3/31/83

APPROVED BY ORIGINAL SIGNED BY FIELD OFFICIAL TITLE OIL & GAS INSPECTOR DATE MAR 31 1983  
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED  
MAR 31 1983  
C.S.D.  
HOBBS OFFICE