

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease  
State  Fee

5. State Oil & Gas Lease No.  
B1732

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL  GAS WELL  OTHER   
7. Unit Agreement Name

2. Name of Operator  
Tenneco Oil Company  
8. Farm or Lease Name  
Sunshine State

3. Address of Operator  
1860 Lincoln, Suite 1200, Denver, Colorado 80203  
9. Well No.  
1

4. Location of Well  
UNIT LETTER C 990 FEET FROM THE North LINE AND 2209 FEET FROM  
10. Field and Pool, or Well Name  
Blinebry Penrose Skelly/Drinkard

THE West LINE, SECTION 19 TOWNSHIP 21S RANGE 31E NMPM.

15. Elevation: (Show whether DF, RT, GR, etc.)  
3532 KB  
12. County  
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK   
TEMPORARILY ABANDON   
PULL OR ALTER CASING   
OTHER Workover

PLUG AND ABANDON   
CHANGE PLANS   
REMEDIAL WORK   
COMMENCE DRILLING OPNS.   
CASING TEST AND CEMENT JOB   
OTHER   
ALTERING CASING   
PLUG AND ABANDONMENT

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- MIRUPU. Kill well. pull rods and pump.
- GIH w/bit and wash to top of model "D" pkr.
- Mill up model "D" pkr. Drive it to bottom.
- Set bkr Model "R" @ 6600'. Acidize Drinkard w/2000 gal 15% in two stages w/benzoic acid diverter.
- Set ret. BP @ + 6000'. Set bkr model "R" @ 5600'.
- Acidize Blinebry w/2000 gal 15% in 1000 gal stages w/benzoic acid diverter between stages.
- Raise BP to 3900'.
- Perforate Grayburg 3719 - 3855 + 14 spots w/2 JSPF
- Set Model R @ + 3700 and acidize Grayburg w/3000 gal acid in 3 stages w/benzoic acid diverter after each stage.
- Run tbg., pump and rods to 6710.
- Swab back acid after each job.
- Clean up area.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Production Clerk DATE 12/23/75

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: