

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator BTA Oil Producers		8. Farm or Lease Name Hugo 693 Ltd.
3. Address of Operator 104 S. Pecos Midland, Texas 79701		9. Well No. /
4. Location of Well UNIT LETTER <u>D</u> <u>660</u> FEET FROM THE <u>North</u> LINE AND <u>660</u> FEET FROM THE <u>West</u> LINE, SECTION <u>15</u> TOWNSHIP <u>9-S</u> RANGE <u>35-E</u> NMPM.		10. Field and Pool, or Wildcat Vada-Penn
15. Elevation (Show whether DF, RT, GR, etc.) 4163' GL		12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Proposed Procedure:

Call NMOCC, Hobbs, (505/393-6161) 24 hrs. advance. Hole to be filled w/mud laden fluid.

1. Spot 35 sx cmt through tbq. @ 9850'. Cut 2-7/8" tbq. @ free point.
2. Set CIBP above 2-7/8" tbq. stub w/6 sx cmt on top. WOC 12 hrs.
3. Cut & pull 5-1/2" csg. Set 50 sx cmt @ stub; 50 sx cmt @ 5502' (Glorietta); 50 sx cmt @ 4067'. (Base intermediate)
4. Cut & pull 8-5/8" csg. Set 50 sx cmt on 8-5/8" stub; 50 sx cmt @ 375' (Base surface); 10 sx @ surface.
5. Install dry hole marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Janis Jones TITLE Production Clerk DATE 7-25-73

APPROVED BY Joe D. Ramey TITLE Dist. I, Supv. DATE Jul 27 1973

CONDITIONS OF APPROVAL, IF ANY: