

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

N.M. Oil Corp
1625 N. French Dr
Hobbs, NM 88240

FORM APPROVED
Bureau No. 1004-0135
Expires: March 31, 1993
Lease Designation and Serial No.
NM0202771A
Indian, Allottee or Tribe Name

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Novy Oil & Gas, Inc.

3. Address and Telephone No.

125 N. MARKET ST., SUITE 1230, WICHITA, KS 67202 (316) 265-4651

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit Letter "G" 1980' FNL & 1830' FEL, SW NE Sec. 1-9S-34E

7. If Unit or CA, Agreement Designation

NM 061P3587C427

8. Well Name and No.

Government C Com #1

9. API Well No.

30-025-23737

10. Field and Pool, or Exploratory Area

Vada Penn

11. County or Parish, State

Lea Co., NM

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☐ Abandonment
☒ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other _____
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work)*

- (1) Move in and rig up unit.
- (2) Release packer & pull 3 jts. tubing. Reset packer @ 8900'.
- (3) Rig up Halliburton & cement squeeze Abo perms from 9010-9020' w/250 sacks to 3500#.
- (4) Pull out of hole with tubing & packer.
- (5) Pick up 4 3/4" bit, six collars and TIH on tubing.
- (6) Drill out cement. Test squeeze to 1500#.
- (7) Continue in hole & drill bridge plug. Pull out of hole with bit & collars.
- (8) Pick up overshot, jars, bumper sub, drill collars and trip in hole.
- (9) Fish out 1 jt. 2 3/8" tubing and tubing anchor.
- (10) Clean out to PBTD @ 9758'.
- (11) Run production equipment, tubing and rods. Put on pump. Pump Bouch "C" perms.

Anticipate work to start April 1, 2001.

14. I hereby certify that the foregoing is true and correct

Signed

Title PRESIDENT

Date

2/27/01

(This space for Federal or State office use)

Approved by

Title

PETROLEUM ENGINEER

Date

MAR 09 2001

Conditions of approval, if any

(ORIG. SGD.) LES BABYAK

Title 18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.

*See Instruction on Reverse Side