

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-30748
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. V-2722
7. Lease Name or Unit Agreement Name Remuda State Unit
8. Well No. 1
9. Pool name or Wildcat Flying M San Andres
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 4202' GR

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	2. Name of Operator YATES PETROLEUM CORPORATION
3. Address of Operator 105 South 4th St., Artesia, NM 88210	4. Well Location Unit Letter H : 1980 Feet From The North Line and 660 Feet From The East Line Section 8 Township 10S Range 33E NMPM Lea County
11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Propose to plug and abandon well as follows: NOTIFY OCD (393-6161) 24 HOURS PRIOR TO COMMENCING PLUGGING OPERATIONS.

1. Pull rods, pump and tubing.
2. Run 2-3/8" tubing to TD. Load hole with 10#/gallon brine containing 25#/bbl salt gel.
3. Set a 25 sack Class "C" 2% CaCl2 plug from 4637-4287'. Pull tubing to 3500' and circulate hole clean.
4. WOC 4 hours and tag plug.
5. Run casing spear and determine casing free point from casing stretch. Cut off casing with cutter at free point and pull casing.
6. Spot a 25 sack Class "C" plug from 3857-3607' (8-5/8" shoe).
7. Spot a minimum of 25 sacks Class "C" plug from 50' below 5-1/2" casing stub to 50' above stub.
8. Spot a 27 sack Class "C" plug from 435-335' (13-3/8" shoe).
9. Spot 27 sacks Class "C" plug from 100' - surface. Install regulation abandonment marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Rusty Klein TITLE Production Clerk DATE August 3, 1993
TYPE OR PRINT NAME Rusty Klein TELEPHONE NO. 505/748-1471

(This space for State Use)

Signed by
Paul Kautz
Geologist

APPROVED BY _____ TITLE _____ DATE AUG 06 1993

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED