

NO. OF COPIES RECEIVED		
DISTRIBUTION		
INTAKE		
LE		
S.G.S.		
AND OFFICE		
OPERATOR		

HOBBS OFFICE O. C. C.
NEW MEXICO OIL CONSERVATION COMMISSION
 FEB 15 9 56 AM '67

Form C-103
 Supersedes Old
 C-102 and C-103
 Effective 1-1-65

5a. Indicate Type of Lease State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.
7. Unit Agreement Name
8. Farm or Lease Name H.R. Fields
9. Well No. 1
10. Field and Pool, or Wildcat Gladiola Wolfcamp
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE "APPLICATION FOR PERMIT..." (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL GAS WELL OTHER

2. Name of Operator
Sinclair Oil & Gas Company

3. Address of Operator
P.O. Box 1920, Hobbs, New Mexico

4. Location of Well
 UNIT LETTER A 330 FEET FROM THE North LINE AND 330 FEET FROM
 THE East LINE, SECTION 25 TOWNSHIP 12S RANGE 37E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

9624' PBTD 13-3/8" csg set @ 300' - cement circulated.
 10-3/4" csg set at 660' - cement circulated.
 7-5/8" csg set at 4507' - cement circulated.
 5-1/2" csg set at 9654' w/300 sacks cement.

PROPOSE TO PLUG AND ABANDON WELL AS FOLLOWS:
 Cover perforations 9512-9547 w/cement - OR - set CIBP at apprx. 9500' w/2 sks cement on top CIBP. Cut & pull 5-1/2" csg. Set 25 sk cement plug in top of 5-1/2" csg stub. If top of 5-1/2" stub is below top of Glorieta @ 5868, then set 25 sk cement plug across top of Glorieta Zone. Set 25 sk cement plug in base of 7-5/8" csg at 4507. Set 10 sack cement plug in top of 13-3/8" csg w/regulation plugged & abandoned marked installed - clean & level location. (Note - in event any 7-5/8" csg is cut & pulled - set 25 sk cement plug in top of 7-5/8" stub, 25 sk plug at base of salt @ 3120 unless 7" stub is above this point, 25 sk plug at top of salt @ 3000 unless 7" stub is above this point, and 25 sack plug in base of 10-3/4" csg unless 7" stub is above this point.)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Superintendent DATE 02-14-67

APPROVED BY _____ TITLE _____ DATE _____

NO MODIFICATIONS BY APPROVAL, IF ANY