

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- <b>Plug and Abandon</b>		7. Unit Agreement Name
2. Name of Operator <b>Sunray DX Oil Company</b>		8. Farm or Lease Name <b>G. T. Hall</b>
3. Address of Operator <b>P. O. Box 1416 - Roswell, New Mexico</b>		9. Well No. <b>1</b>
4. Location of Well UNIT LETTER <b>L</b> <b>660</b> FEET FROM THE <b>West</b> LINE AND <b>1980</b> FEET FROM THE <b>South</b> LINE, SECTION <b>8</b> TOWNSHIP <b>12-S</b> RANGE <b>38-E</b> NMPM.		10. Field and Pool, or Wildcat <b>Gladiola Devonian</b>
15. Elevation (Show whether DF, RT, GR, etc.) <b>3880 DF</b>		12. County <b>Lea</b>

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in workover rig.
2. Squeeze Dev. perms (12004 - 12014) w/50 sxs reg. cmt w/12.5# Gilsonite/sx in last 25 sxs.
3. Cut off 5-1/2" csg as deep as possible.
4. Lay 25 sxs plugs @ following:
  - 10735 - 10660 across 5-1/2 stub (Est)
  - 9075 - 9000 (T. Wlfc.)
  - 7175 - 7100 (T. Tubbs)
  - 5925 - 5850 (T. Glor.)
  - 4555 - 4480 Across Intermediate
5. Lay 10 sx plug at surface and install dry hole marker.
6. Clear and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED John Hastings John Hastings TITLE District Engineer DATE 11-28-67

APPROVED BY [Signature] TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: