

UNIT STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE
(Other instructions on
reverse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM 14931

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Tonto Federal

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Lusk, Bone Springs, &
Wolfcamp, East11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

27-19S-32E

14. PERMIT NO.

Blanket

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

RKB 3606, GR 3588

12. COUNTY OR PARISH

Lea

13. STATE

NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

☐
☐
☐
☐

PULL OR ALTER CASING

☐
☐
☒
☐

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

☐
☐
☐

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

☐
☐
☐
☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. MIRU. Pull rods & Pump. Install BOP. Pull Tubing.
 2. RIG w/dump bailer to 10500' and spot 35' Class H Plug on CIBP. POH.
 3. Run CIBP on Wireline to - 10000'. RIH w/Dump Bailer and spot 35' plug on top of CIBP.
 4. Circ. and load hole w/9.5# mud laden fluid
 5. P.U. 5 1/2" csg, run freepoint. Shoot and pull 5 1/2". (EST. 6000').
 6. Run Tbg. and spot 30 Sx Cmt. Plug from 50' inside 5 1/2" stub to 50' Outside.
 7. Spot 40 Sx across 9 5/8" casing shoe 4600-4475'.
 8. Spot 35 Sx plug 2650-2550. Spot 35 Sx Plug 950-1050'.
 9. Spot 20 Sx Cmt Plug @ surface. Cut off wellhead, weld on steel plate and reset marker.
 10. Clean Up Lease.
- Estimated starting date of plugging operation: 2-1-78.

APPROVED FOR
CONDITIONS OF APPROVAL

18. I hereby certify that the foregoing is true and correct

SIGNED

Ben Harry

TITLE Office Assistant

DATE 1-11-78


(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side



U. S. GEOLOGICAL SURVEY
P. O. Box 1157
Hobbs, New Mexico 88240

Re: Permanent Abandonment

Well: 1 Tonto Federal

CONDITIONS OF APPROVAL

1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases".
2. The Hobbs office (telephone (505) 393-3612) is to be notified in sufficient time for a representative to witness all plugging operations.
3. Blowout prevention equipment is required.
4. In addition to normal filling of pits and cleanup of location, additional surface restoration work may be required, i.e. ripping of pad and/or access road, reseeding, etc. We have asked the Bureau of Land Management for the surface restoration requirements for this well and we should be able to furnish you these requirements within 30 days. After plugging the well and before making final clean-up, you should contact this office unless you have already been advised as to what additional surface restoration work is required.
5. At step 6, cement plug at stub of 5½" casing should be 50 sacks instead of 30.
6. Plug across shoe of 9-5/8" casing must be tagged to assure it is in place.