

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>	
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Cleverock Ped Co State	
9. Well No. #1	
10. Field and Pool, or Wildcat East Lusk Wolf Camp	
12. County Lea	

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER- 2. Name of Operator Petroleum Development Corp. 3. Address of Operator 9720 Candelaria N.E., Albuquerque, New Mexico 4. Location of Well UNIT LETTER <u>I</u> , <u>660</u> FEET FROM THE <u>East</u> LINE AND <u>2030</u> FEET FROM THE <u>South</u> LINE, SECTION <u>16</u> TOWNSHIP <u>T 19 S</u> RANGE <u>R 32 E</u> NMPM.	15. Elevation (Show whether DF, RT, GR, etc.)
---	---

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐  
OTHER ☐

PLUG AND ABANDON ☒  
CHANGE PLANS ☐  
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐  
ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Move in rig. Blow well down.
2. Pull production equipment from well.
3. RIH with CIBP on wire line and set at 9700', using dump bailer. Cap plug with 35' cement
4. RIH with tubing and circulate with mud laden brine.
5. POH. Weld on lift sub, stretch casing.
6. Cut at free point. Pull out of hole with 5½" casing.
7. RIH with tubing to 5½" casing stub and spot 45 sax plug in and out of stub.
8. PUH with tubing to 4207 and spot a 55 sax plug. Cross 8-5/8 shoe. WOC & tag.
9. POH and perforate 8-5/8 casing at the salt sec. and break down and squeeze perforations with 75 sax using wiper plug to displace with. WOC.
10. Spot a 45 sax plug 425 to 325 ft.
11. Cut off well head and place 10 sax surf. plug and install dry hole marker

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Jerry Sexton TITLE Agent DATE 11-27-78

APPROVED BY Jerry Sexton TITLE Dist. 1, Sup. DATE NOV 27 1978

CONDITIONS OF APPROVAL, IF ANY:

Ev since 5/27/79