

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> For <input type="checkbox"/>	
5. State Oil & Gas Lease No. E-5841	
7. Unit Agreement Name West Pearl Queen Unit	
8. Farm or Lease Name	
9. Well No. 141	
10. Field and Pool, or Wildcat Pearl Queen	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL GAS WELL OTHER-

2. Name of Operator
Gulf Oil Corporation

3. Address of Operator
P. O. Box 670, Hobbs, NM 88240

4. Location of Well
UNIT LETTER C, 660 FEET FROM THE North LINE AND 1980 FEET FROM THE West LINE, SECTION 33 TOWNSHIP 19S RANGE 35E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
3714' GL

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Enter bottom half of parted 4½" casing at 760'.**Tag sand on top of RBP at 4700'. Circulate hole with abandonment mud. GIH with open-ended tubing. Spot 20 sacks Class "C" neat cement on top of RBP. Spot 100' Class "C" neat plug 2750'-2650'. Spot 160' Class "C" neat plug across parted casing 810'-550'. Spot 10 sack surface plug. Install dry hole marker. Clean and clear location.

~~**If unable to enter bottom half of parted 4½" casing at 760': Circulate hole with abandonment mud. GIH with open-ended tubing. Spot 210' Class "C" neat plug 760'-550'. Spot 10 sack surface plug. Install dry hole marker. Clean and clear location.~~

THE COMMISSIONER HAS BEEN ADVISED BY NOTICE DATED 24 APRIL 1983 OF THE CLOSING OF THE OFFICE OF THE COMMISSIONER FOR THE C-103 TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED RD Pitre TITLE Area Engineer DATE 4-29-83

APPROVED BY ORIGINAL SIGNED BY JERRY SEXTON TITLE DISTRICT SUPERVISOR DATE MAY 3 1983
CONDITIONS OF APPROVAL, IF ANY: