

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88241-1980

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

2040 Pacheco St.
Santa Fe, NM 87505

WELL API NO.	30-025-05763
5. Indicate Type of Lease	STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.	
7. Lease Name or Unit Agreement Name	North Monument G/SA Unit Blk. 15
8. Well No.	9
9. Pool name or Wildcat	Eunice Monument G/SA

1. Type of Well: OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER Water Injection Well	2. Name of Operator Amerada Hess Corporation
3. Address of Operator P. O. Box 840, Seminole, Texas 79360-0840	4. Well Location Unit Letter I : 1980 Feet From The South Line and 660 Feet From The East Line Section 31 Township 19S Range R37E NMPM Lea County
10. Elevation (Show whether DF, RKB, RT, GR, etc.)	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Plan to MIRU pulling unit. Remove wellhead, install BOP & TOH w/tbg. & pkr. TIH w/RBP set at 1150'. Dump sand on top RBP. Shoot squeeze holes at 1135'. Est. circ. through squeeze holes. Run Dye Caliper to determine cement volume to circ. to surface. Cement Squeeze holes at 1135'. WOC. Drill out cement & press. to 500#. TOH w/RBP. TIH w/CIBP set at 3720'. Run 4" 11.6#/Ft. flush jt. liner to 3719'. Cement liner to surface. Drill out cement & test liner to 1000#. Drill out CIBP & tag TD. TIH w/pkr. & tbg. Circ. pkr. fluid. Set pkr. & perform chart press. test. Continue injecting water.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

Roy L. Wheeler, Jr.

TITLE Bus. Svc. Spec. II

DATE 10-3-2000

TYPE OR PRINT NAME Roy L. Wheeler, Jr.

TELEPHONE NO. 915 758-6700

(This space for State Use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

3
2

RECEIVED
HODS
000