

Submit 3 Copies
to Appropriate
District Office

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.
3002505788

5. Indicate Type of Lease
STATE FEE

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE 'APPLICATION FOR PERMIT' (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

ARCO CRUTCHFIELD

1. Type of Well:
OIL WELL GAS WELL OTHER

8. Well No.
1

2. Name of Operator
AMERADA HESS CORPORATION *(Atlantic Richfield Co)*

9. Pool name or Wildcat
Element 4-SR-DW

3. Address of Operator
POST OFFICE DRAWER D, MONUMENT, NEW MEXICO 88265

4. Well Location
Unit Letter **I** : **1980** Feet From The **SOUTH** Line and **660** Feet From The **EAST** Line

Section **32** Township **19S** Range **37E** NMPM **LEA** County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <u>RE-PLUG AND ABANDON.</u> <input checked="" type="checkbox"/>		OTHER: _____ <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Move in and rig up pulling unit. Cut off P & A marker. TIH with tubing, drill collars and bit. Drill out surface plug and clean out to 1,500'. TOH with tubing, drill collars and bit. Rig up Schlumberger. Perforate 1,447'-1,451', with 1 JSPF. Rig down Schlumberger. TIH with packer on tubing and establish rate and pressure. TOH with packer. Rig up cementers. TIH with cement retainer on tubing to 1,274'. Clear retainer. Set retainer. Mix and pump 200 sacks of Class "C" cement. Attempt to circulate cement then obtain squeeze. Pull out of retainer and cap with 100' cement; TOH with tubing and spot 50 foot plug at surface. Weld on P & A marker. Rig down and move out pulling unit. Clean and clear location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Terry L. Harvey TITLE Senior Staff Assistant DATE 03-08-94

TYPE OR PRINT NAME Terry L. Harvey TELEPHONE NO. 393-2144

(This space for State Use)

APPROVED BY _____ TITLE Orig. Signed by Paul Kautz Geologist DATE APR 04 1994

CONDITIONS OF APPROVAL, IF ANY:

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

THE COMMISSION MUST BE NOTIFIED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103 TO BE APPROVED.

RECEIVED

MAR 24 1994

HOODS
OFFICE