

STATE OF NEW MEXICO
OIL AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
ALBUQUERQUE	
EL PASO	
LAND OFFICE	
REGISTRAR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. E-1638
7. Unit Agreement Name W. Pearl Queen Unit
8. Farm or Lease Name
9. Well No. 157
10. Field and Pool, or Wildcat East Pearl 7 Rivers
12. County Lea

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT - II" (FORM C-101) FOR SUCH PROPOSALS.

<input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-
Operator Gulf Oil Corporation
Address of Operator P. O. Box 670, Hobbs, NM 88240
Name of Well I 2310 FEET FROM THE South LINE AND 990 FEET FROM East LINE, SECTION 31 TOWNSHIP 19S RANGE 35E N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
3720' GL

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PARLILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOBS <input type="checkbox"/>	
Perf, Acz & Frac E. Pearl 7 Rivers <input checked="" type="checkbox"/>		OTHER <input type="checkbox"/>	

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Perf 4023-25', 4090-92', 4124-26', 4168-70', 4238-40' with (2) 1/2" JHPF (20 holes). Spot approx 12 bbl 15% NEFE double inhibited HCL 4240'-3975'; reverse out excess acid. Put spot acid away using 2% KCL water; swab and test. Acidize with 3500 gals 15% NEFE slick HCL and (24) 7/8" RCNB's; flush with 2% KCL water with surfactants. Foam frac with 40,000 gals 70 quality foam pad, (16) 7/8" RCNB's & possibly 1200# Gulfmix rock salt. Flush to perfs with 70 quality foam. Swab and test.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED RD Pate TITLE Area Engineer DATE 11-7-80
Orig. Signed by Jerry Seaton
Checked by Mike L. Suter