DISTRIBUTION	ALE III	HENICO OIL CONCE	DVATION COMMISSION		Frem C. 101		
DISTRIBUTION		NEW MEXICO OIL CONSERVATION COMMISSION 3-NMOCC-HOBBS 1-MYM, ENGR.			Form C-101 Revised 1-1-65	•	
NTA FE		ARRAK-TULSA	<u>*</u>		5A. Indicate	Type of Lease	
S.G.S.		RY-MIDLAND	1-BH-FLD CL	к	STATE	PEE XX	
AND OFFICE					5. State Oil 6	Gas Lease No.	
PERATOR							
					MM		
	FOR PERMIT TO	DRILL, DEEPEN,	OR PLUG BACK				
Type of Work					7. Unit Agree	ement Name	
DRILL [DEEPEN 🔲	PLUG E	ACKXX	8. Farm or Le	ago Nama	
Type of Well	•		SINGLE MULTIPLE		BAKER "B"		
OIL GAS WELL Game of Operator	O/HER		ZONE	ZONE L.	9. Well No.		
ETTY OIL COMPANY	,			•	10		
Arritress of Operator					_ :	i Pool, or Wildeat	
P. O. Box 730, HOBBS, NEW MEXICO 88240						SAN ANDRES	
			COMMI		777777		
LOCATION OF WELL UNIT LETTER	Lo	CATED 2310 1	FEET FROM THE SOUTH	LINE			
3.650	DA CO	10	ຸ ງງ ຕ ງໆ	· · · · · ·			
1650 FEET FROM T	HE EAST	NE OF SEC. 10	TWP. 22-S RGE. 37	TTTTTT	12. County	~~} }}};	
					LEA		
44444444	+++++++++	+++++++	4444444	++++	111111	://///////////////////////////////////	
				[[]]]]			
44444444	<i>HHHH</i>	444444	19. Proposed Depth 1	9A. Formation	7777777	20, Hotary or C.T.	
			4850'	SAN AND	279		
Lievations (Show whether DF, I	RT. etc.) 21A. Kind	6 Status Plua, Bond	21B. Drilling Contractor			Date Work will start	
150' D.F.		_	PULLING UNIT		3-79		
IJO D.E.			- COMMING ONLI		l	· · · · · · · · · · · · · · · · · · ·	
	1	PROPOSED CASING AN	D CEMENT PROGRAM				
SIZE OF HOLE	SIZE OF CASING	WEIGHT PER FOOT	T SETTING DEPTH	SACKS OF	CEMENT	EST. TOP	
7"	13-3/8"	44.5#	158'	16	50		
2-1/4"	9-5/8"	36#	2805'	100	00		
3-1/4"	7"	20#	5210'	3:	50		
•	•	1		t	•		
Dia							
. Rig up pulling u	. 7 7 4			. 0 5065	') Cifc	late Clean Flu	
. Install BOP & pu	ill tubing.	50001 /max of	Daddook Darf is		/. CILC		
. Install BOP & pu . Clean out 7" cas	sing to below			. e 3003		izace erean ira	
. Install BOP & pu . Clean out 7" cas . Run GR/N with co	sing to below a llar locator :			, e 3003		itate otean 11a	
Install BOP & pu Clean out 7" cas Run GR/N with co Pick up & set CI	sing to below blar locator : IBP @ 4850'+.	from 5000' to s	surface.			itace cream 110	
Install BOP & put Clean out 7" cas Run GR/N with co Pick up & set CI Run Cement Bond	sing to below bllar locator: (BP @ 4850'+. Log 4850' to	from 5000' to s 2500' or where	surface. the cement top i	ls.	5" hole s		
Install BOP & put. Clean out 7" cas. Run GR/N with co. Pick up & set CI. Run Cement Bond. If cement O:K, p	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP	from 5000' to s 2500' or where	surface. the cement top i	ls.	5" hole s		
Install BOP & put Clean out 7" cas Run GR/N with co Pick up & set CI Run Cement Bond If cement O:K, put Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & pu . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & put. Clean out 7" cas. Run GR/N with co. Pick up & set CI. Run Cement Bond. If cement O:K, p. Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & put. Clean out 7" cas. Run GR/N with co. Pick up & set CI. Run Cement Bond. If cement O:K, p. Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & put. Clean out 7" cas. Run GR/N with co. Pick up & set CI. Run Cement Bond. If cement O:K, p. Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & put . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
. Install BOP & put . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe	sing to below blar locator: (BP @ 4850'+. Log 4850' to berforate 1 SP. erfs.	from 5000' to s 2500' or where F using 5" End	surface. the cement top i	ls.	5" hole s		
Install BOP & put Clean out 7" cas Run GR/N with co Pick up & set CI Run Cement Bond If cement O:K, p Swab test new pe If necessary, ac	sing to below blar locator: Dlar locator: DBP @ 4850'±. Log 4850' to berforate 1 SP: Derfs. Deriver w/5000	from 5000' to s 2500' or where F using 5" End gals. 15% HCl.	the cement top in Loaded carrier of	.s. gun, 0.6		size in concret	
Install BOP & put Clean out 7" cas Run GR/N with co Pick up & set CI Run Cement Bond If cement O:K, p Swab test new pe If necessary, ac	sing to below blar locator: Dlar locator: DBP @ 4850'±. Log 4850' to berforate 1 SP: Derfs. Deriver w/5000	from 5000' to s 2500' or where F using 5" End gals. 15% HCl.	the cement top in Loaded carrier of	.s. gun, 0.6		size in concret	
. Install BOP & pu . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe . If necessary, ac	sing to below blar locator: IBP @ 4850'+. Log 4850' to berforate 1 SP: cidize w/5000 of the series of the serie	From 5000' to s 2500' or where F using 5" End gals. 15% HCl.	the cement top in Loaded carrier of	.s. gun, 0.6		size in concret	
. Install BOP & put . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe	sing to below blar locator: IBP @ 4850'+. Log 4850' to berforate 1 SP: cidize w/5000 of the series of the serie	From 5000' to s 2500' or where F using 5" End gals. 15% HCl.	the cement top in Loaded carrier of the cement top in Loaded carrier of the control of the contr	run, 0.6	ODUCTIVE ZONE	size in concret	
. Install BOP & pu . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe . If necessary, ac	sing to below blar locator: IBP @ 4850'+. Log 4850' to berforate 1 SP: cidize w/5000 of the series of the serie	From 5000' to s 2500' or where F using 5" End gals. 15% HCl.	the cement top in Loaded carrier of	run, 0.6	ODUCTIVE ZONE	size in concret	
. Install BOP & pu . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe . If necessary, ac ABOVE SPACE DESCRIBE PRO Treby certify that the information med	opposed Program: IF any on above is true and cor	From 5000' to s 2500' or where F using 5" End gals. 15% HCl. PROPOSAL IS TO DEEPEN AREA SL Title	the cement top in Loaded carrier of the price back, give data of the computed grand belief.	run, 0.6	ODUCTIVE ZONE	size in concret	
. Install BOP & put. Clean out 7" cas. Run GR/N with co. Pick up & set CI. Run Cement Bond. If cement O:K, p. Swab test new pet. If necessary, accepted to the content of t	opposed Program: IF any on above is true and cor	From 5000' to s 2500' or where F using 5" End gals. 15% HCl. PROPOSAL IS TO DEEPEN AREA SL Title	the cement top in Loaded carrier of the price back, give data of the computed grand belief.	run, 0.6	ODUCTIVE ZONE Date Jani	AND PROPOSED NEW PROD	
. Install BOP & pu . Clean out 7" cas . Run GR/N with co . Pick up & set CI . Run Cement Bond . If cement O:K, p . Swab test new pe . If necessary, ac ABOVE SPACE DESCRIBE PRO Treby certify that the information med	opposed Program: IF any on above is true and cor	From 5000' to s 2500' or where F using 5" End gals. 15% HCl. PROPOSAL IS TO DEEPEN AREA SL Title	the cement top in Loaded carrier of the cement top in Loaded carrier of the control of the contr	run, 0.6	ODUCTIVE ZONE Date Jani	size in concret	