
			1						
	HOBBS OCD DEC 21 2012								
orm 3160-5	B10					FORM APPROVED			
pril 2004)		UNITED STATES		OCD Hobbs		OM B No. 1004-0			
	DECAN	DEPARTMENT OF THE I			r	Expires: March 31	, 2007		
	В	UREAU OF LAND MANA	AGEMENT		5. Lease Seria				
	RECEIVED	4				NM 867			
	CONDIC	I NOTIOLO AND RELO				6. If Indian, Allottee or Tribe Name			
		is form for proposals to	1		•				
		ell Use Form 3160-3 (Al			7. If Unit of (	CA / Agreement, Na	ne and/or No.		
		PLICATE - Other instr	uctions on rever	se side.			<u> </u>		
ype of W			·                       .		8. Well Nam				
	Oil Well	Gas Well	Othe	<u>r</u>		BILBREY 33 F	EDERAL 1		
ame of C	perator	CONOCOPH	ILLIPS COMPAN	'S COMPANY		9. API Well No. <b>30-025-30781</b>			
A J J		2h Bhore Ne		ude area code )	10 Field and	10. Field and Pool, or Exploratory Area			
a. Address P.O. BOX 51810, MIDLA				<b>432-688-6943</b>		BILBREY; MORROW & ATOKA			
		or Survey Description)				r Parish, State			
	· -			. /					
	660' FNL & 1980	O'FWL, U/LC SE	EC 33 T21S R32	<u>E /</u>		LEA COUN	TY, NM		
	12. CHECK APPR	ROPRIATE BOX(ES) T	O INDICATE NA	TURE OF NOTIC	CE, REPORT, OR (	OTHER DATA	· .		
TYPE	OF SUBMISSION			TYPE	OF ACTION				
		Acidize	Deep	)en	Production (Star	t/Resume)	Water Shut-off		
Notice o	f Intent	Alter Casing	Frac	ture Treat	Reclamation	Γ	Well Integrity		
S.1.	n t Dan a t						т с <b>,</b>		
Subsequ	ent Report	Casing Repair		Construction	Recomplete	Ĺ	Other		
Final AL	andonment Notice	Change Plans	✓ Plug	and Abandon	Temporarily Aba	andon			
I mai AU		Convert to Injec	tion 👘 🗌 Plug	Back	Water Disposal	Nater Disposal			
	MIRU. ND WH,		LD PROD RO	DS & TBG	d: Tag At	STA SPot	25 SX CM		
,	RIH WL - SET	7" CIBP @ 8,380'				•			
	Circ hole w/ M	LF. Cap BP w/ 30ş:	K H cmt	cmt		RECLAMATION PROCEDURE			
		@ 5936'- <del>5836'</del> (		ノ		ATTAC	10CN		
	Spot 40sx cmt	@ 4730'-4585' - Ta	g				INCU		
	Perf & Sqz 50s	x cmt @ 2865'-276	51 Tan / . 9	alal )			/ILV		
	Perf & Sqz 50s	•	ज्जन Tay ( / 🎜	C KILLA )					
	Dorf & Car 50c	sx cmt @ 1200'-110		( Krug)			<i>וובט</i>		
		ex cmt @ 1200'-110 ex cmt @ 375'-275'	0' - Tag - Tag	C KILL?			· .		
	Perf & Sqz 150	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su	0' - Tag - Tag Irface	( King)		SEE ATTAC	· .		
)	Perf & Sqz 150	ex cmt @ 1200'-110 ex cmt @ 375'-275'	0' - Tag - Tag Irface			SEE ATTAC	HED FOR		
)	Perf & Sqz 150	ex cmt @ 1200'-110 ex cmt @ 375'-275' lsx cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface marker				· .		
) <u>Brou</u> i	Perf & Sqz 150	ex cmt @ 1200'-110 ex cmt @ 375'-275' lsx cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface				HED FOR		
Brow	Perf & Sqz 150	x cmt @ 1200'-110 x cmt @ 375'-275' lsx cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface marker				HED FOR		
I hereby c	Perf & Sqz 150 Fill wellbore. R and (ever a certify that the following	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface marker	quired	······································	CONDITION	HED FOR		
Brow	Perf & Sqz 150 Fill wellbore. R nd (ever)	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface marker		······································		HED FOR		
I hereby of Name	Perf & Sqz 150 Fill wellbore. R and (ever a certify that the following	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A	0' - Tag - Tag Irface marker <u>Las Ker Re</u> C	quired	P&A	CONDITION	HED FOR		
Name	Perf & Sqz 150 Fill wellbore. R and (ever a certify that the following	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A $bc \neq Hole M$ g is true and correct T	0' - Tag - Tag Irface marker <u>Las Ker Re</u> C	<u>gussed</u> Title Date	P&A 10		HED FOR		
I hereby of Name	Perf & Sqz 150 Fill wellbore. R and (ever a certify that the following	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A $bc \neq Hole M$ g is true and correct T	0' - Tag - Tag Irface marker <u>Carker Re</u> ACE FOR FEDE	Title Date RAL OR STATE	P&A 10 E OFFICE USE	CONDITION TECH	HED FOR		
I hereby of Name Signature	Perf & Sqz 150 Fill wellbore. R and <u>(e.w.f.</u> certify that the following GREG BRYAN GREG BRYAN	$x \operatorname{cmt} @ 1200'-110$ $x \operatorname{cmt} @ 375'-275'$ $y x \operatorname{cmt} @ 60' to support to support$	0' - Tag - Tag Irface marker <i>(a, Ker Ac</i> ACE FOR FEDE	<u>gussed</u> Title Date	P&A 10 E OFFICE USE	CONDITION TECH	HED FOR		
I hereby of Name Signature proved by	Perf & Sqz 150 Fill wellbore. R A (evel a certify that the following GREG BRYAN GREG BRYAN approval, if any, are att	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A $b \leftarrow f d o f e M$ g is true and correct T THIS SP Cached. Approval of this no	0' - Tag - Tag Inface marker $\frac{2}{2}$	Title Date RAL OR STATE	P&A 10 E OFFICE USE	CONDITION TECH	HED FOR		
I hereby of Name Signature proved by nditions of rant or cep	Perf & Sqz 150 Fill wellbore. F and level a pertify that the following GREG BRYAN GREG BRYAN approval, if any, are att tify that the applicant h	$x \operatorname{cmt} @ 1200'-110$ $x \operatorname{cmt} @ 375'-275'$ $y x \operatorname{cmt} @ 60' to support to support$	0' - Tag - Tag Inface marker Carker Ac ACE FOR FEDE tice does not to those rights	Title Date Title SE	P&A 10 E OFFICE USE	CONDITION TECH	HED FOR		
I hereby of Name Signature proved by nditions of rant or cer he subject	Perf & Sqz 150 Fill wellbore. F and level a pertify that the following GREG BRYAN GREG BRYAN approval, if any, are att tify that the applicant h	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A Dev Hole M g is true and correct T THIS SP Cached. Approval of this no olds legal or equitable title	0' - Tag - Tag Inface marker Carker Ac ACE FOR FEDE tice does not to those rights	Title Date RAL OR STATE	P&A 10 E OFFICE USE	CONDITION TECH	HED FOR		
<b><u>Brown</u></b> I hereby of Name Signature proved by nditions of trant or cer he subject reon.	Perf & Sqz 150 Fill wellbore. For the second	ex cmt @ 1200'-110 ex cmt @ 375'-275' esx cmt @ 60' to su RDMO. Install P&A b - x A ole M g is frue and correct T THIS SP/ cached. Approval of this no olds legal or equitable title the the applicant to conduct	0' - Tag - Tag Inface marker <u>Cerker</u> <u>Ce</u> ACE FOR FEDE tice does not to those rights operatins	Title Date RAL OR STATE Title SEP	P&A 10 E OFFICE USE	CONDITION TECH /8/12	HED FOR S OF APPROV		
I hereby of Name Signature proved by inditions of trant or cer he subject reon.	Perf & Sqz 150 Fill wellbore. For the second	ex cmt @ 1200'-110 ex cmt @ 375'-275' lex cmt @ 60' to su RDMO. Install P&A Dev Hole M g is true and correct T THIS SP Cached. Approval of this no olds legal or equitable title	0' - Tag - Tag Inface marker <i>Carker Re</i> <i>Carker Re <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> </i>	Title Date RAL OR STATE Title $S \in P$ Office $C \neq D$ any person knowing	P&A 10 E OFFICE USE	CONDITION TECH /8/12	HED FOR S OF APPROV		
I hereby of Name Signature proved by inditions of trant or cer he subject reon.	Perf & Sqz 150 Fill wellbore. For the second	ex cmt @ 1200'-110 ax cmt @ 375'-275' bx cmt @ 60' to su CDMO. Install P&A	0' - Tag - Tag Inface marker <i>Carker Re</i> <i>Carker Re <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> </i>	Title Date RAL OR STATE Title $S \in P$ Office $C \neq D$ any person knowing	P&A 10 E OFFICE USE	CONDITION TECH /8/12	HED FOR S OF APPROV		
I hereby of Name Signature proved by inditions of trant or cer he subject reon.	Perf & Sqz 150 Fill wellbore. For the second	ex cmt @ 1200'-110 ax cmt @ 375'-275' bx cmt @ 60' to su CDMO. Install P&A	0' - Tag - Tag Inface marker <i>Carker Re</i> <i>Carker Re <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> </i>	Title Date RAL OR STATE Title $S \in P$ Office $C \neq D$ any person knowing	P&A 10 E OFFICE USE	CONDITION TECH /8/12	HED FOR S OF APPROV		
Name Signature oproved by inditions of mant or cer the subject ereon.	Perf & Sqz 150 Fill wellbore. For the second	ex cmt @ 1200'-110 ax cmt @ 375'-275' bx cmt @ 60' to su CDMO. Install P&A	0' - Tag - Tag Inface marker <i>Carker Re</i> <i>Carker Re <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> <i>Carker Re</i> </i>	Title Date RAL OR STATE Title $S \in P$ Office $C \neq D$ any person knowing	P&A 10 E OFFICE USE	CONDITION TECH /8/12	HED FOR S OF APPROV		

WELLBORE SKETCH

ConocoPhillips Company -- Lower 48 - Mid-Continent BU / Permian Operations



WELLBORE SKETCH ConocoPhillips Company -- Lower 48 - Mid-Continent BU / Permian Operations

r

					Date: J	une 26, 2012	
RKB @ <u>3733</u>	1						
DF @ GL @3708'	;	Subarea :	Hobbs				
		Lease & Well No					
	- P&S 150sx cmt @ 60'-3'	Legal Description	n: 660' FNL & 1980' Unit Letter C	FW , Sec. 33,	T-21-S, R-32-E		_
	17-1/2" Hole	County :	Lea	State :	New Mexic	20	_
	- P&S 50sx cmt @ 375'-275' • Tag	Field : <u>Bilbre</u> Date Spudded :	y Morrow Atoka 3/5/90	Rig Releas	ed:		
	13-3/8" 54.5# K-55 ST&C @ 1150'	API Number :	30-025-30781	The recease	<u></u>		
	Cmt'd w/ 1300 sks, circ 200 sx TOC @ Surf.	Status: TA'D			Code	# 100001	
	~ P&S 50sx cmt @ 1200'-1100' - Tag			Pro	operty Code	# 10896'	
		Stimulation His	tory:		Lbs. N	lax Ma	
		Interval Date	Туре	Gais			te Down
(\$5 ····································	P&S 50sx cmt @ 2865'-2765' - Tag						
er an er	Top of Salt @ 2815 TOC 7" Csg @ 3050' (TS)						
	1						
	12-1/4" Hole						
	9-5/8" 40# S-95, K-55 & L-80 @ 4635' Cmt'd w/ 1500 sx						
	TOC @ Surf.						
· · · · · · · · · · · · · · · · · · ·	<sup>-</sup> Spot 40sx cmt @ 4730'-4585' • Tag						
	i i i						
	–Spot 30sx cmt @ 5936'-5836'						
	<u>Cap w/ 30sx H cmt</u> CIBP @ 8380'						
╠ <sub>╋</sub> ┿┿╧╧╧╧┥╎	-						
	8480'-8495'						
	8610'-8660'						
	spot cmt, 8795'-8830' CIBP @ 8830'	spot 103 bbls 9#	mud 8800-11620'				
> <	DV Tool @ 8986'						
	8-3/4" Hole 7" 29# P-110, 26# P-110 @ 12,000'						
· · · · · · · · · · · · · · · · · · ·	Cmt 1st Stge: 400 sks						
	Cmt 2nd Stge: 1115 sks TOC @ 3050' (TS)						
	spot 45 sxs cmt. 12050'-11590'; TOC @	11,620'					
	TOL - 11674'						
	Side Treak Lines TOL 42002	Mix 75 av and Date 4					
		Mix 75 sx cmt. Rate 1 #3000 squeeze press	bbl/min. @2800# got 42 ure.	G DEIOW PKR.	Across pert's		
Win	13876-13881		•			•	
СІВ	P & whipstock @ 13,886'						
	<u>Atoka</u> 13610-12						
	13630-38 SQ- 1/26/2000						
A REAL PROPERTY AND A REAL	CIBP @13903 w/ 25' cmt on top / witnes Body of RBP @ 13904'	s by Steve Caffey					
	Morrow 13973-88 14340-45 14371-76						
	14332-34 14356-68 <u>14385-92</u>	;	Formation Tops:				
	PKr @ 13922 14494-500 PKR @ 14107	Morrow		325'	Morrow Lin		
		==14341-14505'		4680' 5886'	Morrow Cla Morrow Lo		
	2 3/8 tbg. Nipples to 14282'	:	Bone Spring	8688'	Barnett	14820	
	6-1/8" Hole 14900' 5" 18# NT-95 14900'			11766' 13158'			
PBTD: 14748'	Cmťď w/ 175 sks			13342'			
TD: 14900'	TOC @ 11674'	PBTD 14548 TD. 14600'					
							1

## BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

## Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

2. <u>Notification</u>: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.

3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.

4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.

5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10<sup>th</sup> day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

7. <u>Subsequent Plugging Reporting</u>: Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date well was plugged</u>.

8. <u>Trash</u>: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

J. Amos 3/6/11

## Requirements for ground level dry hole markers <u>Well Identification Markers</u> Conditions of Approval (COA)

The BLM Carlsbad Field Office (CFO) Conditions of Approval (COA) Requires that ground level dry hole markers be placed on well within the Lesser Prairie Chicken habitat area. The dry hole markers will be to the following specifications. The operator will construct the markers as follows:

- 1. An 8 inch X 8 inch steel plate 1/8 to 3/16 of an inch thick is to be placed on the old dry hole marker stand pipe 2 inches from ground level, in the Lesser Prairie Chicken habitat area.
- 2. Steel plate may be welded or bolted approximately 2 inches from ground level on the stand pipes. If plates are bolted to the stand pipe, the person installing the plate will be required to weld a pipe collar on the plate and place a minimum of two set screws/bolt on each collar. Aluminum data plates may be bolted with minimum ¼ inch bolt and locking nuts or self tapping fine threaded screws. A minimum of one in each corner is to be installed on each plate.
- 3. An 8 inch x 8 inch aluminum plate, which is 12 gauge or .080 sign material (1/8 inch aluminum plate may be used in place of the .080 plate) with the required information for that well stamped or engraved in a minimum 3/8 inch tall letter or number.
- 4. The following information will be stamped or engraved on the 8 inch X 8 inch aluminum plate in the following order.
  - a. First row: Operators name
  - b. Second row: Well name and number
  - c. Third row: Legal location to include <sup>1</sup>/<sub>4</sub> <sup>1</sup>/<sub>4</sub>, Section, Township, and range. If the legal location cannot be placed on one row it can be split into two rows with the <sup>1</sup>/<sub>4</sub> <sup>1</sup>/<sub>4</sub> (example: 1980 FNL 1980 FWL) being on the top row.
  - d. Fourth row: Lease Number and API number.
    - i. Example marker plate: (attached)

NMOCD Order No. R-12965 also required the operator to notify NMOCD when this type of dry hole marker is used. This can be done on the subsequent report of abandonment which is submitted to the BLM after the well is plugged. State that a ground level dry hole marker was installed as required in the COA's from the BLM.



# United States Department of the Interior

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

### Reclamation Objectives and Procedures

**Reclamation Objective:** Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- 1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation

equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.

- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

#### Jim Amos

Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Terry Gregston Environmental Protection Specialist 575-234-5958

Bobby Ballard Environmental Protection Specialist 575-234-2230

Randy Rust Natural Resource Specialist 575-234-5943

Linda Denniston Environmental Protection Specialist 575-234-5974

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Justin Frye Environmental Protection Specialist 575-234-5922 Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Doug Hoag Civil Engineering Technician 575-234-5979

Tanner Nygren Natural Resource Specialist 575-234-5975

John Fast Natural Resource Specialist 575-2345996