

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRIPlicate*
(Other instruction
verse side)

Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 069300

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

N/A

7. UNIT AGREEMENT NAME

N/A

8. FARM OR LEASE NAME

Mobil Atlantic Fed.

9. WELL NO.

2

10. FIELD AND POOL, OR WILDCAT

Allison Pass

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 10, T-9-S, R-36-E

12. COUNTY OR PARISH 13. STATE

Lee Ill. Mex.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL WELL GAS WELL OTHER

2. NAME OF OPERATOR

Blackrock Oil Company

3. ADDRESS OF OPERATOR

1701 Cotton Flat Road, Midland, Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.)
At surface

Unit S, 660 FML & 1980 FEL

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

4089 G.L.

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO :

TEST WATER SHUT-OFF

PULL OR ALTER CASING

FRACTURE TREAT

MULTIPLE COMPLETE

SHOOT OR ACIDIZE

ABANDON*

REPAIR WELL

CHANGE PLANS

(Other)

SUBSEQUENT REPORT OF :

WATER SHUT-OFF

REPAIRING WELL

FRACTURE TREATMENT

ALTERING CASING

SHOOTING OR ACIDIZING

ABANDONMENT*

(Other)

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) Set C.I. Bridge Plug @ 9739, dump 35' of cement on top.
- 2) Cut 4 1/2" casing @ 6010, spot 100' cement plug.
- 3) Pull casing to 5540, (top Glorieta @ 5490), spot 100' cement plug.
- 4) Pull casing to 4200 (@ 5/8" csg. shoe @ 4150), spot 100' cement plug, lay down all 4 1/2" casing.
- 5) Cut @ 5/8" casing @ 1400, lay down @ 5/8" casing.
- 6) Run 2 3/8" tubing to 1400, spot 100' cement plug.
- 7) Pull tubing to 450, (12 3/4" csg. shoe @ 400') spot 100' cement plug.
- 8) Lay down tubing, put 10 sx. cement plug in top of 12 3/4" casing and install marker.

See attached sheet for amendments to proposed plugging method.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE D. D. Butler, President

DATE March 11, 1974

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED AS AMENDED
APR 8 1974
ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; diameter, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site abandoned. Final inspection looking to approval of the abandonment.

APPROVED
AS AMENDED
APR 8 1968
ARTHUR R. BISHOP
DISTRICT ENGINEER

AMENDMENTS to Blackrock Oil Company's Notice of Intention to Plug well
No. 2 Mobil Atlantic Federal.

1. Set additional 25 sack cement plug inside 4½" casing in interval 7300-7600 feet, or bridge plug at 7600 feet capped with 35 feet cement.
2. Cement plugs placed through 4½" casing should be 50 sacks minimum.
3. Advise this office in sufficient time for a representative to witness setting of all plugs.