

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals, and Natural Resources Department

Form C-103
Revised 1-1-89

OIL CONSERVATION DIVISION

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

P.O. Box 2088

WELL API NO.
30-059-20035

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

Santa Fe, New Mexico 87504-2088

5. Indicate Type of Lease
STATE FEE

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name

BRAVO DOME CO2 GAS UNIT

1. Type of Well
OIL WELL GAS WELL OTHER CO2

8. Well No.
2232-281J

2. Name of Operator
AMOCO PRODUCTION COMPANY

9. Pool name or Wildcat
BRAVO DOME CO2 GAS UNIT

3. Address of Operator
P.O. Box 303, AMISTAD, NEW MEXICO 88410

4. Well Location
Unit Letter J : 1980 Feet From The South Line and 1980 Feet From The East Line
Section 28 Township 22N Range 32E NMPM Union County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)
4949 GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work)
SEE RULE 1103.

MIRUSU, kill well as necessary, NUBOP, release packer, lay down production tubing and packer, run cast iron bridge plug with wireline, set CIBP at 2,216 feet, run workstring, displace casing with mud laden fluid, pressure test casing to 500 psi, cap CIBP with 3 sacks of cement, pull workstring to 1,845 feet, spot 7 sacks of cement, pull workstring to 30 feet, fill casing with cement, NDBOP, cut off wellhead, install PXA marker, RDMOSU, cut off well anchors and clean location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNATURE DJ Holcomb TITLE Field Foreman DATE 8-18-99

TYPE OR PRINT NAME Danny J. Holcomb TELEPHONE NO. (505) 374-3010

This space for State Use)

APPROVED BY Ry Johnson TITLE DISTRICT SUPERVISOR DATE 8/23/99

CONDITIONS OF APPROVAL, IF ANY.