

FIELD REPORT FOR CEMENTING OF WELLS

OIL CONSERVATION DIVISION

Operator <u>Ray Westall</u>		Lease <u>Myrtle Myra</u>		Well # <u>5</u>	
Location of Well	Unit <u>0</u>	Section <u>9</u>	Township <u>21</u>	Range <u>27</u>	County <u>Eddy</u>
Drilling Contractor	<u>WEK</u>		Type of Equipment <u>Rotary</u>		
APPROVED CASING PROGRAM					
<i>* Witness</i>					
Size of Hole	Size of Casing	Weight Per Foot	New or Used	Depth	Sacks Cement
<u>17 1/2</u>	<u>13 3/8</u>	<u>48 #</u>		<u>500</u>	<u>750 Circ</u>
<u>12 1/4</u>	<i>* 8 5/8</i>	<u>36 #</u>		<u>2450</u>	<u>1000 "</u>
<u>7 7/8</u>	<u>5 1/2</u>	<u>17.5 #</u>		<u>5100</u>	<u>800</u>
Casing Data:					
Surface _____ joints of <u>8 5/8"</u> inch <u>24</u> # Grade <u>J-55</u>					
(Approved) (Rejected)					
Inspected by <u>M.S.</u> date <u>4-28-92</u>					
Cementing Program					
Size of hole <u>12 1/4"</u> Size of Casing <u>8 5/8"</u> Sacks cement required _____					
Type of Shoe used <u>guide</u> Float collar used <u>insert</u> Btm 3 jts welded <u>yes</u>					
TD of hole <u>2458'</u> Set <u>2458'</u> Feet of <u>8 5/8"</u> Inch <u>24</u> # Grade <u>J-55</u>					
New/used csg. @ <u>2458'</u> with <u>200 270cc</u> sacks neat cement around shoe					
+ <u>895</u> sax <u>Pacesetter Lite</u> additives <u>1/2# celoseal, 10# gilcoate, 270cc</u>					
Plug down @ <u>7:10</u> (AM) (PM) Date <u>4-29-92</u>					
Cement circulated <u>Yes</u> No. of Sacks <u>250 sx</u>					
Cemented by <u>Western Company</u> Witnessed by <u>Mike Stubblefield</u>					
Temp. Survey ran @ _____ (AM) (PM) Date _____ top cement @ _____					
Casing test @ _____ (AM) (PM) Date _____					
Method Used _____ Witnessed by _____					
Checked for shut off @ _____ (AM) (PM) Date _____					
Method used _____ Witnessed by _____					
Remarks: <u>+ 150 cc CI H 1270 thickset, 15# gilcoate, 1/2# celoseal, 270 cc</u>					
Full circulation to TD.					