

CIST

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL API NO.	30 015 27399
5. Indicate Type of Lease	STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.	LH 2460

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	RECEIVED JUL 11 1996 OIL CON. DIV.
2. Name of Operator SOUTHWEST ROYALTIES, INC. /	
3. Address of Operator P. O. BOX 11390; MIDLAND, TX 79702	7. Lease Name or Unit Agreement Name Pogo 36 State
4. Well Location Unit Letter <u>M</u> : <u>330</u> Feet From The <u>South</u> Line and <u>330</u> Feet From The <u>West</u> Line Section <u>36</u> Township <u>25S</u> Range <u>29E</u> NMPM <u>Eddy</u> County	8. Well No. 2
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3034.9' GR	9. Pool name or Wildcat N. Brushy Draw Delaware

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>		CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Notify O&G to witness tags

- 1) Set CIBP @ 3,212' & cap w/35' of cement.
- 2) Circ. ¹⁰920 ppg gelled mud from 3170' to surface.
- 3) Cut 5-1/2" @ 3150±'. TOC by CBL at 3170'. Pull 5-1/2" casing.
- 4) Spot 60 sxs 3170'-3070'. *Tag*
- 5) Spot 50 sxs 667-567'. *Tag*
- 6) Spot 25 sxs from 50' to surface.
- 7) Cut off 3' below surface, cap w/1/4" steel plate and install abandonment marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Beverly Hatfield* TITLE Regulatory Coordinator DATE 7-9-96

TYPE OR PRINT NAME _____ TELEPHONE NO. _____

(This space for State Use) **ORIGINAL SIGNED BY TIM W. GUM**
DISTRICT II SUPERVISOR

APPROVED BY _____ TITLE _____ DATE **AUG 21 1996**

CONDITIONS OF APPROVAL, IF ANY: