

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE*
(Other instructions on re-
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. <input type="checkbox"/> OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER		5. LEASE DESIGNATION AND SERIAL NO. NM 25600
2. NAME OF OPERATOR Mesa Petroleum Co.		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. Box 2009, Amarillo, Texas 79189		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2270' FNL & 1390' FEL		8. FARM OR LEASE NAME CUBA FEDERAL
14. PERMIT NO.		9. WELL NO. 9 # 1
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 6845' GR		10. FIELD AND POOL, OR WILDCAT Puerco-Mancos
BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 9, T20N, R2W
		12. COUNTY OR PARISH Sandoval
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Propose to P&A well per verbal approval received from Steve Mason 12/16/85;

1. Set CIBP @ 3500' plus 50' cement (perfs 3582'-4000');
2. Set 100' cement plug from 3265-3165' (7" casing shoe);
3. Set 100' cement plug from 2060-1960' across Mesa Verde;
4. Cut off 4 1/2" casing @ freepoint (est. 2690'), set 100' plug 50' in and out of 4 1/2" stub;
5. Set 100' cement plug from 955'-855' across Chakra;
6. Set cement plug from 400'-surface across Picture Cliffs/Fruitland/9 5/8" casing shoe;
7. Load hole with 9.2+ ppg mud between plugs;
8. Install dry hole marker.

NOTE: TOC 4 1/2" csg @ 3000'
TOC 7" csg @ surface
TOC 9 5/8" csg @ surface

RECEIVED
DEC 30 1985
OIL CON. DIV.
DIST. 3

XC: BLM-F (0+5), NMOCD-Aztec, WF, CR, Acctg, Land, Expl., Reg., Partners, GSD

18. I hereby certify that the foregoing is true and correct

SIGNED

R. E. Mathis

TITLE

Regulatory Clerk

DATE

12/16/85

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE

DATE

DEC 27 1985

*See Instructions on Reverse Side

NMOCC