(Formerly 9.		TMENT OF THE INT	ERIOR (Other Instructions of	3. LEASE DESIGNATION AND SERIAL NO.
		EAU OF LAND MANAGEM		Jic. Tribal Contract #24
(Do e	DI USE IDIS FORM FOR DEA	OTICES AND REPORT		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
ī.———	Use "APPL	CATION FOR PERMIT—" for au	of pack to a different reservoir.	Jicapilla
OIL X	CAR OTERS			7. UNIT AGREEMENT NAME
2. HAME OF				
DUGAN F	PRODUCTION CORP) <u>.</u>		Boulder
3. ADDRESS O	P OPERATOR		Application of the Contraction	9. WELL NO.
T. LUCATION O	X 420, Farming	ton, NM 87499 clearly and in accordance with a		∠ 3
Set also ap At surface		and in accordance with	DEGETVE	10. PIELS AND POOL, OR WILDCAT
3301 Ect	9 2001 5111			Boulder Mancos
330 F3[_ & 390' FWL		NOV271990	11. SAC, T., R., M., OR BLK. AND SURVEY OR ARRA
4. PERMIT NO.		1 16 Brown and 45h - had	All CON DIVE	Sec.23,T28N,R1W,NMPM
		15. BLEVATIONS (Show whether	CIR CALL DIA	12. COUNTY OR PARISH 12. STATE
L.	G 1 4		<u> </u>	Rio Arriba NM
	Check A	ppropriate Box To Indicate	Nature of Notice, Report, a	or Other Data
	NOTICE OF INTE	NTION TO:	,	sudding sures on:
PRACTURE T		PCLL OR ALTER CASING	WATER SECT-OFF	REPAIRING WELL
SHOOT OR A	CIDER	MULTIPLE COMPLETE	PRACTURE TREATMENT	ALTERING CASING
REPAIR WEL		CHANGE PLANS	SHOOTING OR ACIDISING	ABANDONMENT*
(Other)			(Other)	nits of multiple completion on Well Expletion Report and Log form.)
		/	•	tes, including estimated date of starting any tical depths for all markers and somes perti-
Plu	g to abandon /gal. mud as Perforate	by spotting Clast follows:	s "B" cement plug	tes, including estimated date of starting any tical depths for all markers and somes perti-
Plu lb.	g to abandon /gal. mud as Perforate	by spotting Clas	s "B" cement plug	tes, including estimated date of starting any tical depths for all markers and somes perti-
Plu lb.	g to abandon /gal. mud as Perforate across Gal	by spotting Class follows: 41 liner @ 4145' lup top @ 4045' w	s "B" cement plug	tes, including estimated date of starting any tical depths for all markers and somes perti- is with 9 (3945-4145)
Plu lb.	g to abandon /gal. mud as Perforate across Gal. Spot 100'; cu. ft.	by spotting Class follows: 41" liner @ 4145' lup top @ 4045' w plug across liner	s "B" cement plug . Spot 200' plug ith 39 cu. ft.	tes, including estimated date of starting any tical depths for all markers and somes perti- S with 9 (3945-4145)
Plu 1b., 1)	g to abandon /gal. mud as Perforate across Gal Spot 100' 1 cu. ft. Spot 100' 1 (2828-2928) Perforate 5	by spotting Class follows: 41 liner @ 4145' lup top @ 4045' w plug across liner plug in 7" casing with 23 cu. ft.	Spot 200' plugith 39 cu. ft. top @ 3627' (357)	tical depths for all markers and somes perti- s with 9 (3945-4145) 7-3677) with 16
Plu 1b. 1) 2)	g to abandon/gal. mud as Perforate across Gal. Spot 100' 1 Cu. ft. Spot 100' 1 (2828-2928) Perforate 5 Cu. ft. cen	by spotting Class follows: 41 liner @ 4145' lup top @ 4045' w plug across liner plug in 7" casing with 23 cu. ft.	s "B" cement plug . Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1	tical depths for all markers and somes perti- s with 9 (3945-4145) 7-3677) with 16
Plu 1b. 1) 2) 3)	g to abandon/gal. mud as Perforate across Gal. Spot 100' 1 Cu. ft. Spot 100' 1 (2828-2928) Perforate 5 Cu. ft. cen	by spotting Class follows: 4½ liner @ 4145' lup top @ 4045' w plug across liner plug in 7" casing with 23 cu. ft. 50' below surface ment down 7" to ci	s "B" cement plug . Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 irculate to surface dry hole marker.	tical depths for all markers and somes perti- s with 9 (3945-4145) 7-3677) with 16
Plu 1b. 1) 2) 3) 4)	g to abandon/gal. mud as Perforate across Gal. Spot 100' 1 cu. ft. Spot 100' 1 (2828-2928) Perforate 5 cu. ft. cem	by spotting Class follows: 4½" liner @ 4145' lup top @ 4045' w plug across liner plug in 7" casing with 23 cu. ft. 50' below surfacement down 7" to cising head and set	s "B" cement plug . Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1	tea including estimated date of starting any tical depths for all markers and some perti- is with 9 (3945-4145) 7-3677) with 16 e top @ 2878! 183' and pump 71 ce.
Plu 1b. 1) 2) 3) 4)	g to abandon/gal. mud as Perforate across Gal Spot 100' cu. ft. Spot 100' (2828-2928) Perforate 5 cu. ft. cen Cut off cas	by spotting Class follows: 4½ liner @ 4145' when the desired across liner plug across liner plug in 7" casing with 23 cu. ft. 50' below surfacement down 7" to citating head and set	Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 irculate to surface dry hole marker. SEE ATTACHED FOR INDITIONS OF ACCROVAN	tea including estimated date of starting any tical depths for all markers and some perti- s with 9 (3945-4145) 7-3677) with 16 e top @ 2878' 183' and pump 71 se.
Plu lb. 1) 2) 3) 4) 5)	g to abandon/gal. mud as Perforate across Gal. Spot 100' 1 cu. ft. Spot 100' 1 (2828-2928) Perforate 5 cu. ft. cem	by spotting Class follows: 4½ liner @ 4145' we limp top @ 4045' we plug across liner plug in 7" casing with 23 cu. ft. 50' below surfacement down 7" to citating head and set	Spot 200' plugith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 croulate to surface dry hole marker.	tea including estimated date of starting any tical depths for all markers and some perti- is with 9 (3945-4145) 7-3677) with 16 e top @ 2878! 183' and pump 71 ce.
Plu 1b. 1) 2) 3) 4) 5) hereby certify IIGNED This space for	g to abandon gal. mud as Perforate across Gal Spot 100' cu. ft. Spot 100' (2828-2928) Perforate 5 cu. ft. cem Cut off cas That the feregoing is in John Alexander Federal or State once to	by spotting Class follows: 4½" liner @ 4145' we have a 4045' we plug across liner plug in 7" casing with 23 cu. ft. 50' below surfacement down 7" to citating head and set	Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 irculate to surface dry hole marker. SEE ATTACHED FOR INDITIONS OF ACCROVAN	tical including estimated date of starting any tical depths for all markers and some pertical depths for all markers an
Plu 1b. 1) 2) 3) 4) 5) This space for approved by	g to abandon gal. mud as Perforate across Gal Spot 100' cu. ft. Spot 100' (2828-2928) Perforate 5 cu. ft. cem Cut off cas That the feregoing is in John Alexander Federal or State once to	by spotting Class follows: 4½" liner @ 4145' where the 4045'	Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 irculate to surface dry hole marker. SEE ATTACHED FOR INDITIONS OF ACCROVAN	tical including estimated date of starting any tical depths for all markers and some pertical depths for all markers an
Plu 1b. 1) 2) 3) 4) 5) hereby certify IGNED C This space for PPROVED BY	g to abandon /gal. mud as Perforate across Gal. Spot 100' cu. ft. Spot 100' (2828-2928) Perforate 5 cu. ft. cen Cut off cas that the foregoing is an John Alexander Federal or State once to	by spotting Class follows: 4½" liner @ 4145' where the 4045'	Spot 200' plug ith 39 cu. ft. top @ 3627' (357' across Mesa Verde casing (133') @ 1 rculate to surfact dry hole marker. SEE ATTACHED FOR ENDITIONS OF APPROVAL	tical depths for all markers and some pertitical depths for all markers and some pertition depths for all markers and some pertition of the second se

*See Instructions on Reverse Side

UNITED STATES DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT FARMINGTON RESOURCE AREA 1235 LA PLATA HIGHWAY FARMINGTON, NEW MEXICO 87401

Attachment to Notice of

Re: Permanent Abandonment

Intention to Abandon

Well: 3 Boulder

CONDITIONS OF APPROVAL

- 1. Plugging operations authorized are subject to the attached "General Requirements for Permanent Abandonment of Wells on Federal Leases."
- 2. Mark Kelly with the Farmington Office is to be notified at least 24 hours before the plugging operations commence (505) 326-6201.
- 3. Blowout prevention equipment is required.
- 4. The following modifications to your plugging program are to be made (when applicable):
 - a) Move meserede plug down to 3110-3010
 - b) Pert @ 805 and spot a plug from 805-530 inside a outside 7" casing (Pictured Cliffs @ 755, Fruithand @ 705 and the Ojo Hkmo @ 580)

Office Hours: 7:45 a.m. to 4:30 p.m.



GENERAL REQUIREMENTS FOR PERMANENT ABANDONMENT OF WELLS ON FEDERAL AND INDIAN LEASES FARMINGTON RESOURCE AREA

- 1. Secure prior approval either on a Sundry Notice (Form 3160-5) or verbally from the Fluids Drilling & Production Section at this office before changing the approved plugging program.
- 2. Plugging equipment used shall have separate mixing and displacement pumps and a calibrated tank to assure proper displacement of plugs. The Operator is responsible for providing all measuring devices needed to assure proper measurement of materials being used.
- 3. A proper tank or pit will be used to contain all fluids pumped from the well during plugging operations. Unattended pits are to be fenced.
- 4. All cement plugs are to be placed through tubing (or drillpipe) and shall be a minimum of 100 feet in length with 50% excess inside casing or 100% excess when plug is set in open hole or squeezed into perforations. 15.6#/gal slurry weight is to be used when using class B neat cement or when CaCl₂ is used. Use the recommended slurry weight of other type cements when they are used (Class C, Pozzolan etc.).
- 5. Any cement plugs placed when well is not full of fluid, or when well may be taking fluid, (i.e. across perfs-unless bridge plug or retainer is used, across bad csg., or fresh water formations) will be tagged (touched) after cement has set to verify proper location.
 - 5a. <u>Testing</u> The first plug below the surface plug shall generally be tested by either tagging the plug with the working pipe string, or pressuring to a minimum pump (surface) pressure of 1000 psig, with no more than a 10 percent drop during a 15-minute period (cased hole only). If the integrity of any other plug is questioned, it must be tested in the same manner. Also, any cement plug which is the only isolating medium for a fresh water interval or a zone containing a valuable mineral deposit should be tested by tagging with the drill string.
- 6. Mud must be placed between plugs. Plugging mud is to be made up with a minimum of 15 lbs/bbl of sodium bentonite, and a nonfermenting polymer.

 Minimum consistency of plugging mud must be 9 lbs/gal and with a minimum viscosity of 50 sec/qt. Fresh water is to be utilized for mixing mud.
- 7. Following the placement of a cement plug, the withdrawl rate for at least the length of the cement plug shall not exceed 30 ft/min, in order to minimize the contamination of the plug.

- 8. Within 30 days after plugging work is completed, file a Sundry Notice (Subsequent Report of Abandonment, Form 3160-5), in quintuplicate with Area Manager, Bureau of Land Management, 1235 La Plata Highway, Farmington, NM 87401. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. Show date well was plugged.
- 9. All permanently abandoned wells are to be marked with a regulation marker (4" pipe extending 4' above the ground line) containing the information as specified in 43 CFR 3162.6(d). Unless otherwise approved.
- 10. After plugging work is completed the surface is to be rehabilitated in accord with instructions from the Fluids Surface Management Section of the Farmington Resource Area Office.

All above are minimum requirements. The period of liability under the bond of record will not be terminated until the lease is inspected and surface work approved.

Please advise this office when the well location is ready for final inspection.

Failure to comply with the above conditions of approval may result in an assessment for noncompliance and/or a Shut-in Order being issued pursuant to 43 CFR 3163.1.

You are further advised that any instructions, orders or decisions issued by the Bureau of Land Management are subject to administrative review pursuant to 43 CFR 3165.3 and appeal pursuant to 43 CFR 3165.4 and 43 CFR 4.700.