

Submit 3 Copies To Appropriate District Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
1301 W. Grand Ave., Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-025-23123
5. Indicate Type of Lease STATE ☐ FEE ☒
6. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

7. Lease Name or Unit Agreement Name:

**Penroc
Ainsworth 'A'**

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

PENROC OIL CORPORATION

8. Well No.

1

3. Address of Operator

P.O. Box 2769 Hobbs NM 88241

9. Pool name or Wildcat

Lane Abo

4. Well Location

Unit Letter **P** : **660** feet from the **S** line and **660** feet from the **E** line

Section

26

Township

9S

Range

33E

NMPM

County

Lea

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE NOTED 24 ☐

THE COMMISSION MUST BE NOTED 24 HOURS PRIOR TO THE BEGINNING OF PLUGGING OPERATIONS FOR THE C-103.

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation.

11 3/4" @ 302' w/ 335 SX. circ. 8 5/8" @ 3945' w/ 400 SX. TOC calc 2100
5 1/2" @ 9760 w/ 650 SX. Calc. TOC 6437' - CTRP @ 8880' Abu Pkgs: 8805-23
RU & Pull rods & Pump. LD Rods. Pull tbg. Set CTRP @ 8750' w/ 35 SX. cement on top
Run tbg to 8700'. Displace hole w/ gelled brine. Weld on pull nipple &
stretch csg. Cut & pull csg from free point. Run tbg & spot 40 SX plug
50-50 in csg stub. Pull tbg & WOC & tag. Pull tbg to 3995' Spot
40 SX plug. Pull tbg WOC - tag. Pull tbg to 1600' spot 35 SX plug.
Weld pull nipple on 8 5/8" csg. Cut & pull 8 5/8" from 300' if free.
Run tbg to 50' inside 8 5/8" stub. Set 50 SX. cement plug. Pull tbg & WOC.
Tag. Pull tbg to 60'. Circ. cement to surface. Cut off well head & install DHM.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE **M. Y. (Merch) Merchant** TITLE **President** DATE **4/6/04**

pe or print name **M. Y. (Merch) Merchant** Telephone No. **(505) 492-1236**
his space for State use)

PPROVED BY **Larry W. Wink** TITLE **FIELD REPRESENTATIVE II/STAFF MANAGER** DATE **APR 19 2004**
nditions of approval, if any: