

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

NEW MEXICO OIL CONSERVATION COMMISSION

Orig&3cc: OCC, Hobbs
cc: State Land Office
cc: Southern Region (West Texas)
cc: file

5a. Indicate Type of Lease	State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	B-1561

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Plug and abandon oil well	7. Unit Agreement Name
2. Name of Operator SINCLAIR OIL CORPORATION	8. Farm or Lease Name State A
3. Address of Operator P. O. Box 1920, Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER J, 1980 FEET FROM THE East LINE AND 1980 FEET FROM THE South LINE, SECTION 2 TOWNSHIP 11S RANGE 37E NMPM.	10. Field and Pool, or Wildcat Echols Devonian
15. Elevation (Show whether DF, RT, GR, etc.) 3936' GR	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐
OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 11,822', PBTD 11,740' w/CIBP. Present production 0 BOPD and 1807 BWPB.
5-1/2"OD casing set @ 11,805' and cemented back to approx. 10,870'.
9-5/8"OD casing set @ 4226' and cement circulated to surface.
13-3/8"OD casing set @ 341' and cement circulated to surface.

Devonian perms. open 11,608-11,680'.

Propose To: Plug and abandon as follows: load hole w/heavy mud laden material.

Set CIBP @ 11,550', 2 sks. cement above Dev.Perfs. 11,608-11,680'.

Cut 5-1/2"OD casing @ approx. 5000' and pull.

Spot 20 sks. cement plug top of 5-1/2"OD casing stub.

Spot 20 sks. cement plug bottom of 9-5/8"OD casing @ 4226'.

Spot 10 sks. cement plug in top of 9-5/8"OD casing and cellar, set regulation dry hole marker, clean and level location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED 

TITLE Superintendent

DATE 2-12-69

APPROVED BY 

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

STAMPED DATE FEB 16 1969